

American DJ® User Instructions

COLORWASH 4™

HALOGEN LAMP WARNING!

This fixture is fitted with halogen lamps which are highly susceptible to damage if improperly handled. Never touch lamp with bare fingers as the oil from your hands will shorten lamp life. Also, never move fixture until lamp has had ample time to cool. Remember, lamps are not covered under warranty conditions.

Caution! Always disconnect from main power before replacing lamps or servicing unit. Remember to always replace with same lamps and fuses.

Model: Colorwash 4™

Specifications:

Lamp: 4 x ZB-64514 120V 300W

Dimensions: 13.25" x 9.5" x 4"

Weight: 10 lbs.

Optional: ZB-ADJ300 150 hr. Long Life lamp also available



Thank you for purchasing this American DJ® product. For your convenience this lighting effect has been lamped and is ready to be used, there is no assembly required. Please read the following instructions before installing or using your new unit.

Product Description:

Colorwash 4™

The Colorwash 4™ features a built-in four channel sound active chaser, illuminating four separate dichroic colored special design reflectors. The Colorwash 4™ creates a dramatic color wash effect. Great for special effects productions, stage, clubs, mobiles, roller-rinks, etc. Fan cooled

Operating Instructions:

Unit is ready to be hung or set on the ground. After plugging in, unit will react to the bass sounds of the music via its own internal microphone. Adjust knob on rear of unit for desired music sensitivity.

To replace lamp; Remove filter Replace bulb do not touch with bare fingers. Reassemble.

Specifications subject to change

For service, contact your *American DJ®* dealer.

American DJ® LOS ANGELES, CA. 90058