# DC166 Quick Start Guide

#### Lumens

### 

- \* Please activate your warranty at <a href="www.lumens.com.tw/reg">www.lumens.com.tw/reg</a>
- \* Please visit our website <a href="www.lumens.com.tw/goto.htm">www.lumens.com.tw/goto.htm</a> to download latest version of Software, Multilingual User Manual and Quick Start Guide.

### 1. Package Contents

#### **Main Unit**



Quick Start Guide



\* To download this manual in other languages, visit Lumens website



**VESA Base** 

Remote control



**VGA Cable** 

**USB Cable** 



C-Video Cable



RS232 Adapter (Optional)



**Power Cord** 



\* Appearance may vary in different countries

Microscope Adapter




Accessory Pouch



Presenter Protector Bag




r Bag




Backlight Padded Carry (Optional) Bag (Optional)



### 2. Getting Started




- 1 Place an object to be displayed under the camera.
- 2 Turn the power on.  $\circlearrowleft$
- 3 Adjust the gooseneck and lens to appropriate position.
- 4 Press the [ AUTO TUNE ] button to optimize the image.
  You are ready to teach / present.
  - \* Each time the camera head is moved, press the [FOCUS] button to refocus the lens.






#### **▼** Connect to a Projector or Monitor




## **▼** Connect to a Computer and Use Lumens' Software.




\* Driver and software can be downloaded from Lumens website.

# **▼** Connect a Projector, Computer simultaneously




\* Press [ SOURCE ] to change image source from Computer.

#### ▼ Connect to an Interactive Whiteboard (IWB)



#### **▼** Connect to a TV



\* NTSC: USA, CANADA, MEXICO, PANAMA, CHILE, JAPAN, TAIWAN, KOREA AND PHILIPPINES.

- \* PAL: Country / region not listed above.
- \* After the unit is re-started, new DIP switch configuration is effective.

#### **▼** Connect to an Computer via RS232

