

# Bluetooth Wireless Speaker

## Quick Start Guide




**ABS03F**

aluratek.com

qsg Q10265 Copyright © 2012 Aluratek, Inc. All Rights Reserved.

### Product Application



### Operation

#### Charging the battery

The battery is not fully charged and it is highly recommended that you charge ABS03F before you begin using it.

Note: Using ABS03F "out of the box" will not harm the device. You will experience reduced battery life as the unit will not be fully charged.

Connect the larger USB end of the cable provided to your PC / power adapter. Connect the smaller USB end to charging port of ABS03F. Please charge the battery for a minimum of (4) hours. The Red LED will be on while charging. When charging is complete, the red LED will turn off.

Function	Operation
Volume +	Press for 1 second to advance to next song. Press and hold to increase the volume.
Volume -	Press for 1 second to advance to previous song. Press and hold to decrease the volume.

### Operation

Note: The pairing mode will last for 3 minutes. If the pairing failed within 3 minutes, the system will search for the last paired device and the blue LED will flash slowly. To restart the pairing process, turn off the speaker and power on again.

#### Pairing with the transmitter such as iPhone, smart phone, and tablet:

The pairing procedure will vary depending on the actual device. Please refer to the user guide of your device for detail instruction. The general pairing procedures are as follows:

1. Make sure ABS03F is turned ON.
2. ABS03F will enter pairing mode automatically after 10 seconds. (you will hear 3 audio tones and the blue LED will flash rapidly)
3. Activate your device's Bluetooth function and set your device to search for Bluetooth devices. Select ABS03F when it is found.
4. For transmitter with Bluetooth version 2.1, you will not need to input a code. If you are prompted for PIN, please enter "0000".
5. If prompted by your device to connect, please select "Yes".
6. After connecting successfully, the blue LED will flash every 3 seconds.

Note: Please make sure the audio output is set to Bluetooth / ABS03F for audio streaming from the device.

### Tech Support & Warranty Information

If you need further assistance, please contact the Aluratek support department for troubleshooting prior to returning this device.

E-mail: [support@aluratek.com](mailto:support@aluratek.com)  
 Web: [www.aluratek.com/support](http://www.aluratek.com/support)  
 Local (Tustin, CA): 714-586-8730  
 Toll free: 1-866-580-1978

Aluratek warrants this product against defect in material or workmanship for **1 Year** from the date of purchase.

For more information, please visit: <http://aluratek.com/warranty-return-policy>

You can register your product online at: <http://aluratek.com/product-registration>

### Radio and TV Interference Statement

**WARNING!!!** This equipment has been tested and found to comply with the limits of a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instruction, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by whatever measures may be required to correct the interference.