


COOKTOP PARTS

For Models: MGR7665WW0, MGR7665WB0, MGR7665WS0
(White) (Black) (Stainless Steel)

30" GAS FREESTANDING
SELF CLEAN RANGE
SEALED BURNER



Illus. No.	Part No.	DESCRIPTION
1	W10196161	Literature Parts
		Installation Instructions
		Anti-Tip Template
	9757142	English/Spanish
	9757143	English/French
	W10234650	Owners Manual
	W10198615	Tech Sheet
	9762761	Safer Cooking Tips


Illus. No.	Part No.	DESCRIPTION
2		Cap, Burner
		Left Front
	W10183368	Black
	W10169973	Grey
		R. Front, L. Rear
	W10183369	Black
	W10169974	Grey
		Right Rear
	W10183370	Black
	W10169975	Grey
3		Burner
	8286183	Left Front
	W10194076	R. Front, L. Rear
	8286181	Right Rear

Illus. No.	Part No.	DESCRIPTION
4		Cooktop
	W10153562	White
	W10153563	Black
5		Panel, Manifold
	8523855	Black
	8523854	White
6		Knob, Control (3)
	W10200193	Black
	W10200192	White
8		Grate, Burner (4)
	W10233576	Black
	W10233577	Grey
9	3400701	Screw
10	3196557	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CONTROL PANEL PARTS

For Models: MGR7665WW0, MGR7665WB0, MGR7665WS0
(White) (Black) (Stainless Steel)



Illus. No.	Part No.	DESCRIPTION
1	W10184437	Endcap, Left Hand Black
	W10184433	White
	W10184438	Endcap, Right Hand Black
	W10184434	White
2	8053505	Shield-Heat, Lwr


Illus. No.	Part No.	DESCRIPTION
3	W10225558	Panel, Console Black
	W10111301	White
	W10225560	Stainless Steel
	4	9758080
5	W10211996	Brkt-Mntg, Console
6	8523412	Bracket, Support
7	W10198745	Cover, Upper

Illus. No.	Part No.	DESCRIPTION
8	W10192841	Shield, Heat
9	W10184370	Cover, Lower
	3196169	Screw
10	3196169	Screw
11	W10236250	Control, Range Black
	W10236249	White
12	3196178	Screw
	8273564	Clip
16	W10138683	Bracket, EOC Mount

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

MANIFOLD PARTS

For Models: MGR7665WW0, MGR7665WB0, MGR7665WS0
(White) (Black) (Stainless Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

MANIFOLD PARTS

For Models: MGR7665WW0, MGR7665WB0, MGR7665WS0
 (White) (Black) (Stainless Steel)


Illus. No.	Part No.	DESCRIPTION
1	8273096	Screw, Valve
3		Tubing, Burner W/Orifice
	W10170442	Left Front
	W10170443	Left Rear
	W10170442	Right Front
	W10170441	Right Rear
4	W10157928	Tubing (Manifold to Regulator)
5	8523406	Harness, Igniter (W/Switches)
6	W10216419	Electrode (4)
7	W10169928	Pipe, Manifold
8		Valve
	9757218	LF – RF – LR
	8273004	Right Rear
10	8273062	Screw (4)
11	3400228	Bolt
12	8054078	Burner, Broiler
13	W10184491	Spreader, Flame (Oven)
14	9758078	Burner, Bake
15	9761959	Valve/Regulator
16		Igniter
	8054129	Broil
	9758079	Bake
17	8272222	Tubing (Broiler Fitting To Valve)
18	3186489	Fitting, Broiler
20		Orifice, Burner
	W10170510	Left Front
	W10170510	Right Front
	W10170508	Left Rear
	W10170506	Right Rear
21	W10137062	Spreader, Flame (Broiler)
22	3196265	Screw
23	3196176	Screw
24	3196385	Screw
25	3400016	Screw

Following Parts Not Illustrated

W10170534 Spuds, LP Gas
(Kit of 4)

CHASSIS PARTS

For Models: MGR7665WW0, MGR7665WB0, MGR7665WS0
(White) (Black) (Stainless Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CHASSIS PARTS

For Models: MGR7665WW0, MGR7665WB0, MGR7665WS0
 (White) (Black) (Stainless Steel)


Illus. No.	Part No.	DESCRIPTION
1	W10153186	Flue Box
2	8272747	Shield, Flue
3	8273036	Burner Box
4		Panel, Side (2)
	8053830	White-Textured
	8053832	Black-Textured
5	8523249	Brkt, Manifold Mtg
6		Frame, Front (Not Serviced)
7	3196037	Foot, Front (2)
8	W10058460	Foot, Rear (2)
9	3195097	Bottom, Oven
10	W10181986	Sensor, Oven
11	8053967	Baffle, Burner
12	8053969	Shield, Heat
13	8053968	Shield, Lower
14	9760314	Rail, Base (2)
15	W10008830	Seal, Oven Flange
16	9758701	Spacer, Door
17	W10222733	Back, Main
18	8522416	Seal, Oven
19	8053971	Brace, Main Back
20		Retainer, Insul.
	9761449	Left Hand
	9761448	Right Hand
21	W10137382	Clip, Panel (6)
22	9757891	Cord, Power
23	9760407	Brkt - Hinge
24	9757262	Switch, Door
25	3196701	Light Socket Assy
26	311255	Bulb, Oven Light
27	9761013	Latch, Door
28	W10078370	Rod, Latch
29	W10107820	Latch-Mtr
30	W10114344	Glide, Drawer
31	W10182346	Insulation
33	3196178	Screw
34	3196152	Screw
35		Screw
	3196166	White
	3196168	Black
36	W10031780	Screw
37	3196179	Screw
38	3196177	Screw
39	3196168	Screw
40	9757239	Rod - Door Switch, Rear Mount
41	3196560	Screw

INSULATION

8524099 Insulation, Wrap
 W10180437 Insulation, Back
 8272613 Insulation, Vent

DOOR PARTS

For Models: MGR7665WW0, MGR7665WB0, MGR7665WS0
(White) (Black) (Stainless Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST


DOOR PARTS

For Models: MGR7665WW0, MGR7665WB0, MGR7665WS0
 (White) (Black) (Stainless Steel)

Illus. No.	Part No.	DESCRIPTION
1		Trim, Top
	W10118391	Black
	W10118390	White
2	3196164	Screw
3		Handle, Door
	W10111310	Black
	W10111309	White
	W10118391	Stainless Steel
4	9761344	Liner, Door
5	W10031790	Screw
6	9758162	Glass, Inner (2)
7	3186289	Frame, Glass
8	8272618	Insulation, Door
9	9761357	Retainer, Insul.
10	9761493	Hinge, Door
11		Glass, Outer Door
	W10106405	Black
	W10106404	White
	W10106403	Stainless Steel
12		Trim, Door Side
		Left Hand
	8523171	Black
	8523172	White
	W10113926	Stainless Steel
		Right Hand
	8523165	Black
	8523166	White
	W10113925	Stainless Steel
13	3196160	Screw
14	3196165	Screw
16	3196794	Bracket, Window(2)
17		Trim, Bottom
	8523177	Black
	8523175	White
18	9761517	Clip, Door Mntg
19	W10031780	Screw
20	W10113759	Strap, Door

DRAWER & BROILER PARTS

For Models: MGR7665WW0, MGR7665WB0, MGR7665WS0
 (White) (Black) (Stainless Steel)



Illus. No.	Part No.	DESCRIPTION
1	W10179196	Rack, Oven (2)
2	9761031	Drawer, Storage
3	W10174397	Bracket, Drawer(2)
4		Rivet, Push (2)
	3196814	White
	3196813	Black
5		Panel, Drawer Frnt
	W10022090	White
	W10022100	Black
	8053338	Stainless Steel
6	8053334	Spacer, Glide
7	3196168	Screw
8	3196167	Screw
9	W10217861	Panel (Stls Steel)
10	W10197980	Hndl (Stls Steel)
11	9781235	Clip (Stls Steel)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OPTIONAL PARTS

For Models: MGR7665WW0, MGR7665WB0, MGR7665WS0
(White) (Black) (Stainless Steel)

Illus. No.	Part No.	DESCRIPTION
<u>REFINISHING MATERIAL</u>		
	242756	Touch-Up Self-Clean(1/2 Pt)
<u>INSULATION</u>		
	261514	Insulation, Fiberglass (1-1/2" x 24" x 120")
	240132	Insulation, Fiberglass (2-1/2" x 22" x 120")
<u>PAINT, TOUCH-UP (1/2oz.)</u>		
	72017	White
	4392899	Biscuit
	511873	White Porcelain (2 Oz.)

Illus. No.	Part No.	DESCRIPTION
<u>PAINT, PRESSURIZED SPRAY (12 oz.)</u>		
	350930	White
	4392901	Biscuit
	285006	Superior Black
	206922	Primer (White)
<u>PAINT, BULK (1 qt.)</u>		
	799344	White (Uncut)
	4392900	Biscuit (Uncut)
<u>ACCESSORY PARTS</u>		
	241430	Foil, Aluminum Oven (18" x 25')
	4396923	Pan - Broiler

Illus. No.	Part No.	DESCRIPTION
<u>ANTI-TIP KIT</u>		
	W10017440	Anti-Tip Kit
<u>WIRING HARNESS PARTS</u>		
	W10182840	Harness, Main (EOC Pyro)
	W10170250	Harness, Wire Bake/Broil
	W10174458	Harness, Wire (Cooktop Spark)
	W10045060	Harness, Wire (Ground)
	3196896	Clip, Wire
	3400016	Clip, Wire
	313438	Clip, Harness
	3196173	Screw
	3196696	Clip, Harness
	3196174	Screw-Grnd Harns