

Sony "AUX-LITE" Application guide for Peripheral PXA07 and PIE SON-AUX.

Looking for a way to play the audio from a portable device, video system, or anything else through your Sony Car stereo system?

We make it extremely simple.

You can connect optional portable devices to the BUS AUDIO IN (see Fig.1) terminal on the Sony AUX-LITE Ready unit. If the changer or other device is NOT connected to the terminal, the unit allows you to listen to the portable device on your car speakers.

Note:

When connecting a portable device, be sure BUS CONTROL IN is not connected. If a device is connected to BUS CONTROL IN, "AUX" cannot be selected with the "SOURCE" button.

Tip

When connecting both a portable device and a cd changer, use the optional "AUX-IN selector (i.e. Sony XA-300 or PIE SON-AUX)

Purchase our PXA07 iPod adapter with charging feature to play your iPod on the Sony AUX-LITE Ready Stereo.

Installation instructions for Peripheral PXA07

1. Connect the RCA outputs of the PXA07 to the "BUS AUDIO IN -AUX IN" connectors on the back of the Sony radio
2. Connect iPod to the dock connector
3. Connect the red wire to +12V "ignition wire" and gray to ground.
3. Look up the user manual for the corresponding Sony radio to enable to "AUX-Lite" function - Here is how to enable the "AUX-LITE" function on Sony CDX-630 CD Receiver

Selecting Auxiliary on Sony AUX-LITE Ready Radios

It is possible to use auxiliary equipment with this unit. Activate the auxiliary setting when using auxiliary equipment connected to this unit.

1. **Press SOURCE** repeatedly until **AUX**
Aux appears in the display.
2. **Adjusting the volume level.**
Press **MENU** appears in the display.
Press the **▲ ▼** repeatedly to select the "AUX Level"
Press **Enter**
Press the **▲ ▼** repeatedly to select the desired level
the volume level is adjusted in 1dB steps from -6dB to + 6dB
Press **Enter**



Fig. 1

SONY "AUX-LITE" Ready Radios

If you're looking for a way to play a portable audio device, video system, or anything else through your Sony system, we make it extremely simple. In models with Aux Lite, the BUS audio inputs can be used as an auxiliary input instead of a CD changer input, allowing any audio signal to play through the head unit, and the entire audio system. **Warning: The Sony Radio must be "AUX-LITE" ready.**

The following Sony radios are "AUX-LITE" ready:

CDX-GT805DX	CDX-GT705DX	CDX-F605X
MEX-BT5000	CDX-R505X	CDX-F50M
CDX-RA700	CDX-GT500	MEX-1GP
CDX-M7815X	CDX-M7810	CDX-F7715X
CDX-F7710	CDX-M8815X	CDX-R5715X
CDX-M8810	CDX-F5710	CDX-F7005X
CDX-F7705X	CDX-M8805X	CDX-M8800
CDX-F7700	CDX-F5705X	CDX-F7000
CDX-F5700	CDX-M850MP	CDX-M3DI
CDX-M800	CDX-M630	MEX-5DI
CDX-CA900X	CDX-GT805DX	

Use the SON-AUX audio switcher to connect two audio devices to any AUX LITE Ready Radio (no CD Changer required).
Use the SON-AUX audio switcher to connect a single audio device to Sony radios without AUX-LITE (CD Changer required)

Revised July 17, 2008

© 1995-08 Discount Car Stereo, Inc. All rights reserved. Information in this document is subject to change without notice. Other products and companies referred to herein are trademarks or registered trademarks of their respective companies or mark holders.