


TE110DS manual override switch

In some cases, customers may require a manual button or switch that allows them to activate their doorstrike without using the TE110DS. The diagram below shows one possible wiring schematic to accomplish this.



Use a standard pushbutton or any device that will provide a momentary contact closure and wire it across the 'Strike' terminals on the TE110DS. When the button is pressed, power will be delivered to the strike mechanism causing it to activate

CHANNEL VISION
Costa Mesa CA 92626
1-800-840-0288
www.channelvision.com

Title
TE110DS manual override switch

Size A	File Name TE110DS_pushbutton override
Scale na	Sheet 1 of 1 Date 09/04