



4-POLE SUN SHADE MODEL 2000001652

Before you begin



Read all instructions before set up.

- Select a level site clear of rocks, branches, and other hard or sharp objects, to install your sun shade.

⚠ WARNING: Keep clear of overhead power lines.


- Do not set up your sun shade under trees because of potential lightning strikes or falling tree limbs in inclement weather.
- Secure with **all** stakes and guylines provided to prevent property damage or personal injury.
- For best results in windy conditions, position narrow end of sun shade into the wind.
- Enlist the help of at least one other person to assist you when it is time to assemble the sun shade.
- Under no circumstance should this product be used to cover automobiles, marine products or similar.

ASSEMBLY PARTS



Sun Shade Assembly

1. Assemble the shock-corded short and long Metal Poles. (Fig. 1)
2. Insert narrow metal tip on long Metal Pole into metal grommet located on the web strap long end of the sun shade. (Fig. 2)
3. Lift pole to upright position; then extend out the guylines tied onto the web strap. (Fig. 2)
4. Slip loop on each guyline over plastic stake and drive in at a slight angle to secure. (Fig. 3)
5. Repeat steps 3 & 4 above for the remaining long Metal Pole and guylines.
6. Insert narrow metal tip on short Metal Pole into metal grommet located on the web strap at the front of the sun shade. (Fig. 2)
7. Lift short Metal Pole to upright position; then extend out the guyline tied onto the web strap. (Fig. 2)
8. Slip loop on guyline over plastic stake and drive in at a slight angle to secure. (Fig. 3)
9. Repeat steps 6 & 7 above for the remaining short Metal Pole and guyline.
10. Extent out remaining guylines at back of the sun shade until taut and secure with plastic stakes. (Fig. 2)



STITCH LINE

(continued on other side)

Things You Should Know:

- Tree limbs, tree sap, bird droppings, or moisture steadily dripping off tree limbs can cause damage to the sun shade fabric and its coating resulting in leaks or loss of flame-resistant properties.
- Never store this product, even for a short period of time, without drying it thoroughly and brushing off caked dirt. Do not pack stakes or poles inside your this product. Use a separate storage bag.
- Stakes should be removed by pulling on the stake itself. NEVER PULL ON THE SUN SHADE TO REMOVE STAKES AS THIS COULD RESULT IN PROPERTY DAMAGE OR PERSONAL INJURY.
- Metal poles should not be left telescoped together during storage.
- Do not leave this product set-up for weeks at a time. Be aware that exposure to ultraviolet rays from the sun can seriously damage material and/or cause it to become discolored.
- This product is intended to provide protection from sunlight. It is not intended to be used during heavy rain, wind, hail, snow or other inclement weather. Excess water build up can cause the frame system to become unstable, and possibly collapse, causing injury.

⚠ WARNING: Keep all flame and heat sources away from this tent fabric.

This tent meets the flammability requirements of CPAI-84. The fabric may burn if left in continuous contact with any flame source. The application of any foreign substance to the tent fabric will render the flame-resistant properties ineffective.



The Coleman Company, Inc. • 3600 N. Hydraulic • Wichita, Kansas 67219
1-800-835-3278 • www.coleman.com

MADE IN CHINA • PRINTED IN CHINA

© 2008 The Coleman Company, Inc.

Coleman®, , and  are registered trademarks of The Coleman Company, Inc.

STITCH LINE