



	Acer N300 Series
מערכת הפעלה	Microsoft [®] Windows Mobile [™] Version 5.0 Software for Pocket PC, Premium Edition with Microsoft [®] Outlook [®] 2002
מעבד	Samsung S3C2440 processor at 400 MHz
זיכרון	64 MB mobile SDRAM for system operation
Flash ROM*	128 MB of flash memory for operating system, embedded applications, user applications and storage
תצוגה	3.7" high-brightness transflective TFT LCD (65,536 colors) with 480 x 640 VGA resolution
מידות	110 (L) x 70 (W) x 13.7 (H) mm 4.33 (L) x 2.76 (W) x 0.54 (H) inches
משקל	135 g 4.76 oz.
חריץ הרחבת זיכרון	SD/MMC expansion slot with SDIO support USB Host/Client 1.1
שמע	Built-in microphone and speaker 3.5 mm stereo earphone jack (2 watt)
Special keys and buttons	Four quick-launch application buttons: Today, Calendar, Contacts, Messaging 5-way joystick Soft reset button Power button Hold switch Battery access latch
LED	Red/Green LED — Alarm, battery charging Blue LED — Bluetooth ® and wireless LAN*
סוללה	Rechargeable and replaceable 1200 mAh Li-ion battery 8-hour battery life when backlight is inactive 3 hours to fully charge
Proprietary 26-pin connector	USB Host 1.1 USB Client 1.1 Serial port DC-in
ActiveSync [®]	Available via USB sync cable, serial sync cable, wireless LAN * , Bluetooth® or cradle
Wireless	Bluetooth® 1.2 IEEE 802.11b wireless LAN *
תוכנות שכבר מותקנות	Outlook [®] Mobile — Organize personal information: calendar,

contacts, tasks, notes and messaging Word™ Mobile — Word processing application compatible with Microsoft® Word Excel™ Mobile — Spreadsheet application compatible with	במכשיר
Microsoft [®] Excel	
PowerPoint [™] Mobile — Presentation slide application compatible with Microsoft [®] PowerPoint	
Windows [®] Media™ Player 10 Mobile — Play back multimedia	
files: MP3, Windows [®] Media audio, Windows [®] Media video, and streaming video files	
Internet Explorer Mobile — Browse websites and download	
files and images Voice recorder	
Calculator — Easy-to-use calculator	
Games — Enjoy playing classic Solitaire and Bubble Breaker File Explorer — Manage files in flash memory or on storage	
media cards	
Microsoft [®] ActiveSync [®] 4.0 — Synchronize PIM data with Microsoft [®] Outlook [®]	
Pictures & Videos — View pictures and videos	
Lunar View * * — View the Chinese lunar calendar	
Pocket MSN — Provides instant access to your MSN Hotmail account and MSN Messenger Contacts list	
Backup/restore utility — Back up/restore important files onto	
external storage devices System Info — Monitor hardware and software status and	
information	
Power control — Fine-tune power settings for optimal battery life	
Backlight Control — Change backlight settings for optimal viewing quality	
Microphone AGC and volume control setting — Control the quality of voice recordings	
Speaker control setting — Adjust speaker volume settings Bluetooth® setting — Easily configure Bluetooth® options Wireless LAN setting * — Easily configure wireless LAN options	
Terminal Services Client * * * — Run applications or remotely manage a server from the Pocket PC	
Pocket TV Enterprise Edition — Play back MPEG 1 video files	Cattina Otanta d CD
Microsoft [®] Outlook [®] 2002 Microsoft [®] ActiveSync [®] 4.0 Acer n300 Handheld User Guide	Getting Started CD
Acer n300 stylus	תוכן האריזה
Acer n300 battery pack Acer n300 cradle *	
SD dummy card	
Acer n300 series pouch AC adapter	
USB sync cable *	
USB sync cable	אביזרים נלווים
3-in-1 sync cable USB host and DC-in cable)לא כלולים באריזה(
Serial sync cable	
DC-in adapter AC adapter kit	
Car charger	
Foldable keyboard Acer n300 book-style leather cover	
Acer n300 flip-top leather cover	
Acer n300 cradle Acer n300 battery pack	
Acer n300 high-capacity battery pack	
Acer n300 screen protector Acer n300 stylus pack	
Acei 11000 stylus pack	

שנתיים אחריות	אחריות עולמית
* Specifications vary depending on model and usage. *** Available only with English and European language versions of Microsoft® Windows Mobile™ Version 5.0.	
Acer recommends Microsoft [®] Windows Mobile™ 5.0	