

*IPiParty*tm

Wireless iPod sender



*Wireless connection between your iPod
and any audio system.*

*Use your iPod as a remote control and scroll,
shuffle and play like you're used to.*

*The transmitter has its own rechargeable battery
and does not use any power from your iPod.*

MARMITEK






iParty

- Wireless connection to any type of audio system.
- Enjoy your iPod music with other people.
- Use your iPod as a remote control: scroll, shuffle and play like you're used to.
- The transmitter has its own rechargeable battery and does not use any power from your iPod.
- The receiver is also a charger (2 rechargeable batteries included).
- Universal 3.5 mm jackplug cable included for use with other MP3 players.
- Separate receiver and transmitter available.
- Available for iPod Mini or iPod Nano.



HOW DOES IT WORK?



The iParty creates a wireless connection between your iPod and your audio system. Just click your iPod onto the iParty transmitter. The receiver can be connected to your hifi system via the RCA cable included. The transmitter has its own rechargeable battery and does not use any power from your iPod. A second rechargeable battery is included and can be charged up in the receiver. This means you always have a fully charged battery available.

TECHNICAL INFORMATION

- Range: 10-15 m
- Audio: stereo
- Frequency: 864 MHz
- Number of channels: 2 channels
- Power adapter for receiver: 230 VAC/50 Hz, 12 V/200 mA adapter
- Battery for transmitter: NiMh AAA 1.2V, 800 mAh
- Dimensions receiver: 95x85x24 mm
- Dimensions Mini transmitter: 96x55x22 mm
- Dimensions Nano transmitter: 112x44x14,5 mm

SET CONTENTS

- iParty transmitter (Click On)
- iParty receiver
- 2 Rechargeable batteries for the transmitter (NiMh)
- 1 Power adapter 230 V for the receiver
- 1 RCA cable
- 1 Universal 3.5 mm jackplug cable for use with other MP3 players
- User manual (English - German - French - Spanish - Italian - Dutch)

AVAILABLE PRODUCTS

- iParty Mini Set (E) Art. No. 09691
- iParty Mini Set (U) Art. No. 09700
- iParty Nano Set (E) Art. No. 09720
- iParty Nano Set (U) Art. No. 09725
- Extra iParty Mini receiver (E) Art. No. 09705
- Extra iParty Mini receiver (U) Art. No. 09708
- Extra iParty Nano receiver (E) Art. No. 09710
- Extra iParty Nano receiver (U) Art. No. 09722
- Extra iParty Mini transmitter Art. No. 09712
- Extra iParty Nano transmitter Art. No. 09718