




CABINET PARTS

For Models: 7ET18ZKXDW00, 7ET18ZKXDN00
(White) (Almond)


REFRIGERATOR



1		Cabinet (Not A Serviceable Part)
2	2157591	Hinge (Top)
3	2166108	Roller-Front (2)
4	489459	Screw
5	489385	Clamp, Tube (Water Supply Line)
9	489436	Screw
10	2179826	Rivet
11	2174650	Screw
12	549193	Clamp-Cord
15	489423	Screw
16	2183064	Hinge, Center
17	2163757	Shim, Hinge Center
18	489463	Screw
20	2179829	Hinge Butt
23	2172745	Shim, Bottom Hinge
24		Fitting, Water Tube (NOT SERVICED)
27		Hole Plug (12)
	2151652	White
	2151653	Almond
31	2166251	Cover, Valve
35		Corner Filler (2)
	2163733	White
	2166187	Almond
36		Grille
	2182429	White
	2182430	Almond
38	487576	Washer
39	1123517	Shim
40		Cover-Hinge
	2160403	White
	2160404	Almond
41		Rail, Center (NOT SERVICED)
42		Corner Filler, Grille
	2166156	White
	2166204	Almond
43	2183063	Pin, Hinge
44	2183158	Cover, Unit

FREEZER DOOR PARTS


For Models: 7ET18ZKXDW00, 7ET18ZKXDN00
(White) (Almond)



1		Freezer Door (Includes #8)
	2182487	White
	2182491	Almond
4	2159367	Bracket, Door Stop
5	488921	Screw, 8 x 1/2
6	2183003	Thimble
7		Hole Plug
	844478	White
	989196	Almond
8	2159327	Door Gasket, Magnetic
10		Handle End, Top
	9791776	White
	9791777	Almond
11		Handle End
	9791771	White
	9791772	Almond
12		Handle, Center
	2171043	White
	2171044	Almond
13	943187	Shim, Handle
14	943188	Spacer, Handle Door Panel
16	489006	Screw, 8 x 5/8
17	2171037	Trim, Door Shelf (2)
18		Nameplate
	2162781	White Model
	2162782	Almond Model
22	2156002	EndCap, Trim (4)

SHELF PARTS


For Models: 7ET18ZKXDW00, 7ET18ZKXDN00
(White) (Almond)



1	2172637	Shelf, Ladder (2)
2	2172638	Shelf, Ladder Center
3	2163762	Cup, Shelf Mtg.
4	2163835	Track, Crisper
5	489415	Screw
6	520965	Screw Support
7	2163853	Shelf, Cantilever
8	2176262	Trim, Shelf
9	2190580	Crisper Cover
11	2174665	Glass, Crisper Cover
12	2176305	Pan Shelf, Cantilever
13	2163882	Retainer, Glass
14	2166216	Glass, Meat Cover
15	2172541	Crisper Support
16	2163856	Shelf, Full Cantilever
17	2176275	Shelf, Freezer
19	2190528	Pan, Crisper
20	2190682	Pan, Meat
22	841180	Ice Tray
23	1116917	Container
24	2190529	Crisper Pan
25	2166748	Egg Bin

REFRIGERATOR DOOR PARTS


For Models: 7ET18ZKXDW00, 7ET18ZKXDN00
(White) (Almond)



1		Refrigerator Door (Includes #8)
	2171029	White
	2171030	Almond
3	2159303	Shelf, Flip-Up
4	944035	Bracket, Door Stop
5	488921	Screw, 8 x 1/2
6	2183003	Thimble
7		Hole Plug
	844478	White
	989196	Almond
8	2159057	Door Gasket, Magnetic
10		Handle End
	9791771	White
	9791772	Almond
11		Handle End, Side
	2183141	White
	2183142	Almond
12		Handle, Center
	2148035	White
	2148036	Almond
14	943188	Spacer, Handle Door
16	489006	Screw, 8 x 5/8
17	487909	Screw, 8 x 1/2
18		Screw Cover
	9791769	White
	9791770	Almond
20	2171038	Trim, Door Shelf
21	2184570	Trim, Door Shelf
22	2171036	Door Compartment
23	2171040	Trim-Door Shelf
24		Hole Plug, Handle
	1122653	White
	1122654	Almond
26	2160050	Divider, Door Shelf
29	2156001	Endcap, Trim (2)
30	2156000	Endcap, Trim (4)
35	2171039	Trim, Door Shelf
37	2171041	Trim-Door Shelf
38	2156006	Plug-Trim (2)
39	2156007	Plug-Trim (2)

LINER PARTS


For Models: 7ET18ZKXDW00, 7ET18ZKXDN00
(White) (Almond)



1		Liner (Not A Serviceable Part)
2	531933	Grommet (2)
3	2166181	Gasket, Evaporator Cover (Side)
4	2183400	Timer, Defrost
5	549512	Thermostat Tube Barrier
6	941839	Hole Plug
7	2172542	Wire Assy. Control Box
8	2162085	Socket, Light (2)
9	2179858	Damper, Air
10	2176298	Fan Motor
11	2163777	Fan Blade
12	2179790	Control Box
13	2193210	Thermostat Assy. (Includes Items 5, 18, & 36)
14	489438	Screw
15	489412	Screw
16	2183154	Cover-Evaporator
17	946059	Light Bulb (2)
18	2163802	Weight, Thermal
19	1118894	Rocker Arm Switch
20	2179859	Post, Damper
21	2176281	Cover, Air Diffuser
22	2176296	Knob, Thermostat
23	2182340	Air Tower
24	2176280	Air Diffuser, Bottom
25	2172565	Freezer Floor
26	2179877	Air Diffuser, Top
27	2183038	Cover, Hole
29	2163827	Bracket, Fan Motor
30	2166178	Gasket, Evaporator Cover (Top)
31	2174629	Air Return & Foil Assembly
32	487996	Cap
33	2174610	Wire Assembly, Freezer Compartment
34	2176297	Knob, Damper
35	2163810	Bracket, Damper Knob
36	2172532	Seal, Rear Thermostat
38	2176341	Clip, Defrost Timer
39	2171846	Valve, Release

UNIT PARTS

For Models: 7ET18ZKXDW00, 7ET18ZKXDN00
(White) (Almond)



1	2182437	Plate, Unit Mounting
2	489242	Screw
3	2179882	Condenser
4	2176300	Heater, Defrost
5	2176337	Evaporator Assy.
6	489414	Screw
7	2172619	Drain Pan
8	2182380	Defrost Bi-Metal
9	2176301	Bracket, Heater
10	2163780	Extension, Air Baffle
11	489473	Screw
12	2162358	Cover
13	2154759	Overload (Includes Relay)
14		Grommet (4)
	2183042	4roduction
	1100826	Service
15		Relay (See Overload)
17	2163782	Roller (2)
18	981126	Rivet
19	2182338	Clip, Heater
20	2183183	Protector
21		Nut (Not Serviced)
28	2169441	Compressor (Includes Items 12, 13, 15, 29, 32, 38 & 56) (Also
Order		
	482801	Installation Kit
	876765	Tube Kit
29	2174865	Drier
30	2155774	Clamp
32	2169137	Capacitor (Service Only)
38	2172890	Wire Assembly
39	2182395	Air Baffle
40	2176336	Motor, Condenser
42	2184586	Wire Assy. Unit
43	851732	Fan Blade
44	486692	Nut
46	2179856	Tube, Discharge
47	2179854	Tube, Suction
48	2154109	Tube, Process
49	2174670	Tube, Condenser To Heat Loop
56	487240	Screw
58	2163795	Evap. Tray

Following Parts Not Illustrated and Optional Parts Not Included

978025	Valve, Access (1/4")
978026	Valve, Access (5/16")
978027	Valve, Access (3/8")
978028	Valve, Access (1/2")
978029	Valve, Access (5/8")
978030	Valve, Access (3/4")
876764	Valve, Access (3/16")
482278	Start Kit

REFRIGERANT CHARGE 4.0 Ozs. (R134A)

Parts Not Illustrated and Optional Parts (Not Included)

Miscellaneous

978941 Insulation, Fiberglass (63-1/2" x 35-1/2" x 2-5/8")
212643 Sealer, Gum (4 Feet)
479502 Tape, Vinyl (3/4" x 108")
876305 Kit, Insulation (14 Pcs. 3" x 24" x 48")
876370 Kit, Insulation (2 Pcs. 3" x 24" x 48")
876029 Kit, Foam Slab (30" x 32-1/2" x 1-1/2")
505587 Sealer, Mastic (1 Qt.)
511873 Touch-Up, White Porcelain (2 Oz.)
542638 Grease, Silicone (1/2 Oz.)
542639 Cement, Alumilastic (1-1/4 Oz.)
606755 Bag, Insulation (36-5/8" x 46")
799833 Kit, Evaporator Repair (Aluminum Epoxy)
799832 Kit, Porcelain Repair (White)
503695 Cork Sealer (1/4 Pound)
2172516 Door Reversal Instructions

Customer Touch-Up Material

350942 *Primer, White (13 Oz. Spray Can)
350939 *Enamel, Black (13 Oz. Spray Can)
350930 *Enamel, White (13 Oz. Spray Can)
350956 *Enamel, Almond (13 Oz. Spray Can)
72017 Brush Touch-Up Kit (White)
72032 Brush Touch-Up Kit (Black)
72107 Brush Touch-Up Kit (Almond)

Refinishing Material

799344 Enamel, White (1 Qt. Uncut)
978883 Enamel, Almond (1 Qt. Uncut)
833938 Kit, Terminal Connector

Caution: The Spray Paint Is Not To Be Used Where The Paint May Make Contact With
The Door Gaskets

LITERATURE PARTS

LIT2172667 Service & Wiring Sheet
LIT2182565 Energy Label
LIT2193016 Use & Care Guide

Following May Be Purchased DO-IT-YOURSELF REPAIR MANUALS

LIT677969 Do-It-Yourself Manual Ref./Fzr.
LIT677971 Do-It-Yourself Manual, Ice maker

FIELD INSTALLABLE ICE MAKER ECKMF94

TORX SCREW WRENCH

1117510 Torx Key