




WATERPROOF INDOOR/OUTDOOR BLUETOOTH® SPEAKER

Item # NS-BT007

TO USE BY CONNECTING WITH BLUETOOTH BASE (AV DONGLE)

1. Press & Hold the Speaker Pairing Button  for 8 Seconds until LED flashes Red then Blue



LED Flashes
Red & Blue

2. Press & Hold the Dongle (Base) Pairing button  for 8 seconds until LED Flashes Red then Blue




LED Flashes
Red & Blue

3. After steps 1 & 2 are completed - wait 3 - 5 seconds - LEDs on Speaker & Base will Flash Blue to Confirm Pairing



4. Plug the 3.5mm Phone Jack on the Base into the Headphone Jack on your Audio Device, then Press PLAY



ACCESSORIES LIST:



SPEAKER



BLUETOOTH®
AV DONGLE



USB CABLE



USB ADAPTOR



4x AA BATTERY

Remarks:

1. After approximately 1 Minute - the Speaker and Dongle will exit the Pairing Mode if the Pairing Operation Fails
2. The Password of this speaker is set to "0000" - It can only be paired with a Bluetooth Device whose Password is set to "0000"