



myPDFmanuals

You can read the recommendations in the user guide, the technical guide or the installation guide for TOSHIBA BDX 3300. You'll find the answers to all your questions on the TOSHIBA BDX 3300 in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.


User manual TOSHIBA BDX 3300
User guide TOSHIBA BDX 3300
Operating instructions TOSHIBA BDX 3300
Instructions for use TOSHIBA BDX 3300
Instruction manual TOSHIBA BDX 3300



TOSHIBA



Blu-ray Disc™ Player



BDX3300KB
Owner's Manual



[Your user manual](#)
[TOSHIBA BDX 3300](#)

Manual abstract:

If the fuse cover is lost or damaged, the plug must not be used until a replacement available from the appliance manufacturer is obtained. If the plug has to be changed because it is not suitable for your socket, or becomes damaged, it should be cut off and an appropriate plug fitted following the wiring instructions below. The plug removed must be disposed of safely as it is hazardous if inserted into a live socket. 3 English Disposal of your old product and batteries
IMPORTANT The wires in this mains lead are coloured in accordance with the following code: BLUE: NEUTRAL BROWN: LIVE As the colours of the wires in the mains lead of this unit may not correspond with the coloured markings identifying the terminals in your plug, proceed as follows: The wire that is coloured blue must be connected to the terminal in the plug which is marked with the letter N or coloured black. The wire that is coloured brown must be connected to the terminal which is marked with the letter L or coloured red. Do not connect either wire to the earth terminal which is marked by the letter E or by the safety earth symbol or coloured green or green-and-yellow. Use a 5A BS1362 fuse which is approved by ASTA or BSI. Always replace the fuse cover after changing the fuse. Copyright notice This product incorporates copyright protection technology that is protected by U.S.

patents and other intellectual property rights. Use of this copyright protection technology must be authorized by Rovi Corporation, and is intended for home and other limited viewing uses only unless otherwise authorized by Rovi Corporation. Reverse engineering or disassembly is prohibited. Notice for Trademark English 4 HDMI, the HDMI logo and High-Definition Multimedia Interface are trademarks or registered trademarks of HDMI Licensing LLC in the United States and other countries. BONUSVIEW™ Blu-ray Disc™, Blu-ray™, BD-Live™, BONUSVIEW™, and the logos are trademarks of the Blu-ray Disc Association.

Manufactured under license from Dolby Laboratories. Dolby and the double-D symbol are trademarks of Dolby Laboratories. Manufactured under license under U.S. Patent Nos: 5,956,674; 5,974,380; 6,226,616; 6,487,535; 7,392,195; 7,272,567; 7,333,929; 7,212,872 & other U.

S. and worldwide patents issued & pending. DTS-HD, the Symbol, & DTS-HD and the Symbol together are registered trademarks & DTS-HD Master Audio 1 Essential is a trademark of DTS, Inc. Product includes software. © DTS, Inc. All Rights Reserved. AVCHD' and the AVCHD' logo are trademarks of Panasonic Corporation and Sony Corporation. DVD Video' is a trademark of DVD Format/ Logo Licensing Corporation. Oracle and Java are registered trademarks of Oracle and/or its affiliates. Other names may be trademarks of their respective owners.

"Wi-Fi CERTIFIED" logo is a registered trademark of Wi-Fi Alliance. "Wi-Fi PROTECTED SETUP" logo is a trademark of Wi-Fi Alliance. DLNATM, DLNA CERTIFIED™ are trademarks, service marks, or certification marks of the Digital Living Network Alliance. YouTube is a registered trademark of Google, Inc. Picasa is a trademark of Google, Inc. 5 English 2 Your Product Region Regions Codes Both the Blu-ray Disc Player and the discs are coded by region. These regional codes must match in order to play the disc. If the codes do not match, the disc will not play. The Region Number for this Blu-ray Disc™ Player is described on the rear panel of the Blu-ray Disc™ player. TM Blu-ray™ discs that can be played English 6 North America, Central America, South America, Korea, Japan, Taiwan, Hong Kong and South East Asia. Europe, Greenland, French territories, Middle East, Africa, Australia and New Zealand. Region DVD discs that can be played U.S.A. and Canada regions U.K., Europe regions and Japan Asia Pacific, Taiwan, Korea ALL ALL ALL ALL ALL 1 2 3 4 5 6 India, China, Russia, Central and South Asia. Australia, New Zealand, Latin America Russia and India regions China, Calcos Islands, Walls and Futuna Islands Feature highlights High-Definition entertainment Watch high-definition content disc with HDTV (High Definition Television). Connect it through a high speed HDMI cable..



[Your user manual](#)
[TOSHIBA BDX 3300](#)