

2mm ShortTrim

Product Compatibility

Pink Memory Stick Micro™ is compatible with the following Sony Ericsson mobile phones*:



K790i / K800i



M600i



K610i



Z530i



Z550i



W300i

* The compatibility with other devices is not guaranteed.

FOLD

Specifications

	MSA512A-PINK
8 digit PC	50118125
EAN code PC	3355830018051
Master carton quantity	10 pcs
Capacity	512MB
Approximate user capacity	450MB
Approximate Pink content size	82MB
Interface	Memory Stick Interface Serial/Parallel
Operating Voltage	2.7V - 3.6V
Operational Current-	
Parallel (Serial)	100mA Max (65mA Max)
Standby Current	1.5mA Max
Transfer Speed	160Mbps (20MB/sec)
Minimum Write Speed	15Mbps
Dimensions (WxLxT)(mm)	15x12,5x1,2
Weight	1g
Environmental Temperature	-25°C to 85°C
Warranty time (years)	5
Supplied Accessories	Operating instructions, M2 standard adaptor

The "Memory Stick Micro™" capacity is composed of the actual usable capacity (user capacity), and system files.
The user capacity of this product is approximately 450MB.
Approximately 82MB of user capacity is, at the time of purchase, used by PINK pre-loaded music and video files. These files can be deleted by the user.

Blog Song and Mobitube are protected trademarks of Sony BMG Entertainment France
Sony, "like.no.other" and "Memory Stick" are registered trademarks of Sony Corporation, Japan

SONY

© SONY BMG MUSIC ENTERTAINMENT

FOLD

FOLD

SONY

Exclusive P!NK Video and Music for your mobile



p!nk



Pre-loaded "Stupid Girls" BlogSong™ and MobiTube™ on "Memory Stick Micro™"

MEMORY STICK MICRO

M2



MEMORY STICK

MSA512A-PINK

like.no.other™

FOLD



Entertainment with no limits

- **Enjoy P!nk at her best** with this limited edition Memory Stick™
Pre-loaded content features her exclusive 'Stupid Girls' BlogSong™ video and MobiTube™ audio edit.
- **Discover** how easy it is to transform your mobile phone into a never-ending entertainment centre, thanks to the advanced technology of Sony Ericsson mobile phones and Sony Memory Stick Micro™.
- **Share!**
The content included in the P!nk Memory Stick Micro™ is completely copyright free.



Instructions



Before start:

Check your mobile phone model name.
The instructions in this manual are for 7 models (M600i, W300i, Z530i, Z550i, K610i, K790i and K800i).

Insert the "Memory Stick Micro™" ("M2™") card in your mobile phone.

Please refer to the instruction manual provided with your mobile phone to check the correct direction of insertion.

If you are experiencing difficulties, please contact the Memory Stick Customer Support: <http://www.sony.net/memorystick/supporte/>



Audio

Using Media Player, Walkman® player or Music Player

1. Follow the operation corresponding to your mobile phone as indicated below:
 - **M600i**: Select Menu > Select Media Player > Music* > Artists.
 - **W300i**: Select Menu > Select Walkman® Player > Artists.
 - **Z530i / Z550i**: Select Menu > Select Media Player > Artists.
 - **K610i / K800i / K790i**: Select Menu > Select Music Player > Artists.
2. Select "P!NK" > "I'm Not Dead" > "Stupid Girls" and select Play. Playback starts.

* The first time you open Music, select More > Update music to search the phone memory and the Memory Stick for sound files, please refer to your mobile phone operating instructions.

Using File Manager

1. Follow the operation corresponding to your mobile phone as indicated below:
 - **M600i**: Select Menu > Select Tools > File Manager > Select Memory Stick Tab > Music.
 - **W300i / Z530i / Z550i**: Select Menu > Select File Manager > Select Memory Stick Tab > Sounds.
 - **K610i / K800i / K790i**: Select Menu > Select File Manager > Select Memory Stick Tab > Music.
2. Select "P!nk - Stupid Girls" > "Stupid Girls mp3-128" and select Play. Playback starts.



Video

Using Media Player, Walkman® player or Video player

1. Follow the operation corresponding to your mobile phone as indicated below:
 - **M600i**: Select Menu > Select Media Player > Video > Select Memory Stick Tab > "P!nk - Stupid Girls - BlogSong™" > "M600" folder.
 - **W300i**: Select Menu > Select Walkman® Player > Videos.
 - **Z530i / Z550i**: Select Menu > Select Media player > Videos.
 - **K610i / K800i / K790i**: Select Menu > Select Entertainment > Video Player.
2. Select the video clip corresponding to your mobile phone as indicated below:
 - **M600i**, select your preferred language such as "P!NK English - M600" and select Play.
 - **K800i / K790i**, select your preferred language such as "P!NK English - K800, K790" and select Play.
 - **K610i**, select your preferred language such as "P!NK English - K610" and select Play.
 - **W300i / Z530i / Z550i**, select your preferred language such as "P!NK English - Others" and select Play. Playback starts.

Using File Manager

1. Follow the operation corresponding to your mobile phone as indicated below:
 - **M600i**: Select Menu > Select Tools > File Manager > Select Memory Stick Tab > Video.
 - **W300i / Z530i / Z550i / K610i / K800i / K790i**: Select Menu > Select File Manager > Select Memory Stick Tab > Videos.
2. Select "P!nk - Stupid Girls - BlogSong™".
 - 2.1. For **M600i / K610i / K800i / K790i**, select the folder corresponding to your mobile phone, such as "M600", "K610" or "K800 / K790", then select the video clip in your preferred language, such as "P!NK English - K800, K790" and select View > Play.
 - 2.2. For **W300i / Z530i / Z550i**, choose your preferred language such as "P!NK English - Others" and select View > Play. Playback starts.

