



Choose panhead or ballhead shooting modes. Extend your tripod height another 8".



Twist SwitchGrip downward, for those hard angles that only a copystand can reach.



Twist SwitchGrip outward, to mount SLR & digital cameras for instant viewing.





Use the mini ballhead tripod separately for full range of motion.



The Tiffen Company 90 Oser Avenue, Hauppauge, New York 11788 www.tiffen.com E-mail: techsupport@tiffen.com

SVIIICH GILD Handle with Detachable Mini Ballhead Tripod

