

Indoor/Outdoor Analog Wired Camera Model P-520

USER'S MANUAL



©2010 Lehigh Consumer Products, LLC All rights reserved. Distributed by Lehigh Consumer Products, LLC, Macungie, PA 18062. Due to continuing product development, the product inside the packaging may look slightly different than the one on the package. Lehigh Consumer Products, LLC is a subsidiary of Jarden Corporation (NYSE: JAH). To obtain warranty service, contact the Consumer Affairs Division at 1-800-323-9005, Monday through Friday, 7:30 a.m.- 5 p.m., Central Standard Time. Made in China

M08-0240-002

First Alert



Table of Contents

Safety	1
Safety Precautions	
Getting to Know Your P-520 Camera	2
Check Package ContentsFeatures	
Setting Up Your P-520 Camera	3
General Precautions	. 3
Installing the Camera	. 3
Connecting the Camera to a VCR/DVR and TV	. 4
Night Vision	. 4
Troubleshooting	4
Technical Information	5
Warranty	6
Product Limited Warranty	. 6
Warranty Exclusions	
Obtaining Service	. 7



Safety

S AFETY PRECAUTIONS

- Do not drop, puncture, or disassemble the camera.
- Never tug on the power adapter. Use the plug to remove it from the wall.
- Do not expose the camera to high temperatures.
- For your own safety, avoid using the camera when there is a storm or lightning.
- Use the device with care. Avoid pressing hard on the camera body.
- Do not crush or damage the power cable.

FCC COMPLIANCE

This device complies with Part 15 of the FCC Rules. Operation is subjected to the following two conditions: (1) this device may cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in residential installations. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur with a particular installation. If this equipment does cause interference to radio or television equipment reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment into an outlet on a circuit different from that to which the received is connected.
- Consult the dealer or an experience radio/TV technician for help.

Notice: Changes or modifications to the product could void the user's authority to operate the product.




Getting to Know Your P-520 Camera

Congratulations on purchasing your First Alert Security Camera product. First Alert has been helping families and businesses stay safe for over 50 years. By having a First Alert Security Camera, you're taking the first step in protecting your home or business from damage or theft. We're watching, even when you're not.

CHECK PACKAGE CONTENTS

After unpacking the carton, check the contents for damage. Contact your supplier or dealer immediately if any part is missing or damaged.

- Wired Indoor/Outdoor Camera (1)
- Camera Stand (1)
- Mounting Kit (1)
- 100 ft BNC Cable (1)
- Power Supply (1)
- User's Manual (1)



FEATURES

The P-520 security camera is a simple solution for surveillance at home or business use. Connect the camera directly to your security monitor or DVR for convenient monitoring or recording of clear quality pictures.

- 1/4" color CMOS camera
- 400 TV lines resolution
- Night vision with 12 infrared LEDs
- Indoor/outdoor weather resistant material
- Includes audio surveillance capability



Setting Up Your P-520 Camera

GENERAL PRECAUTIONS

- Use only the power supply provided with the system.
- Unplug the power supply when the system is not in use for extended periods.
- Do not place any of the equipment near a radiator, vent, or other place where it might be exposed to heat, moisture, dust, vibrations, or strong magnetic fields.
- Do not attempt to repair the camera. Contact a qualified technician or the dealer for service. Any change or modification may damage the equipment and invalidate the warranty.
- When installing the camera, follow manufacturer's advice when using power tools, steps, ladders, etc. and wear suitable protective equipment (e.g., safety goggles) when drilling holes. Before drilling holes through a ceiling, check for hidden electricity cables and water pipes.


INSTALLING THE CAMERA

1 Select the position for the camera and secure the camera stand.

Screws and anchors are supplied. Use an appropriate screw type for the mounting surface.

- 2 Screw the camera onto the stand. Tighten the lock nut to secure the camera on the stand.
- Adjust camera to the proper view angle. Make sure the lens is upright relative to your subject. Tighten the thumb screw.
- 4 Connect the camera to power using the supplied power cable and adapter.

The power adapter is not weather resistant and needs to be sheltered from moisture, rain, and sunlight.





CONNECTING THE CAMERA TO A VCR/DVR AND TV

- 1 Connect the 100 ft cable (supplied) to the camera.
- 2 Connect other end of the cable to the input on the VCR/DVR. (yellow connector = video in; white connector = audio in)
- 3 Connect an AV cable (not supplied) from the VCR/DVR to the TV.
- 4 Connect the power supply cable (supplied) to the camera (red plug). Plug the adapter into an electric outlet.

Make sure the power adapter is in a dry place.

- 5 Power on the VCR/DVR and TV.
- **6** Tune your TV to the correct INPUT (e.g., INPUT1) using your TV's remote control.

Follow your manufacturer's instructions to record to your VCR or DVR.

NIGHT VISION

The camera has built-in infrared LEDs to allow you to view up to a distance of 16 ft at night for 24-hour surveillance. The LEDs automatically activate at night and the picture viewed turns to a black and white image.

TROUBLES HOOTING

Problem	Solution			
	Make sure the camera and TV are plugged in.			
No picture.	Make sure the TV/ VCR/ DVR is tuned to the correct input channel.			
Flickering image.	Move the camera or move any source of bright light away from the camera.			
	Adjust the contrast and brightness on the TV.			
Image is too light or dark.	Move the camera or move any source of bright light away from the camera.			
A white image ennears at night	The camera's infrared LEDs shine invisible light that reflects off surfaces such as glass causing white light.			
A white image appears at night.	Place the camera on the other side of windows or place the lens flush against the surface to improve night vision.			





Technical Information

Image Device 1/4" CMOS

Video System NTSC

Resolution 400 TV lines

Effective Pixels NTSC: 656 (H) x 492 (V)

Video Output 1 Vp-p, 75 Ohm

Minimum Illumination 0 Lux (IR on)

Signal/Noise Ratio > 46 dB

IR LEDs 12

Night Vision Distance 16 ft

Viewing Angle 50 degrees

Color Yes

White Balance Automatic

Day/Night Mode Yes

Gain Control Automatic

Audio Yes

Power Supply DC 9V Indoor/Outdoor Both

Operating Temperature -4 – 113°F

Audio Surveillance Yes

Dimensions 4.5" x 2.0" x 3.5"



Warranty

PRODUCT LIMITED WARRANTY

BRK Brands, Inc., ("BRK") the maker of First Alert® brand products warrants that for a period of one year from the date of purchase (the "Warranty Period"), this product will be free from defects in material and workmanship. BRK, at its sole option, will repair or replace this product or any component of the product found to be defective during the Warranty Period. Replacement or repair will be made with a new or remanufactured product or component. If the product is no longer available, replacement may be made with a similar product of equal or greater value. This is your exclusive warranty.

This warranty is valid for the original retail purchaser only from the date of initial retail purchase and is not transferable. In order to obtain warranty service, you must keep the original sales receipt and proof of purchase in the form of the UPC code from the package. BRK dealers, service centers, or retail stores selling BRK products do not have the right to alter, modify or any way change the terms and conditions of this warranty.

WARRANTY EXCLUSIONS

Parts and Labor: 1 year limited (warranted parts do not include bulbs, LEDs, and batteries)

This warranty does not apply to bulbs, LEDs, and batteries supplied with or forming part of the product.

This warranty is invalidated if non-BRK accessories are or have been used in or in connection with the product or in any modification or repair is made to the product.

This warranty does not apply to defects or damages arising by use of the product in other than normal (including normal atmospheric, moisture and humidity) conditions or by installation or use of the product other than in strict accordance with the instructions contained in the product owner's manual.

This warranty does not apply to defects in or damages to the product caused by (i) negligent use of the product, (ii) misuse, abuse, neglect, alteration, repair or improper installation of the product, (iii) electrical short circuits or transients, (iv) usage not in accordance with product installation, (v) use of replacement parts not supplied by BRK, (vi) improper product maintenance, or (vii) accident, fire, flood or other Acts of God.

This warranty does not cover the performance or functionality of any computer software included in the package with the product. BRK makes no warranty that the software provided with the product will function without interruption or otherwise be free of anomalies, errors, or "Bugs." This warranty does not cover any costs relating to removal or replacement of any product or software installed on your computer.

BRK reserves the right to make changes in design or to make additions to or improvements in its products without incurring any obligations to modify any product which has already been manufactured. BRK will make every effort to provide updates and fixes to its

Model P-520 User's Manual

software via its website. This warranty does not cover any alteration or damage to any other software that may be or may become resident on the users system as a result of installing the software provided. This warranty is in lieu of other warranties, expressed or implied, and BRK neither assumes nor authorizes any person to assume for it any other obligation or liability in connection with the sale or service of the product. In no event shall BRK be liable for any special or consequential damages arising from the use of the product or arising from the malfunctioning or non-functioning of the product, or for any delay in the performance of this warranty due to any cause beyond its control.

BRK does not make any claims or warranties of any kind whatsoever regarding the product's potential, ability, or effectiveness to prevent, minimize, or in any way affect personal or property damage or injury. BRK is not responsible for any personal damage, loss, or theft related to the product or to its use for any harm, whether physical or mental related thereto. Any and all claims or statements, whether written or verbal, by salespeople, retailers, dealers, or distributors to the contrary are not authorized by BRK, and do not affect this provision of this warranty.

BRK's responsibility under this, or any other warranty, implied or expressed, is limited to repair, replacement or refund, as set forth above. These remedies are the sole and exclusive remedies for any breach of warranty. BRK is not responsible for direct, special, incidental, or consequential damages resulting from any breach of warranty or under any other legal theory including but not limited to, loss profits, downtime, goodwill, damage to or replacement of equipment and property and any costs of recovering, reprogramming or reproducing any program or data stored in or used with a system containing the product accompanying software.

BRK does not warrant the software will operate with any other software except that which is indicated. BRK cannot be responsible for characteristics of their party hardware or software which may effect the operation of the software included.

Except to the extent prohibited by applicable law, any implied warranty of merchantability or fitness for a particular purpose is limited in duration to the duration of the above Warranty Period. Some states, provinces, or jurisdictions do not allow the exclusion or limitation of incidental or consequential damages or limitations on how long an implied warranty lasts, so the above limitations or exclusion may not apply to you. This warranty gives you specific legal rights, and you may also have other rights that vary from state to state, or province to province, or jurisdiction to jurisdiction.

OBTAINING SERVICE

If service is required, do not return the product to your retailer. In order to obtain warranty service, contact the Consumer Affairs Division at 1-800-323-9005, 7:30 a.m. – 5:00 p.m. Central Standard Time, Monday through Friday. To assist us in serving you, please have the model number and date of purchase available when calling.

After contacting the Consumer Affairs Division and it is determined that the product should be returned for Warranty Service, please mail the product to: Lehigh, 2834 Schoeneck Rd, Macungie, PA 18062-9679.

