



FM Transmitter

Instructions:

1. Open the battery compartment located on the bottom of the unit.
2. Insert 3AAA 1.5V alkaline batteries (not included) following the diagram on the battery compartment cover.
3. Close the battery compartment.
4. Connect the 3.5mm audio input plug of the FM Transmitter to your portable DVD/CD, MP3 player or other portable device using the head phone jack.
5. Push the power ON/OFF switch on the FM Transmitter to the ON position.
6. Select one of the 4 FM settings on the FM Transmitter.
7. Turn on the power of the portable player and set the volume to a medium level. Note: The FM Transmitter does not provide power for your portable player. Therefore, batteries (not included) must be installed in your portable player.
8. Turn your radio to medium volume, then slowly tune your radio to the same station you selected on the FM Transmitter. Now you should be able to hear your music through your stereo.
9. Adjust the volume on your portable device to a level that produces distortion free stereo. At this time you can adjust the volume on your radio to the desired sound level.

NOTE: While driving your car and listening to the CD auto adapter, it is possible that interference from nearby station may cause your reception to fade out. If you hear this happening, select another frequency on the FM transmitter and tune your radio to the new frequency setting.

ONE YEAR LIMITED WARRANTY: Jasco Products Co., Inc. warrants this product to be free from manufacturing defects for a period of one year from the original date of consumer purchase. This warranty is limited to the repair or replacement of this product only and does not extend to consequential or incidental damage to other products that may be used with this unit. THIS WARRANTY IS IN LIEU OF ALL OTHER WARRANTIES EXPRESS OR IMPLIED. SOME STATES DO NOT ALLOW LIMITATIONS ON HOW LONG AN IMPLIED WARRANTY LASTS OR PERMIT THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES, SO THE ABOVE LIMITATIONS MAY NOT APPLY TO YOU. This warranty gives you specific rights, and you may also have other rights which vary from state to state. If unit should prove defective within the warranty period, return prepaid with dated proof of purchase to: Jasco Products Co., Inc., 311 N.W. 122nd, Oklahoma City, OK. 73114.

