


PYLE[®]


INSTRUCTION MANUAL

PLVHR70



Thank you for the purchase of this Super slim design 7 inch Color TFT-LCD monitor. Before operating the unit, please read this manual thoroughly and keep it for future reference.

PANEL



1. Power: Power on/off

Press this button to turn on the monitor, press again to turn the monitor off.

2. Brightness/color/contrast negative adjustment

To adjust brightness, color or contrast negatively.

3. SEL: to activate the menu and select brightness, color or contrast.

4. Brightness/color/contrast positive adjustment

To adjust brightness, color or contrast positively.

5. AV: to change video signal sources between V1/V2.

6. Remote control receiver

The device has the function of Picture-Flip, it allows you to rotate the screen 180 degrees and have the picture automatically flip so you can view the picture upside-down! So you can mount the monitor up side-down in a car.


NOTE: Although the effective pixels for the liquid crystal is given as 99.98% or more, 0.02% of pixels

may not light or may light incorrectly. It is a very common phenomenon in active matrix display

technology, do not indicate fault or broken of the unit.


Contents and specifications can be subject to change without prior notice.

REMOTE CONTROL





Power:	Power on/off
	Brightness adjustment
	Color adjustment
	Contrast adjustment
PP:	Select among the preset display mode (MEMORY-STANDARD-SOFT-VIVID-LIGHT)
V1/V2:	Change between V1 and V2.
SYS:	Image zoom


WIRING



INSTALLATION



1. STAND ALONE BRACKET



2. HEADREST BRACKET

