



ASSEMBLY INSTRUCTIONS

Save these instructions for future use.

This item is a toy for dolls only.

For children ages three (3) years and older.

MODEL #:09941

NAME: Double Umbrella Doll Stroller

TO OPEN THE STROLLER:


1. Unfold the stroller.
2. See Picture A. Locate the two frame locks (one on each side).
3. See Picture B. Slide the frame locks down and over the metal frame posts.
4. The fold the stroller, reverse this procedure.

CARE INSTRUCTIONS:

Metal parts can be wiped clean with a damp cloth. Fabric parts are poly/cotton. Spot clean canopy as needed. Seats and baskets can be removed for spot cleaning, hand washing, or machine washing (gentle cycle, cold water, non-chlorine bleach, air dry).



PICTURE A



PICTURE B



Visit us online at www.badgerbasket.com

Toll-Free Customer Service: 1-800-236-1310 (Mon-Thurs 7:30 AM to 4:30 PM CST)

Website: <http://www.badgerbasket.com/parts> • **E-mail:** parts@badgerbasket.com

PLANT AND GENERAL OFFICE: PO Box 227, Edgar, WI 54426-0227, Phone: 715-352-2311 Fax: 715-352-3163

CORPORATE OFFICE: 111 Lions Dr., Suite 220, Barrington, IL 60010