### KitchenAid FRONT PANEL PARTS

DRAWER DISHWASHER

For Models: KUDD03DTBL10, KUDD03DTWH10, KUDD03DTSS10 (Black) (White) (Stainless)

The model(s) number shown may be different than what is printed on the model/serial tag of your product. The number(s) shown combine the model number and the first two digits of the serial number from the product tag. 3 Literature Parts 6 12 5 10 9 11


Illus No.		DESCRIPTION	Illus No.		DESCRIPTION	Illus No.		DESCRIPTION
1		Literature Parts Instructions, Installation Energy Guide	5	9761573BL 9761573WH 9761573SS	White Stainless	7 8 9 10	W10117965 99003716 Y912620 99003156	Trim, Toe Kick Screw Screw
2	W10117977	Control Panel (Includes User Interface) Black	6	W10117955	Panel, Drawer (Lower) (Also Order Item 11) Black	11	8304603BL 8304603WH 8304603SS	
3	W10117988 W10117987 W10117966	Upper		W10118028 W10117956	White Stainless Steel (Upper) (Nameplate not	12	W10117969	Harness, User Interface
7	W 10117300	Panel		W10117952 W10118027 W10117953	Included) Black White			

# **TUB PARTS**

For Models: KUDD03DTBL10, KUDD03DTWH10, KUDD03DTSS10

(Black) (White) (Stainless)

The model(s) number shown may be different than what is printed on the model/serial tag of your product. The number(s) shown combine the model number and the first two digits of the serial number from the product tag.



#### **TUB PARTS**

For Models: KUDD03DTBL10, KUDD03DTWH10, KUDD03DTSS10 (Black) (White) (Stainless)

The model(s) number shown may be different than what is printed on the model/serial tag of your product. The number(s) shown combine the model number and the first two digits of the serial number from the product tag.


Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	99003763	Line Break Assembly	11	99003782	Plate, MCM Enclosure	24	99003701	Bracket, Thermostat
2	99003698	Dispenser	12	99003740		25	99003624	Fuse, Thermal
3	99003605	Bezel, Inlet/Outlet	13 14		Drawer, Tub Shield, Drip	26	99003623	Thermostat, High Limit
4	99003760	Slide Right Hand	15 16		Cover, Bottom	27	99001979	O–Ring, Pump Thermostat
	99003759	Left Hand			Suction	28	99003699	
5	W10155595	Fan Motor and Housing Assembly	17 18	W10190553 99003632	Drain Pump Assy. Clamp	29	99003705	Wire Jumper, Thermostat
6	99003696	•	19 20	99003730 W10120019		30	99003708	Wire Jumper, Heater
7	99003626	Switch, Pressure	21	99002651		31	W10118491	Bracket, Drain
8	99003781				Sensor			Pump
9	99003694		22	99003773	Solenoid, Fine Drain	32	W10190274	Catch, Drawer Release
10	99003733	Control Module	23	99003727	H Bracket	33 34	99003758 W10121259	Barrier, MCM Shield, Motor

3

W10190380

## **WASH SYSTEM PARTS**

For Models: KUDD03DTBL10, KUDD03DTWH10, KUDD03DTSS10 (Black) (White) (Stainless)



#### **WASH SYSTEM PARTS**

For Models: KUDD03DTBL10, KUDD03DTWH10, KUDD03DTSS10 (Black) (White) (Stainless)

The model(s) number shown may be different than what is printed on the model/serial tag of your product. The number(s) shown combine the model number and the first two digits of the serial number from the product tag.


Illus. No.	. Part No.	DESCRIPTION
140.	NO.	DESCRIPTION
1 2 3	99003689 99003697 W10190556	Wash Arm Assembly Cap, Wash Arm Filter Flowplate
4	Y6918536	Assembly Screw
5	99003720	Compression Ring, Fine Drain
6 7	99003692 99003772	Seal, Fine Drain Armature, Fine Drain
8 9	99003774 99003775	Spring, Fine Drain Shaft, Fine Drain
10 11 12	99003625 Y6920320 99003777	Heater O-Ring (EPDM) Coarse Cup, Lower
13 14	99003776 99003778	Coarse Cup, Lower Coarse Cup, Upper Coarse Cup Cap
15	Y6920170	Inlet, Upper (Manifold)
16 17	99003602 Y6920354	Seal, Inlet/Outlet Bracket, Upper Manifold Mtg
18	Y6920171	Cap, Manifold
19	99003602	Seal, Inlet/Outlet
20	99003683	Manifold, Upper Assembly
21 22	99003771 99003704	Nut, Heater Shield, Fine Filter
23 24	99003634 99003697	Clamp, Manifold Pivot, Wash Arm

5 W10190380

### **UPPER AND LOWER DISHRACK PARTS**

For Models: KUDD03DTBL10, KUDD03DTWH10, KUDD03DTSS10 (Black) (White) (Stainless)

The model(s) number shown may be different than what is printed on the model/serial tag of your product. The number(s) shown combine the model number and the first two digits of the serial number from the product tag.




No. No.		No.	DESCRIPTION
	1	W10118023	Rack, Base
	2	W10170023	Clip, No-Flip
	3	W10154735	Rack, Insert
	4	W40440040	(Includes Item 2)
	4	W10118019	Rack, Insert (Small Tines)
	5	W10118031	Basket, Silverware
			Assembly
	6	W10118032	Cover, Silverware
	7	W10118001	Basket Shelf, Rack
	8	W10118010	Rack, Left
	9	8519716	Basket, Small
			Items

#### FRAME AND LID PARTS

For Models: KUDD03DTBL10, KUDD03DTWH10, KUDD03DTSS10 (Black) (White) (Stainless)

The model(s) number shown may be different than what is printed on the model/serial tag of your product. The number(s) shown combine the model number and the first two digits of the serial number from the product tag.




7

W10190380

## **ACCESSORY PARTS**

For Models: KUDD03DTBL10, KUDD03DTWH10, KUDD03DTSS10 (Black) (White) (Stainless)

The model(s) number shown may be different than what is printed on the model/serial tag of your product. The number(s) shown combine the model number and the first two digits of the serial number from the product tag.



Illus. Part No. No.		DESCRIPTION		
1	99003670	Trim, Side		
2	99003716	Trim, Toe Kick		
3		(BlacK) Toe Kick Base (LH)		
	Y6920293			
	Y6920297	White		
4	\(\)	Toe Kick Base (RH)		
	Y6920295			
_	Y6920299	********		
5		Toe Kick		
	V6020204	Slide (LH) Black		
	Y6920294			
6	Y6920298			
О		Toe Kick		
	Y6920296	Slide (RH) Black		
	Y6920300			
7	Y6920591			
,	10020091	Diacket, Woulding		