# American Standard Williamsburg™

Centerset Lavatory Faucet with Speed Connect<sup>™</sup> Drain

Congratulations on purchasing your American Standard faucet with Speed Connect drain, a feature found only on American Standard faucets.

## Speed Connect<sup>™</sup> Drain\*

- Fewer parts, installs in less time
- Never needs adjustment
- Guaranteed to seal properly the first time, every time.

Certified to comply with ANSI A112.18.1 M968422Rev.1.2

\*Your new American Standard faucet is designed to work only with the Speed Connect drain. Heplful tips for removing your current drain can be found in the Troubleshooting section of these instructions.

## To ensure that your installation proceeds smoothly-please read these instructions carefully before you begin.

Installation Instructions

2804



#### **INSTALL POP-UP DRAIN**

Remove CLEAR PLASTIC COVER (1). Remove CARDBOARD SPACER (2) from under DRAIN POP-UP (3). Fig. A. Fig. A.

2

3

Drop DRAIN BODY (4) through sink drain hole. Make sure WHITE FOAM GASKET (5) is under flange of DRAIN BODY (4). Fig. B.

**Note:** No plumber's putty or caulk is required.

■ The CABLE ATTACHMENT POINT (6) must face towards the rear of the SINK. Fig. B.

### INSTALL BLACK GASKET

Install BLACK CONE GASKET (1) onto DRAIN BODY (2) from below.

**Note:** The flat side of the BLACK CONE GASKET **(1)** must face down.



REAR OF

SINK

DRAIN

6

Fig. B.

5

#### INSTALL GRAY LOCKNUT

Install GRAY LOCKNUT (1) onto DRAIN BODY (2) from below SINK. Fig. A.

**Note:** The flat side of the GRAY LOCKNUT **(1)** must face up.

Tighten firmly by hand. No tools are required. Check DRAIN FLANGE in SINK to ensure that WHITE FOAM GASKET (3) is fully compressed and not visible. Fig. B.



## 5

Δ

#### POP-UP KNOB

POP-UP KNOB (1) must be fully down.





#### TEST INSTALLED FITTING

- With HANDLES (1) in OFF position, turn on WATER
   SUPPLIES (2) and check all connections for leaks.
- Remove AERATOR (3).
- Operate both HANDLES (1) to flush water lines thoroughly.
- Replace AERATOR (3).

#### **CHECK DRAIN CONNECTIONS**

- Operate POP-UP KNOB (4) and fill lavatory with water. Check that DRAIN STOPPER (5) makes a good seal and retains water in SINK. If DRAIN STOPPER (5) does not seal properly, please refer to Troubleshooting section in these instructions.
- Release POP-UP KNOB (4) down and check all drain connections and "P" trap for leaks. Tighten p if necessary.



## INSTALLATION OF OPTIONAL METAL LEVER HANDLES (Supplied with Faucet)

- Thread PORCELIAN LEVER HANDLE (2) counter-clockwise and remove INDEX BUTTON with MOUNTING ROD ASSEMBLY (1), HANDLE COLLAR (4) and O-RING (5).
- Insert MOUNTING ROD ASSEMBLY (1) into METAL HANDLE (3), HANDLE COLLAR (4) and O-RING (5).

STOP

WASHER

Thread HANDLE ASSEMBLY (6) into ball of HANDLE BASE (7). Apply pressure to the MOUNTING ROD ASSEMBLY (1) while turning the HANDLE COLLAR (4), in order to tighten firmly.

## SERVICE

12

10

- To change direction of handle rotation, proceed as follows:
- Turn valve to OFF position.
   Pull out INDEX CAP and remove
- HANDLE SCREW.
- Remove SPRING CLIP.
- Lift STOP WASHER, turn 90° and replace.
  Replace SPRING CLIP.
- Replace SPRING CLIP.
   Replace ADAPTER, HANDLE, SCREW, and INDEX CAP.
- AERATOR may accumulate dirt causing distorted and reduced water flow. Remove AERATOR and rinse clean.
- If spout drips, operate handles several times from OFF to ON position. Do not force - handles turn only 90°.

#### ALIGN HANDLES

- Pull out INDEX CAP (1) and remove HANDLE SCREW (2), HANDLE (3) and ADAPTER (4).
- Push ADAPTER (4) on VALVE STEM (5). Find correct position of HANDLE (3) by adjusting male teeth on ADAPTER (4) to female teeth on HANDLE (3).

6



Replace HANDLE SCREW (2) and push in INDEX CAP (1).

#### CARE INSTRUCTIONS:

DO: SIMPLY RINSE THE PRODUCT CLEAN WITH CLEAR WATER. DRY WITH A SOFT COTTON FLANNEL CLOTH.

SPRING

CLIP

DO NOT: DO NOT CLEAN THE PRODUCT WITH SOAPS, ACID, POLISH, ABRASIVES, HARSH CLEANERS, OR A CLOTH WITH A COARSE SURFACE.