

16 LED SPOTLIGHT WITH HAND CRANK

Model 96141

ASSEMBLY AND OPERATION INSTRUCTIONS



Due to continuing improvements, actual product may differ slightly from the product described herein.



3491 Mission Oaks Blvd., Camarillo, CA 93011

Visit our website at: <http://www.harborfreight.com>

**TO PREVENT SERIOUS INJURY, READ AND UNDERSTAND
ALL WARNINGS AND INSTRUCTIONS BEFORE USE.**

Copyright© 2007 by Harbor Freight Tools®. All rights reserved. No portion of this manual or any artwork contained herein may be reproduced in any shape or form without the express written consent of Harbor Freight Tools.

For technical questions or replacement parts, please call 1-800-444-3353.

SPECIFICATIONS

Light Source	16, 12000 MCD LED's
Construction	Body: Silver Polypropylene plastic, Lens Bumper: black rubber, Rear Bumper: black rubber, Handle: black polypropylene plastic with black rubber grip, Trigger: black plastic
AC/DC Adapter Input	120 V~, 60 Hz, 7 W
AC/DC Adapter Output	9 VDC, 300 mA
Rechargeable Battery	3FM 2.8, constant voltage charge, cycle use: 7.2-7.5V, standby use: 6.75-6.9V
LED Indicators	Green (charged) Red (charging)
Charging Time	12 Hours
Approximate Run Time (fully charged)	High Intensity Mode-12 hours; Low Intensity Mode-28 hours
Overall Dimensions	8-5/8" L x 3-5/16" W x 9" H
Wire Length	69"
Weight	2.5 lb.
Special Features	Low voltage and overcharging protection, auto shut off when battery is fully charged Cigarette Plug Adapter

Save This Manual

You will need this manual for the safety warnings and precautions, operating, inspection, maintenance and cleaning procedures. Keep your invoice with this manual. Write the invoice number on the inside of the front cover. Write the product's serial number in the back of the manual near the assembly diagram, or write month and year of purchase if product has no number. Keep this manual and invoice in a safe and dry place for future reference.

GENERAL SAFETY RULES



READ AND UNDERSTAND ALL INSTRUCTIONS
Failure to follow all instructions listed below may result in
serious injury.
SAVE THESE INSTRUCTIONS

1. **Keep your work area clean and well lit.** Cluttered benches and dark areas invite accidents.

2. **Keep bystanders, children, and visitors away while using this product.** Distractions can cause you to lose control.
3. **Stay alert. Watch what you are doing, and use common sense when operating the Spotlight. Do not use this product while tired or under the influence of drugs, alcohol, or medication.** A moment of inattention while operating this product may result in serious personal injury.
4. **Do not force the product. Use the correct product for your application.** The correct product will do the job better and safer at the rate for which it is designed. Do not force the product and do not use the product for a purpose for which it is not intended.
5. **Store idle products out of reach of children and other untrained persons.** This product is dangerous in the hands of untrained users. Never point the light beam directly at people or animals.
6. **Maintain this product with care.** Do not use a damaged product. Tag damaged products "Do not use" until repaired.
7. **Check for misalignment or binding of moving parts, breakage of parts, and any other condition that may affect the product's operation. If damaged, have the product serviced before using.** Many accidents are caused by poorly maintained products.
8. **Maintain labels and nameplates on the product.** These carry important information. If unreadable or missing, contact Harbor Freight Tools for a replacement.
9. **Maintain a safe working environment.** Make sure there is adequate surrounding workspace. Do not use this product in a damp or wet location.

UNPACKING


When unpacking, check to make sure that the item is intact and undamaged. If any parts are missing or broken, please call Harbor Freight Tools at the number shown on the cover of this manual as soon as possible.

OPERATION

1. The Spotlight can be charged in three different ways by cranking the Handle, using the 120 V~ Adapter, or using the Cigarette Plug Adapter.
2. The Green LED will indicate when the battery is fully charged. A red LED will indicate that the battery is charging.

Charging with the Cranking Handle

Figure 1



1. Pull out the Handle as shown in Figure 1.
2. Grasp the Handle and crank it continuously clockwise. The red LED will stay on while the Spotlight is charging. For every 3 minutes of turning the handle you will get one minute of light. The Green LED will come on when the Spotlight is fully charged.
3. When finished, fold the Handle back into its slot when done cranking.

Using the Cigarette Plug Adapter

1. Insert the plug end into the charge receptacle on the Spotlight.
2. Plug the Cigarette Plug Adapter into the vehicle's cigarette lighter socket.
3. Allow the Spotlight to charge until the green LED comes on.
4. To prevent the vehicle's battery from running down, charge the spotlight only when the vehicle's engine is running.
5. The Green LED will come on when the Spotlight is fully charged.

Using the 120 V AC/DC Adapter

1. Insert the plug end into the charge receptacle on the Spotlight.
2. Plug the 120V AC/DC Adapter into a 120V receptacle.
3. Allow the Spotlight to charge until the green LED comes on.
4. Remove the 120V AC/DC Adapter electrical plug from the outlet, and disconnect from the Spotlight.

Running the Spotlight

1. The Spotlight will run for approximately 28 hours on a fully charged battery while in LOW mode, and approximately 12 hours on a fully charged battery while in HIGH mode.
2. The LOW setting will run 6 LED's while the HIGH setting will use all 16 LEDs.
3. Select HIGH or LOW modes to run the Spotlight by moving the switch.
4. Squeeze the Trigger to turn ON the Spotlight.



Figure 2

5. Slide the Trigger Lock Switch down (see Figure 2) to lock the Trigger ON. To release the Trigger from locked position, lightly touch the Trigger.
6. Remove finger away from the Trigger to turn the Spotlight OFF.

INSPECTION, MAINTENANCE, AND CLEANING

1. **⚠ WARNING!** Make sure the Trigger is in its “OFF” position before performing any inspection, maintenance, or cleaning procedures.
2. **BEFORE EACH USE**, inspect the general condition of the Spotlight. Check for cracked or broken parts and any other condition that may affect its safe operation. If abnormal noise or vibration occurs, have the problem corrected before further use. **Do not use damaged equipment.**

3. **Protect the Spotlight from rough use.** It is susceptible to damage from being dropped, struck or other abuse.
4. **Protect the Spotlight from exposure to water or corrosive materials.** It should be kept clean and dry. Occasional cleaning with a clean rag will extend its life and good appearance.
5. **Lock it up and store in a dry location to inhibit rust.** Keep out of the reach of children.
6. **Before discarding this product, remove the battery and dispose of it properly in accordance with local, state and federal regulations and ordinances.** To access the battery, remove the six small phillip's-head screws that secure the back and the front part of the housing. Then remove 4 screws holding the two halves of the housing together. Be careful with the battery, it may leak acid. Wash off any spilled acid immediately with cool water.

Note: The LED lights have a long lifetime and do not need replacement. The Spotlight has no replacement parts.