

American DJ®

# USER **Instructions**

## Warp!™

### **HALOGEN LAMP WARNING!**

This fixture is fitted with halogen lamps which are highly susceptible to damage if improperly handled. Never touch lamp with bare fingers as the oil from your hands will shorten lamp life. Also, never move fixture until lamp has had ample time to cool. Remember, lamps are not covered under warranty conditions.

**Caution!** Always disconnect from main power before replacing lamps or servicing unit. Remember to always replace with same lamps and fuses.

**Model: Warp!™**

### **SPECIFICATIONS:**

Lamp: ZB-ELC 24V 250W

Power: 110V/60Hz

Fuse: 5A

Optics: High Quality Glass Lenses

Ventilation: Fan Cooled

Working Position: Any

Weight: 21 lbs.

Size: 11" x 12.25" x 5.75"

Duty Cycle: 10 min. on 10 min. off



**Thank you for purchasing this American DJ® product. For your convenience this lighting effect has been lamped and is ready to be used, there is no assembly required. Please read the following instructions before installing or using your new unit.**

### **Operating Instructions:**

Unit is ready to be hung or set on the ground. After plugging in unit, the lights will react to the music via the sound active internal microphone. Adjust the sound activation knob on the back of the unit for desired music sensitivity.

A Super moonflower effect, The Warp! is sound active with multi-colored dichroic colors and 7 hot gobo patterns. Fan cooled. Hanging bracket for easy installation. A great effect for mobile DJ's, roller rinks, and night clubs.

**To replace lamp;** unscrew knob on lamp replacement hatch on the top casing of the fixture. Replace bulbs; reassemble.

For service, contact your *American DJ™* dealer.