American DJ

User Instructions

ROLLING STAR



SPECIFICATIONS: Rolling Star

Weight: 12 lbs.

Size: 11" x 21.5" x 21.5"L Lamp: 3x ZB-64514 120v/300w

Fuse: 10A

Colors: Multi-Colors

Lenses: 45 Voltage: 110V

HALOGEN LAMP WARNING!

This fixture is fitted with a halogen lamp which is highly susceptible to damage if improperly handled. Never touch lamp with bare fingers, oil from your hands will shorten lamp life. Also, never move fixture until lamp has had ample time to cool. Remember, lamps are not covered under warranty conditions. Allow 5 minutes for lamp to ignite to full brightness.

CAUTION! Read instructions before installing or plugging unit in.

Description: Congratulations and Thank you for purchasing the Rolling Star. The Rolling Star is a medium sized centerpiece with a merry-go-round type effect. It features three multi-colored balls that rotate 360 degrees, dispersing bright colored beams in all directions. The Rolling Star utilizes three 300W lamps, a carrying handle, and a heavy duty base for reliability. This unit comes with a limited one year (365 days) warranty.

Operating Instructions: The Rolling Star has been tested and lamped at the factory. No assembly is required. The fixture may be mounted upside down or placed on a flat surface. After placing your fixture in a secure position, plug your unit into a standard 110V Edison outlet. This unit is not sound activated and should begin to tumble and turn immediately.

Caution! Never open unit while in use, lamp will get very hot and may cause serious injury. Always disconnect main power before servicing or replacing lamp. Always replace with same lamp and/or fuse as original unless specified by a technician.

Lamp Replacement: Disconnect power. Remove three thumb screws that fasten the outer half of the sphere to the inner half. Remove the outer half of the sphere to expose the lamp. Remove the old lamp and replace with a new one. Be sure not to touch the new lamp with bare hands (use a clean dry cloth). Insert lamp into socket and reassemble.

Always replace with the exact same type lamp and fuse, unless otherwise instructed to do so by an authorized American DJ technician.

Customer Support: American DJ® provides a toll free customer support line, to provide set up help and to answer any question should you encounter problems during your set up or initial operation. You may also visit us on the web at www.americandj.com for any comments or suggestions. For service related issue please contact American DJ®. Service Hours are Monday through Friday 9:00 a.m. to 5:00 p.m. Pacific Standard Time.

Voice: (800) 322-6337 Fax: (323) 582-2610

E-Mail: support@americandj.com