



TV TALKERS



EXCALIBUR
ELECTRONICS
Model No.: 344

Congratulations on your purchase of Family Guy TV Talkers from 20th Century Fox and Excalibur Electronics, Inc! You'll get a load of laughs each time you press the remote control.

Before you begin, please read this manual thoroughly. Be sure to read the sections on handling and battery information carefully. This will help ensure that your Family Guy TV Talkers will perform properly for a long time to come. Keep this manual for reference.

*FAMILY GUY TM & © 2006 Twentieth Century Fox Film Corporation.
All Rights Reserved.*



The legendary King Arthur brandished a magic sword, Excalibur, from which we take our company name. With this unique weapon in his hands, he could not be vanquished. Although Excalibur Electronics can't claim the magical secrets of Merlin, King Arthur's court wizard, sometimes our patented technology may make it seem as if we could. We make you think!

TABLE OF CONTENTS



BATTERY INSTALLATION	3
BATTERY COMPARTMENT & LAYOUT	3
HOW TO USE FAMILY GUY TV TALKERS	4
BATTERY INFORMATION	4
SPECIAL CARE & HANDLING	4
90-DAY LIMITED WARRANTY	5
SHIPPING YOUR UNIT	6
EXPIRED WARRANTY	6

BATTERY INSTALLATION

Your Family Guy TV Talkers requires 3-AAA batteries, not included. Follow these steps for installation.


1. Turn the game over so the top side is face-down on a soft surface.
You will see the battery compartment in the middle.
2. Use a Phillips screwdriver to remove the screw.
3. Push back the battery compartment tab using your thumb.
4. Lift off the battery compartment lid.
5. Install each battery carefully matching the polarity (+ and -) with the diagram inside the battery compartment.
6. Place the battery tabs into their slots, and snap the compartment door into place.
7. Screw the lid shut.
8. Move the **ON/OFF** switch to the **ON** position to activate the unit.

BATTERY COMPARTMENT AND LAYOUT



HOW TO USE YOUR FAMILY GUY TV TALKERS

You will hear any one of more than 30 quotes from Brian and Stewie each time the Family Guy sensor receives a signal from your remote control.



1. Insert 3-AAA batteries.
2. Place the **ON/OFF** switch in the **ON** position.
3. Aim your TV remote control at the TV Talkers and press any button. .
You will hear a quote from the TV show.

BATTERY INFORMATION

- Your Family Guy TV Talkers uses 3-AAA batteries.
- Insert batteries with the correct polarity.
- Only batteries of the same or equivalent type should be used.
- Do not mix new and used batteries.
- Remove exhausted batteries from the unit to avoid leakage.
- Do not short-circuit the supply terminals.

SPECIAL CARE AND HANDLING

- Avoid rough handling such as bumping or dropping.
- Avoid moisture and extreme temperatures. For best results, use between the temperatures of 39^o F and 100^o F (4^o C and 38^o C).
- Clean using only a slightly damp cloth. Do not use cleaners with chemical agents.

90-DAY LIMITED WARRANTY

EXCALIBUR ELECTRONICS, INC., warrants to the original customer that its products are free from any electrical or mechanical defects for a period of 90 DAYS from the date of purchase. If any such defect is discovered within the warranty period, EXCALIBUR ELECTRONICS, INC., will repair or replace the unit free of charge upon receipt of the unit, shipped postage prepaid and insured to the factory address shown in this booklet.

The warranty covers normal consumer use and does not cover damage that occurs in shipment or failure that results from alterations, accident, misuse, abuse, neglect, wear and tear, inadequate maintenance, commercial use, or unreasonable use of the unit. Removal of the top panel voids all warranties. This warranty does not cover cost of repairs made or attempted outside of the factory.

Any applicable implied warranties, including warranties of merchantability and fitness, are hereby limited to 90 DAYS from the date of purchase. Consequential or incidental damages resulting from a breach of any applicable express or implied warranties are hereby excluded. Some states do not allow limitation on the duration of implied warranties and do not allow exclusion of incidental or consequential damages, so the above limitation and exclusions in these instances may not apply. The only authorized service center in the United States is:

Excalibur Electronics, Inc.

13755 SW 119th Ave

Miami, Florida 33186 USA

305.477.8080

305.477.9516 Fax

www.ExcaliburElectronics.com

SHIPPING YOUR UNIT TO EXCALIBUR ELECTRONICS, INC.

- Ship the unit carefully packed, preferably in the original carton, and send it prepaid and adequately insured.
- Include a detailed letter with the following:
 - o the specific complaint
 - o your daytime telephone number
 - o your address

EXPIRED WARRANTY

If your warranty has expired and you want an estimated fee for service, write to the above address, specifying the model and the problem.

NOTE: Please do not send your unit without first receiving an estimate for servicing from EXCALIBUR ELECTRONICS, INC. Contact us before sending your unit. We cannot store your unit!

Excalibur Electronics, Inc. reserves the right to make technical changes without notice in the interest of progress.

EXCALIBUR

ELECTRONICS, INC.

13755 SW 119th Ave
Miami, Florida 33186 USA

305.477.8080
305.477.9516 Fax

*Play games live at:
www.ExcaliburElectronics.com*

344 (MA) Family Guy's TV Talker 090506 V4