



KDLI20 Desk Lamp

PLEASE READ AND FOLLOW THE INSTRUCTIONS PRIOR TO USING YOUR DESK LAMP.

Arrange cord away from traffic areas and where it will not be tripped over.

Ensure the “On/Off” switch is in the “Off” position prior to plugging the lamp into the 230-240 Volt mains supply.

The desk lamp is not intended for outdoor, wet or moist location. Do not immerse or allow water to be spilt on the desk lamp.

Avoid touching lamp shade while it is on, some parts of the lamp may become hot. When moving the lamp, switch off, allow to cool down and hold the lamp by the body when carrying.

Keep combustible materials such as drapes and other furnishings well clear of the lampshade, as the lampshade may become hot if the lamp is left operating for a period of time.

Extreme caution and supervision is necessary when this lamp is used by or near children, invalids or animals.

Young children should be supervised to ensure they do not play with the lamp.

When not in use, pack the desk lamp in its original box for best protection and store in a cool, clean and dry location

Always turn off and then unplug the desk lamp before cleaning

Do not attempt to open or work on the desk lamp at anytime, there are no customer serviceable parts inside. Please return the desk lamp to Kambrook or an authorised service agent for service or repairs.

Use this desk lamp only as described in this instruction manual. Any other use not recommended by the manufacture may cause fire, electric shock or injury and voids all warranties.

Do not use the desk lamp on heat sensitive surfaces as there may be a build up of heat when left in the same position over a period of time. Please choose the desired surface carefully.

Specifications:

Electrical Rating

Input – 230-240 Volt AC, 50Hz

Output – 12 Volt, 20 Watt



Warranty Update
Effective as of August 2001

Kambrook 12 Month Warranty

KAMBROOK warrants the purchaser against defects in workmanship and material, for a period of 12 months from the date of purchase (3 months commercial use).

Guarantee and purchase receipt for this product are to be retained as proof of purchase and must be presented if making a claim under the terms of the KAMBROOK guarantee.

KAMBROOK reserves the right to replace or repair the appliance within the warranty period.

Warranty does not apply to any defect, deterioration, loss, injury or damage occasioned by, or as a result of the misuse or abuse, negligent handling or if the product has not been used in accordance with the instructions. The guarantee excludes breakages and consumable items such as light globes.

This warranty is void if there is evidence of the product being tampered with by unauthorised persons.

If the product includes one or a number of accessories only the defective accessory or product will be replaced.

In Australia, this KAMBROOK Guarantee is additional to the conditions and guarantees which are mandatory as implied by the Trade Practices Act 1974 and State and Territory legislation.

For service, spare parts or product information in Australia, please call KAMBROOK on the Customer Service Line (free call) 1800 800 634.

For service, spare parts or product information in New Zealand, please call KAMBROOK New Zealand, Mono Place, Ellerslie, Auckland Phone (09) 525 3466 Fax (09) 525 3464. For spare parts phone (09) 274 9950

If claiming under this guarantee the product must be returned freight prepaid.

YOUR PURCHASE RECORD (Please complete)

Attach a copy of purchase receipt here.

DATE OF PURCHASE _____

MODEL NUMBER _____

SERIAL NUMBER (If applicable) _____

PURCHASED FROM _____

Please don't return purchase record unless you are making a claim