

USER'S MANUAL

Thank you for choosing our waistband amplifier which will bring you inconceivable, endless of comfort and convenience in your future work and life.

This waistband amplifier is perfect to be used in indoor and outdoor activities such as small meetings, parties, teaching, karaoke, sales propagandas and auctions etc.

OPERATION:

1. Open the battery cover of the amplifier and install 6 pcs 1.5V AA batteries or 1.2V AA rechargeable batteries with the same specification. And then close the battery cover.
2. Put the amplifier on waist. Adjust the attached belt to advisable length. Then clip and fasten it on the back side.
3. Insert 3.5mm plug of the microphone into 3.5mm MIC in jack on the amplifier.
4. Wear headset MIC around your head. Keep MIC head close to your mouth.
5. Turn ON/OFF switch clockwise to adjust the volume to suitable level. Now you are ready to use the instrument.

NOTE:

1. AC/DC adapter is optional for choice. AC/DC adapter can be used to charge rechargeable batteries and power the amplifier simultaneously.
2. Do not use AC/DC adapter when using non-rechargeable batteries.

SPECIFICATION:

1. Maximum power: 5W (with 4 Ohm load)
2. Distortion: 5% max @ 2W output
3. Frequency response: 100Hz-10KHz+/-3dB
4. Power supply: DC 9V