



NetFly U-108

Wireless 108Mbps USB Adapter

A02-UP-W108



Quick Start Guide

A02-UP-W108_GE01



Wireless 108Mbps USB Adapter

ENGLISH

This product is covered by Atlantis Land 3 years **Fast-Swap** warranty. For more detailed informations please refer to the web site www.atlantis-land.com.

For more detailed instructions on configuring and using the Switch , please refer to the online manual.

ITALIANO

Questo prodotto è coperto da garanzia Atlantis Land **Fast-Swap** della durata di 3 anni. Per maggiori dettagli in merito o per accedere alla documentazione completa in Italiano fare riferimento al CD Rom o al sito www.atlantis-land.com.

FRANCAIS

Ce produit est couvert par une garantie Atlantis Land **Fast-Swap** de 3 ans. Pour des informations plus détaillées, référez-vous svp au site Web www.atlantis-land.com.

Le manuel complet en Francais est disponible dans le CD Rom ou sur le WEB.

DEUTSCH

Dieses Produkt ist durch die Atlantis Land 3 Jahre **Fast-Swap** Garantie gedeckt. Für weitere Informationen, beziehen Sie sich bitte auf Web Site www.atlantis-land.com.

ESPAÑOL

Este producto está cubierto de garantía Atlantis Land **Fast-Swap** por 3 años. Para una información más detallada, se refiera por favor al Web site www.atlantis-land.com.



Wireless 108Mbps USB Adapter



Register your product!

www.atlantis-land.com

Registration on the web site **www.atlantis-land.com** within 15 days from the purchase of the product dismiss the customer from showing a valid proof of purchase (Sale Receipt or Invoice) in case of the request of intervention. For further information we invite you to look at our web site at the section WARRANTY.



Wireless 108Mbps USB Adapter

Thank you for purchasing the IEEE 802.11g Wireless 108Mbps USB Adapter that provides the easiest way to wireless networking. **For more detailed instructions on configuring and using the Wireless 108Mbps USB Adapter, please refer to the online manual.**

1.1 System Requirements

Before installing the Adapter, your PC should meet the following:

- Desktop PC with available USB V2.0 or V1.1*
- Intel® Pentium®III 600Mhz or compatible processor with 128MB RAM
- Windows 2000/XP operating system
- Minimum 15 Mbytes free disk space for installing the driver and utilities
- CDRom drive

*When plug the device in the USB 1.1/1.0 port, the real throughput will be up to 6Mbps only when running 11Mbps or higher speed

1.2 Package Contents

Unpack the package and check all the items carefully. If any item contained is damaged or missing, please contact your local dealer as soon as possible. Also, keep the box and packing materials in case you need to ship the unit in the future. The package should contain the following items:

- One IEEE802.11g Wireless 108Mbps USB Adapter.
- One A-type USB male to female extension cable
- One Quick Start Guide
- One CD with driver/utilities and user's manual



1.3. Utility Installation


This section describes the procedures of installing the driver and utility. **Before insert USB Dongle into the PC USB of your computer, please install the Utility Program first.**

Make sure that the 108Mbps Wireless Network USB Dongle is NOT inserted into the USB slot.

Go to your Windows **Start** menu and choose **Run**, type **“CDRom:\Setup.exe”** in the dialog box and click **OK**.

Follow the instruction step by step to finish the installation.

The USB extension cable that comes with the Adapter has Type A connectors on both ends. One is a male Type A connector that plugs into the PC's USB port, and the other is a female Type A connector that plugs into the Adapter. This USB extension cable have a special function, it can be twist to any direction to have the best connection in the air. It is recommended that the Pen Size Wireless USB Adapter was vertically plane with the ground.



After restarting the computer, insert the USB dongle into USB port. Few seconds later, there will be a window popup.

1.3.1 Installing on Windows XP

- After the opening banner, Windows will tell you that the new device has been detected. Click **“Next >”**.
- Select **“Install the software automatically (recommended)”** then click **“Next>”**. In next window, click **“Continue Anyway”** then click **“Finish”**.



Wireless 108Mbps USB Adapter

- After installing the driver of USB, there will be another pop-up window to guide you to keep installing the driver of USB Dongle.
- Click “**Next >**”. Select “**Install the software automatically (recommended)**” then click “**Next>**”. In next window, click “**Continue Anyway**” then click “**Finish**”.
- To make sure if the installation is successful, you could check it through the device management.

1.4 Utility

Once the installation is successful, a utility program icon will show on your desktop (108Mbps Wireless Network USB Dongle Configuration Utility). To launch the utility, just double click the icon.

In the Configuration Utility, select “**Site Survey**” tab, and click “**Refresh**” button to search the available wireless network(s). Select the network you want.

1. If you have not enabled wireless encryption on your network, then just click “**Connect**” button to activate wireless connection immediately.
2. If the wireless encryption is enabled click “**Connect**” button then choose encryption and put correct password on the next page, then click on **Apply**.
3. If doesn't show any available wireless network, click “**Add**” button to setup encryption and SSID.



Atlantis Land S.p.A.
Viale De Gasperi, 122
Mazzo di Rho – MI – Italy
info@atlantis-land.com
sales@atlantis-land.com
www.atlantis-land.com