Q: Can I use this unit without the cord?

A: Yes. The **Emjoi® Divine** can be used without the adapter cord once

Q : Do I have to clean the Emjoi® Divine?

A: Yes. We recommend that you clean your unit after each use. Before cleaning make sure to turn off your unit and if it is plugged in, unplug it from the electrical outlet. Remove the disc cover of the unit by squeezing both sides of the disc cover. Using the brush, enclosed, remove hair on all sides of the discs. Replace the disc cover by gently pressing until it clicks into place

Q: Should I let someone else use my Emjoi® Divine?

A: No. For sanitary reasons, the **Emjoi® Divine** is only recommended to be used by one person.

## Q: When should I use the shaving attachment?

A: The shaving attachment is available so you can have the ultimate hair removal experience. You can epilate, for long lasting results or shave; it is totally up to you.

Q: How do I change from the epilation head to the shaving head?

A: Make sure that your Emjoi® Divine is in the "Off" position. Press the release button on the front of the unit and gently pull off the epilation head. Place the shaving attachment into the unit by pressing until it clicks

Note: When placing the shaving attachment into the unit, make sure that the teethed wheel on the unit and the opening of the shaving attachment line up.

Q: What is the comb coming out of each side of the shaving attachment? A: That is a long hair trimmer to make shaving even more effective than the foil head alone.

Q: How do I clean the shaving attachment?

A: It is recommended to clean the shaving attachment after each use. Use the cleaning brush, enclosed, to gently brush the hairs off the unit.

Q: When should I use the exfoliation attachment?

A: The exfoliation attachment is available so you can have the ultimate smooth skin experience. You exfoliate to soften rough skin and epilate to remove hair for silky skin all over your body.

Q: How do I change the epilation head to the exfoliation head?

Note: When placing the exfoliation attachment into the unit, make sure that the teethed wheel on the unit and the opening of the exfoliation attachment line up

Q: How do I change the exfoliation cartridge

A: Make sure that your **Emjoi® Divine** is in the "Off" position. Remove the used exfoliation cartridge (small cartridge on top of the exfoliation attachment above the plastic head) by holding the exfoliation attachment in one hand and with your other hand gently pull off the exfoliation cartridge. Note: To easily remove the cartridge use the finger grooves on the front and back of the exfoliation head. Choose the new exfoliation cartridge you want and press it into place.

Q: When should I put on a new exfoliation cartridge?


A: The exfoliation cartridges last 3-4 sessions depending on frequency of use and the size of the area being treated. O: How often should Luse the exfoliation attachment?


A: You can use the exfoliation attachment on your face and body once or

twice a week depending on skin sensitivity. Q: How do I clean the exfoliation attachment?

A: It is recommended to clean the exfoliation attachment after each use. Use the cleaning brush, enclosed, to gently brush off any debris or dust from the unit.

# Parts Description/Accessories Name






Use short, quick, brush like or

Gently brush the tweezers to

sweeping motions in the direction of hair growth.

For ultimate results take a warm bath or shower and use a loofa or exfoliation cream, in small circles to remove dead skin and open pores. Doing this before you use your **Emjoi® Divine** will help to make the hair removal process more



charge for at least 16 hours, initially

If your unit is not charged the unit can

Take extra care to extend the

Replace the disc cover




Remove the plastic protective cover.

May be used for the bikin

area (hold the skin taut

with one hand).



slide it up to the desired speed

Power "OFF"
Low speed for fine hair

2 High speed for coarse hair

**individual** hair from the upper lip and chin area.

The unit has 2 speeds:


0



The massaging fingers (on the disc cover) minimize pain during

May be used to remove hair

from underarms (extend your






a 90° angle, so the Emjoi® logo is facing you. Do not apply pressure; just glide the unit over the surface of the skin.



To Clean: Turn the unit off. Remove the disc cover of the

OF PROPERLY



unit by squeezing both sides of the disc cover and pulling up.



**CONTAINS BATTERY** BATTERY MUST BE RECYCLED OR DISPOSED



The Emjoi® Divine warranty against defects in material and workmanship lasts one year from the date of purchase.

Keep original receipt for warranty

During this warranty period, return the product to Emjoi, Inc. with proof of purchase to FDR Station, PO Box 7406, New York, NY 10150 Emjoi will take care of repair, or at their discretion, replacement of a defective unit without charge. For questions regarding this policy you may call toll free 1-888-99-EMIOI (1-888-993-6564).

Important: This warranty does not cover damages resulting from accidents, misuse alterations, abuse, lack of reasonable care, or performance of services or repairs by an unauthorized service center. The manufacturers and distributors of the **Emjoi® Divine** do not assume responsibility for any damage caused by misuse or use other than that described in

Model No. AP-17SE US Patent No. 5,976,157 Other Patents Pending © Soft Lines International Ltd. 2008

www.emjoi.com



# A: Make sure that your Emjoi® Divine is in the "Off" position. Press the release button on the front of the unit and gently pull off the epilation head. Place the exfoliation attachment into the unit by pressing until it

For best results: Take a warm bath or shower, to open up your pores, and use a loofa or exfoliation cream in small circles to exfoliate and remove dead skin from the area you wish to remove hair. Doing this before you use your Emjoi® Divine will cleanse and make your skin pliable, so removing

1. Use your Emjoi® Divine in a location that has a comfortable temperature

2. Make sure that the areas you wish to remove hair from are clean, dry and free from moisturizing cream or oil.

3. After your unit is charged remove the adapter plug from the bottom of the unit. If your unit is not charged, insert the adapter plug into the bottom of the unit and plug your adapter into an electrical outlet.

0 Power "OFF"

1 Low speed 2 High speed

7. Position your **Emjoi® Divine** so that the discs are upright, the Emjoi® logo should be facing you.

removing hair from.

strokes in the direction of hair growth

10. Before removing hair from the bikini line and underarms it is important with one hand while removing hair.

11. The **Emjoi® Divine** is only intended to remove single hairs from the upper lip and chin. Hold area taut and use a small brushing motion. Do not use like an electric shaver on your entire face!

12. Repeat within each area until all unwanted hair is removed. The time required to remove unwanted hair depends on the user's hair type.

13. After each use clean your Emjoi® Divine.

14. Keep the protective cap on your unit when it is not in use

hair will be less uncomfortable.

 Remove the protective cap, by gently pulling, from your Emjoi® Divine. 5. To turn On your unit, press the safety switch lock and at the same time slide it up to the desired speed. Low is recommended for fine hair and

high is recommended for coarse hair.

6. Hold the unit in your palm, at a 90° angle, so the Emjoi® logo is facing

9. Gently glide the **Emjoi® Divine** in short, quick, brush like or sweeping

**Note:** For your protection, your **Emjoi® Divine** may slow down, or stop operating completely if it is pressed too hard against the skin.

to use a loofa or exfoliation cream in a warm shower or bath to remove dead skin and prevent ingrown hairs. If it has been an extended amount of time since you have removed hair from your bikini line and underarms. trim the hair with a scissor or trimmer. Make sure to hold your skin taut

Remove the protective cap.

2. Remove the shaver head from the unit by pressing the release button on the front of the unit.

4. Clean the trimmers with cleaning brush.

inside the assembly.

until it clicks into place 7. Replace the shaver head onto the unit by pressing until it clicks into place. Note: When placing the shaver head onto the unit, make sure that the teethed

Adapter

Pouch

Regular cleaning and good maintenance ensures optimum results and will extend the lifetime of your Emjoi® Divine

1. Before cleaning, make sure to turn off your unit and if you have it plugged in, unplug it from the electrical outlet.

2. Remove the disc cover by squeezing both sides of the disc cover 3. Using the brush, enclosed, remove hair on all sides of the discs.

4. Replace the disc cover by gently pressing until it clicks into place.

5. Put the protective cap on to safeguard the tweezers.

Adapter Inlet

Divine

Cleaning Brush

To remove residue from the tweezers, use rubbing alcohol on the tip of the tweezers with a cotton swab that has been squeezed dry. Note: Make sure that the cotton swab is not soaked with alcohol.

# **Using The Shaving Attachment**

(Optional Attachment)

1. Remove the epilation head by pressing the release button on the front

2. Attach the shaver head with the protective cover on, and press until it clicks into place Note: When placing the shaver attachment into the unit, make sure that the teethed wheel on the unit and the teethed wheel on the shaver

Remove the protective cover and it's ready to use. Important: The shaver head should only be used at High speed.

4. Hold the **Emjoi® Divine** at a slight angle to skin and gently move it against the direction of the hair growth allowing the foil to trap the hair and smooth away any stubble.

### Cleaning The Shaving Attachment

(Optional Attachment)

3. Removing the blade and trimmer assembly from the shaver head.

5. Gently shake the blade and trimmer assembly to remove hairs accumulated 6. Replace the blade and trimmer assembly onto the shaver head by pressing

wheel on the unit and the teethed wheel on the shaver head line up. Remove the shaver head housing by pressing the release buttons at sides.

9. Use the brush to remove hairs that accumulated inside the shaver head housing and on the white part of shaver head.

10. Replace the shaver head housing onto the shaver head. Note: When placing the shaver head housing onto the shaver head, make sure that the shaver head housing and the shaver head line up.

### **Changing The Exfoliation Attachmen** (Optional Attachment)

11. Replace the protective cap

1. Make sure that your Emjoi® Divine is in the "Off" position. 2. Press the release button on the front of the unit and gently pull off the

epilation head 3. Place the exfoliation attachment into the unit by pressing until it clicks

into place. Note: When placing the exfoliation attachment into the unit, make sure that the teethed wheel on the unit and the opening of the exfoliation attachment line up.

4. Hold the **Emjoi® Divine** at a 90° angle to the skin. Gently move it against your skin allowing the exfoliation cartridge to smooth away any rough skin.

### **Using The Exfoliation Attachment**

(Optional Attachment)

1. Make sure that your **Emjoi® Divine** is in the "Off" position.

2. Remove the used exfoliation attachment (small cartridge on top of the exfoliation attachment above the plastic head) by holding the exfoliation attachment in one hand and with your other hand gently pull off the exfoliation cartridge.

Note: To easily remove the cartridge use the finger grooves on the front and back of the exfoliation head. 3. Choose the new exfoliation cartridge you want (Pink for face and Grey for body) and press it into place.

1. It is recommended to clean the exfoliation attachment after each use.

### Cleaning The Exfoliation Attachment (Optional Attachment

Use the cleaning brush, enclosed, to gently brush off any debris or dust Before using your hair remover please read all these instructions carefully and completely.

**Optional Attachment** 

• Use the **Emjoi® Divine** only for purposes described in this instruction

· Children should be supervised to ensure that they do not play with the

Please keep these instructions for future reference.

· This unit is intended for one person. We discourage sharing the unit · This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction

concerning use of the appliance by a person responsible for their safety. • Warning -To reduce the risk of burns, fires or electric shock, never leave

your Emjoi® Divine unattended when plugged in.

· Household use only.

 Do not use an extension cord with this unit. Keep the appliance dry.

· This unit is for dry use only.

· Always charge your unit in a cool, dry area. • Do not place or store the unit in direct sunlight. Please store your unit in a cool dry place at a temperature between 0 - 40°C.

• Do not store your unit where it can fall into a tub or sink of water.

• Warning - Do not use your Emjoi® Divine while bathing or in the shower. Your Emjoi® Divine is not waterproof or water resistant and is not intended to be used near water, in the bathtub or in the shower.

 Do not place your unit in water or drop water into your unit. · Do not reach for your unit if it has fallen into water. Immediately unplug

• The Emjoi® Divine can be used with the adapter supplied with the unit, after being plugged into an electric outlet or used without the adapter when it is fully charged. Prior to using the unit for the first time cordlessly it needs to be charged for 16 hours. When the unit is used with the adapter, place the adapter into the unit and

the appliance. When you are finished using your unit turn the unit "OFF" and then remove the adapter from the electrical outlet and then from the unit. When you unplug your unit please pull on the plug and not on the cord.

then into the electrical outlet. Make sure that the plug is inserted firmly into

· Always unplug your unit when it is not in use, unless it is being recharged, and before cleaning it. Do not wrap the cord of your adapter around the unit.

· Keep the cord of the adapter away from hot surfaces. · Never use your unit if the adapter cord or electrical outlet is damaged. • Do not cut off the adapter to use it with another plug as this can be a

hazardous situation. Only use your Emjoi® Divine with the adapter supplied with the unit. For questions regarding your adapter in the US contact 1-888-99EMJOI,

# • Caution: Before plugging into an electrical outlet, make sure that the

adapter is appropriate for the local voltage. This is extremely important Do not use this unit if the epilation head is damaged as this could lead

Never use your unit if it has been damaged or dropped into water.

Do not use your unit if it has damaged or broken tweezer discs as injury

Do not drop or insert anything into any openings of the unit.

nging the Optional Attachment: Turn off the unit. Remove the epilatic head by pressing the release button on the front of the unit. Place the shaver head / exfoliation head onto

lining up the teethed wheel on the body and the attachment.

 Do not use your unit outdoors Do not use your unit where aerosol products or oxygen is being used.

· Keep your unit out of reach of children This appliance is not to be used on, by or near children or invalids. · Only use this unit on clean, dry, lotion free skin.

 Do not use water or any other liquid on the tweezers other than rubbing To prevent accidents and injury to you or damage to the unit - when your **Emjoi® Divine** is in use, keep it away from the hair on your scalp, your eyebrows, eyelashes as well as clothes, brushes, wires,

cords, shoelaces etc. • Do not use the Emjoi® Divine if you have - allergic or sensitive skin that reacts to cosmetics, metals, clothing, etc., acne, body acne, warts, around moles and loose skin, diabetes, Raynaud's disease, eczema, psoriasis, hemophilia, immune deficiency, rosacea, couperose, varicose or irritated. Consult with your health care provider prior to use if you

have any of the above conditions. · Do not use the unit before or during menstruation, during pregnancy or for one month after giving birth unless you consult with your health care provider prior to use.

 Changes in your hormone levels (taking hormone medication, recently pregnant) can influence the color or thickness of hair growth. These changes are not caused by this product but hormonal changes.

· If you have any medical conditions, issues, questions or any sensitivity whatsoever we strongly advise you to consult with your health care provider before using this product. If you have a pacemaker consult with your health care provider prior to use.

. If you are epilating for the first time, we recommend doing it in the

evening so any possible redness or irritation can go away overnight

We suggest testing the unit gradually over a period of two to three days to allow your skin to adjust. • If you have never epilated before (or if it has been an extended time since you epilated) you will feel a prickling sensation when using the unit. This feeling is due to the fact that you are removing hair from the

root. After a few sessions the sensation you feel should diminish. · Removing hair from the root can cause ingrown hair and skin irritation (redness of the skin, discomfort, itching). If you know that you are prone to ingrown hair, removing hair from the root may not be for you. Regula skin massaging with a massaging glove or loofa, may help reduce the

chance or occurrence of ingrown hairs. After using the epilator you can use body cream or aloe vera to sooth the skin and any possible irritation.

 Using an epilator may cause redness or irritation of the skin. This is a normal reaction that will quickly disappear, but may be longer if you have very sensitive skin or are removing hair from the root for the first few times. If any irritation remains for more than 3 days, discontinue

use and consult with your health care provider. · Sometimes inflammation of the skin can occur when bacteria penetrate the skin. Cleaning the epilation head before and after each use can minimize the risk of infection.

• The **Emjoi® Divine** is only intended to remove single hairs from the upper lip and chin. Hold area taut and use a small brushing motion. The Emjoi® Divine is NOT an electric shaver and should NOT be used like an electric shaver on your entire face! Using the Emjoi® Divine like an electric shaver, without holding the skin taut, could potentially allow the **Emjoi® Divine** to pinch or grab the skin, which could cause irritation and skin damage

Before removing hair from the bikini line and underarms it is important to use a loofa sponge or exfoliation cream in a warm shower or bath to remove dead skin and help minimize the chance or occurrence of ingrown hairs. If it has been an extended amount of time since you have removed hair from your bikini line and underarms (if the hair is longer that 5mm), trim the hair with a scissor or trimmer. Make sure to hold your skin taut with one hand while removing hair. Some women may experience irritation after removing hair from the underarms and bikini line for the first time. We suggest testing the unit on a small part of the skin in these areas first

. To preserve and extend the life of your battery it is recommended to occasionally discharge the battery, let the charge run out completely, then recharge it.

 This appliance must be disconnected from the supply mains when removing the battery. · The battery must be removed from the appliance before it is scrapped

 The battery is to be disposed of safely. Do not continually rub the unit on the same area or apply strong pressure.

• Keep the protective cap on your unit when it is not in use.

Frequently asked questions Q: Does the Emjoi® Divine hurt?

A: The first time you use the Emjoi® Divine you might feel a prickling sensation, this feeling is due to the fact that you are removing hair from the root. After several uses, the tweezing becomes more comfortable even for those with sensitive skin.

Q: How should I hold the **Emjoi® Divine**?

A: To minimize discomfort, hold the skin surrounding the area you are removing hair from taut. Gently glide, do not apply pressure, the **Emjoi® Divine** in short, quick, brush like or sweeping strokes in the direction Note: For your protection, your Emjoi® Divine may slow down, or Q: How long should I charge my **Emjoi® Divine** if I want to use it without the cord? A: Initially, you need to charge your unit for 16 hours, like you would for

Q: Do I have to use my Emjoi® Divine with the adapter?

your unit and use it without the cord.

stop operating completely if it is pressed too hard against the skin.

A: No. Since you have the rechargeable **Emjoi® Divine** you can use it

with the adapter plugged into an electrical outlet or you can charge

a cell phone. Once your unit has been initially charged, you will be able to recharge it for 4-6 hours when needed. To extend the lifetime of your unit we recommend that you fully drain, let the battery wear out,

every six months. Q : Can I use the **Emjoi® Divine** on my upper lip?

Important: Hold your upper lip taut and use short brushing strokes to remove individual hairs from your upper lip. O: Can I use the **Emjoi® Divine** anywhere on my face? A: No. The **Emjoi® Divine** is only intended to remove individual hairs from the upper lip and chin area. When removing hair from your upper lip and chin, hold your skin taut and use short brushing motions. Do

A: Yes, the **Emjoi® Divine** is perfect for removing **individual** hairs from

not use **Emjoi® Divine** like you would for an electric shaver on your Q: Can I use the **Emjoi® Divine** on my bikini line and underarm?

A: Yes. Before removing hair from the bikini line or underarms it is important to use a loofa sponge in a warm shower or bath to remove dead ski and prevent ingrown hairs. Since these areas can be sensitive, it is

Q: Will my hair grow back as fast as it does when I shave?

back quicky. When you use the **Emjoi® Divine** it removes hair from the root so it takes longer, up to 4-6 week, to grow back. Q: What if my skin becomes red after using the **Emjoi® Divine**?

A: No. With shaving you are cutting the hair at the surface, so hair grows

A: Whenever you remove hair from the root your skin may become red

or irritated. To sooth irritation you can use lotion with aloe vera or antibiotic ointment.

Q: What can I do for ingrown hairs? A: We recommend using a loofa or an exfoliation cream in the shower or bath to soften the skin and any ingrown hairs, enabling the Emjoi® Divine to remove the hair from the root, If any irritation remains for more than 3 days, discontinue use and consult with your health care

Q: I have varicose veins, can I use the **Emjoi® Divine**?

A: Regarding any medical issues or questions, we strongly advise you to consult with your health care provider prior to use.

Q: Why is the **Emjoi® Divine** curved?

A: Because your body is curved. The tweezing head is curved to gently and effectively glide along the contours of your body.





The **Emjoi® Divine** is a terrific hair remover with 36 tweezer action discs

to ensure rapid, non-irritating and virtually painless hair removal from the

root. With its glide technology and massaging finger attachment

noving hair from the root has never been easier or more comfortable.

The Emjoi® Divine removes hair as short as 0.5 mm on the face, legs,

bikini line and underarms leaving skin super smooth for up to 6 weeks

When using an epilator for the first time we suggest that you

as a rechargeable device without the cord or with the cord by connecting

it to an electrical outlet. Your unit cannot be turned ON if the cord is

plugged into the unit but not into the electrical

outlet. Before using the Emioi® Divine

for the first time as a rechargeable

device, it should be charged for,

recommended that you recharge


occasionally discharge the battery.


let the charge run out completely,


for the local voltage. This is extremely important

at least, 16 hours. It is

# test the unit on an area that has light hair growth in order to get accustomed to the epilation process.







and then recharge it.

when traveling overseas.

