

MultiBlender™ Electronic

850 watt electronic blender with 7 programmed functions

Instruction Booklet PB7950



Contents

Sunbeam's Safety Precautions				
Features of your MultiBlender Electronic				
Before using your MultiBlender Electronic				
Jsing your MultiBlender Electronic				
A Guide to your MultiBlender Electronic				
Handy Blending Hints				
Care and Cleaning	8			
Recipes				
Soups	9			
Dips/Starters/Pastes	11			
Light Snacks	14			
Desserts	15			
Drinks	17			
Thick Shakes	19			
Cocktails	20			

تأكد من تفهم احتياطات السلامة المذكورة اعلاه

請務必理解上述的安全預防措施。

Assurez-vous que les précautions ci-dessus relatives à la sécurité sont bien comprises

Versichern Sie sich, dass die obenstehenden Sicherheitsmaßnahmen verstanden werden

Βεβαιώνετε πως οι παραπάνω προφυλάξεις ασφαλείας γίνονται κατανοητές

Pastikan bahwa tindakan-tindakan keselamatan seperti di atas dimengerti anda

Accertatevi che le suddette norme di sicurezza siano comprese a dovere

上記の注意事項をよくお読みになり、安全を御確認ください

Уверете се дека погоре споменатите мерки на претпаэливост се добро разбрани

Asegúrese de que las precauciones de seguridad precedentes sean bien comprendidas

ต้องแน่ใจว่า ข้อควรระวังเรื่องความปลอดภัยข้างต้น เป็นที่เข้าใจกันดี

Yukarda belirtilen güvenlik önlemlerinin anlaşıldığından emin olunuz

Xin kiểm chắc rằng những biện pháp làm an toàn kể trên được hiểu rõ

Sunbeam's Safety Precautions

SAFETY PRECAUTIONS FOR YOUR SUNBEAM MULTIBLENDER ELECTRONIC PB7950

- Ensure fingers are kept well away from the blades when in use.
- Always operate on a flat surface.
 - Sunbeam is very safety conscious when designing and manufacturing consumer products, but it is essential that the product user also exercise care when using an electrical appliance. Listed below are precautions which are essential for the safe use of an electrical appliance:
- Read carefully and save all the instructions provided with an appliance.
- Always turn the power off at the power outlet before you insert or remove a plug. Remove by grasping the plug - do not pull on the cord.
- Turn the power off and remove the plug when the appliance is not in use and before cleaning.
- Do not use your appliance with an extension cord unless this cord has been checked and tested by a qualified technician or service person.
- Always use your appliance from a power outlet of the voltage (A.C. only) marked on the appliance.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.
- The temperature of accessible surfaces may be high when the appliance is operating.
- Never leave an appliance unattended while in use.

- When using heavy loads this blender should not be operated for more than 1 minute and 40 seconds, this does not apply to any of the recipes detailed in this instruction booklet.
- Do not blend hot ingredients.
- Do not use an appliance for any purpose other than its intended use.
- Do not place an appliance on or near a hot gas flame, electric element or on a heated oven.
- Do not place on top of any other appliance.
- Do not let the power cord of an appliance hang over the edge of a table or bench top or touch any hot surface.
- Do not operate any electrical appliance with a damaged cord or after the appliance has been damaged in any manner. If damage is suspected, return the appliance to the nearest Sunbeam Appointed Service Centre for examination, repair or adjustment.
- For additional protection, Sunbeam recommend the use of a residual current device (RCD) with a tripping current not exceeding 30mA in the electrical circuit supplying power to your appliances.
- Do not immerse the appliance in water or any other liquid unless recommended.
- Appliances are not intended to be operated by means of an external timer or separate remote control system.
- This appliance is intended to be used in household and similar applications such as: staff kitchen areas in shops, offices and other working environments; farm houses; by clients in hotels, motels and other residential type environments; bed and breakfast type environments.

If you have any concerns regarding the performance and use of your appliance, please visit www.sunbeam.com.au or contact the Sunbeam Consumer Service Line. Ensure the above safety precautions are understood.

1

Features of your MultiBlender Electronic

Ingredient cup.

Handy 70ml ingredient cup. Also acts as a device to unscrew the blade assembly from the base of the jug.

Flexible lid with pouring hole.

To provide the necessary safety, the lid seals tightly to the jug and features a pouring hole, that allows you to add ingredients during the blending process.

1.6 litre heat-resistant jug.

The sizeable 1.6 litre glass jug features specially designed internal ribs to cycle ingredients back into the blade system for superior results.

The jug features an easy to pour lip and is marked in both cups and millilitres (mL) for ease of use.

Detachable blade system assembly.

The detachable blade assembly unit unscrews from the glass blending jug for convenient and thorough cleaning.


Motor base.

The base houses a powerful 850 watt motor providing superior performance for every blending task.

Non-slip feet.

Keeps the blender secure on the bench top during use.





Serrated stainless steel six-blade system.

Specially designed for extra durability, the heavy-duty, serrated stainless steel blade with a six-blade construction, crushes ice cubes to powder, produces a smooth consistency when pureeing and combines ingredients perfectly for a frappé.

Recipe programs.

Three blending favourites milkshake, thickshake and smoothie. Just add ingredients and each of these programs have been developed to ensure perfect consistent results everytime.

Functional programs.

To assist with some of the more functional blender uses, these four programs (mix, puree, cocktail and ice crush) have been tested and refined, to remove the guess work and improve on the final blending result.

Manual operation.

Low and High speed control plus Pulse.

Cord storage facility.


For tidy, convenient storage of the cord underneath the motor base.

Before using your MultiBlender Electronic

Important: Always ensure your blender is unplugged from the power outlet before fitting or removing the blade assembly. Always handle the blade assembly with caution, as the blades are extremely sharp.

To assemble the six-blade system in the glass jug (see Figure 1).

1. Place the silicone rubber seal over the sixblade assembly, as shown in figure 1.



2. Place the six-blade assembly into the glass jug and turn clockwise to secure firmly into position (see Figure 2).



Figure 2

Note: The blender jug will leak if the sixblade system is not assembled correctly.

Note: Do not attempt to remove the stainless steel blades from the blade assembly.

3. Plug the power cord into a 230-240 volt power outlet and turn the power 'ON'.

Using your MultiBlender Electronic

- Place the blender jug onto the motor base.
 Note: Do not switch 'ON' the MultiBlender Electronic without the lid in position.
- Place ingredients into the glass jug. Do not exceed the maximum indicated level – 1.6 litres.
- Position the lid with ingredient cup onto the blender jug. Ensure the lid is firmly in place.
- Using the control panel, select the desired function, either from the pre-programmed functions or the manual buttons High, Low and PULSE settings.

The Blending Guide on page 6 shows various functions that can be performed and the suggested speeds to use.

Note: Although the lid fits firmly to the glass jug, we advise when blending liquid ingredients, to place your hand on the lid as you initially select the blending speed/function. As the powerful 850 watt motor could cause the liquid to surge up causing leakage. Once you have started blending you can remove your hand.

Further ingredients can also be added

while blending by removing the ingredient cup and pouring ingredients through the hole in the lid.

Note: The pre-programmed functions can be stopped by simply pressing the 'OFF' button.

If using the manual buttons, Low or High, once you have completed blending, press the 'OFF' button on the control panel.

Note: When removing the six-blade assembly from the glass jug you may need to slightly tilt the blade so that it slides out easily. You shouldn't force the blades out of the glass jug as this will ultimately damage the blades.

A Guide to your MultiBlender Electronic

Processing Task	Food	Suggested Setting	Programme	Suggested Processing Procedure
Aerating	Milkshakes, Smoothies	HIGH	Milkshake	Use chilled milk. Blend until desired consistency is achieved.
Chopping	Nuts, Chocolate, Garlic or Herbs	PULSE		Process ½ cup at a time, to ensure evenly sized pieces.
Crumbing	Bread Crumbs	PULSE		Tear bread roughly. Process until desired consistency.
	Biscuit Crumbs	PULSE		Break into pieces and process until crumbed.
Crushing Ice		PULSE	Crush Ice	Add 1/4 cup of water. Use the PULSE button 3-4 times in succession for crushed ice.
Emulsifying	Salad Dressing	LOW	Crush Ice & Cocktails	Blend until well combined. Oil may be added to the mixture during processing through the pouring hole in the lid.
Mixing	Batters, Cakes	LOW & HIGH	MIX	Process ingredients until just combined. DO NOT OVERPROCESS.
Pureeing	Soups, Vegetables, Fruits	HIGH	PUREE	Blend until smooth.

Handy Blending Hints

- Nothing can beat a blender for making smooth purees and sauces or for whipping up frothy drinks – from healthy breakfast shakes to frozen daiquiris.
- Use your blender for chopping small amounts of food like nuts, bread crumbs and whole spices.
- Turn any oil-based salad dressing into a creamy style dressing by blending it until slightly thickened.
- A brief whirl in the blender will rescue a lumpy gravy, or an egg-based sauce that has separated.
- Food items for blending should be cut into cubes (approximately 2-3cm), this will assist in achieving an even result.
- Ensure the lid is firmly and securely placed on the jug. Do not operate the blender without the lid on, if you wish to add any additional ingredients remove the ingredient cup and add as necessary.
- Never fill above the maximum level indicator – 1.6 litres.

- To ensure efficient mixing when blending dry mixtures, it may be necessary to stop the blender and push ingredients down the sides of the jug with a spatula.
- When pureeing fruit or vegetables, cooked or raw, cut into small pieces to facilitate blending.
- When making bread crumbs, use 2 to 3 day old bread, leaving crusts on, to minimise the possibility of clumping. If only fresh bread is available, dry it out for a few minutes in a low heated oven.
- When blending a variety of ingredients together, blend the liquids first, then add dry ingredients.
- Always ensure stones are removed from fruit and bones from meat as these can harm the blades.
- Don't allow a used blender to sit for too long as the food will dry onto the blades, making it very difficult to clean. If you can't clean the blender straight away, pour some warm water in it and allow to soak.
- Do not process hot liquids in your blender.
 Allow to cool to room temperature before processing.
- Always ventilate the blender jug when pureéing warm ingredients. This is achieved by lifting the ingredient cup out of the lid after starting the blender.


Care and Cleaning

Quick cleaning method.

Half fill the blender with luke warm water and a small amount of detergent. Press the PULSE button for 10-20 seconds. Then remove the jug and rinse it under running water.

For thorough cleaning.

Turn the blender jug upside down. Unscrew the six-blade assembly from the glass jug by placing the open end of the ingredient cap at the base of the blade assembly. Use the 5 grooves on the opening of the ingredient cap to align the cap to the base of the glass jug. Turn the ingredient cap in an anti-clockwise direction to remove the blade assembly. See Figure 3.



Remove the rubber seal from the blade assembly. Wash the blender lid, ingredient cup, rubber seal, blade assembly and blender jug in warm soapy water.

Caution: Take care when cleaning the blades as they are extremely sharp.

Note: Do not clean any part of the blender in the dishwasher.

To clean the motor base.

Use a damp, soft sponge with mild detergent and wipe over the motor base.

Note: Never immerse the motor base in water.

Recipes - Soups

Potato and Leek Soup

Serves 4 Mexican style Tomato Soup

Serves 4

- 1 tablespoon olive oil
- 2 small rashers bacon, chopped
- 3 medium leeks, sliced thinly
- 1 kg potatoes, peeled and chopped roughly
- 2 litres chicken or vegetable stock

Freshly ground black pepper

½ cup grated Parmesan

- 1. Heat oil in a large saucepan; add bacon and cook, stirring occasionally, until crisp. Remove from pan.
- 2. Add leeks to the same pan and cook, stirring for about 5 minutes or until leeks are tender. Add potatoes and stock and bring to the boil; reduce heat and simmer, uncovered, for about 40 minutes.
- Remove from heat; cool to room temperature. Place half of the soup mixture into the blender jug and press the 'PUREE' button. When the cycle has finished, pour back in with remainder of soup.
- 4. Add cooked bacon to soup and reheat until soup is hot. Season to taste with freshly ground pepper.
- 5. Serve soup topped with parmesan cheese.

- 1 tablespoon olive oil
- 2 onions, chopped
- 2 cloves garlic, crushed
- 2 teaspoons cumin powder
- 1 teaspoon chilli powder
- 3 x 400g can chopped tomatoes

500ml water

- 1 teaspoon brown sugar
- 1 tablespoon vinegar
- 2 x 400g cans red kidney beans, rinsed, drained

Sour cream and flour tortillas to serve

- Heat oil in a large saucepan, add onions and garlic and cook on a medium heat until onions start to soften; add the cumin and chilli powder and cook, stirring, until the spices become fragrant. Add the tomatoes, and water; simmer for 20 minutes. Remove from heat; cool to room temperature.
- 2. Stir through the sugar, vinegar and beans; allow to cool.
- 3. Place half of the soup mixture into the blender jug and press the 'PUREE' button. Pour contents of blender jug into a container and repeat this step with the remaining soup mixture.
- Return soup to saucepan to heat through; serve with sour cream and warm flour tortillas.

Roast Pumpkin Soup

Serves 6

Vegetable Soup

Serves 4-6

- 1.5 kg pumpkin
- 2 tablespoons olive oil

Sea salt & freshly ground black pepper

20g butter

- 1 onion, chopped
- 1 litre chicken stock

1/3 cup cream or sour cream to serve (optional)

- 1. Preheat oven to 200°C.
- 2. Remove skin and seeds from pumpkin and cut into even sized chunks.
- Place pumpkin in an oven dish and drizzle with half the oil. Season with a little salt and pepper. Bake in oven for about 40 minutes or until cooked.
- 4. In a large saucepan heat remaining oil and butter. Add onion and cook until tender. Add the pumpkin and stock and bring to the boil. Reduce heat, simmer, uncovered, for 10 minutes. Cool to room temperature before blending.
- 5. Place half of the soup mixture in blender and press the 'PUREE' button. Repeat with remaining soup mixture.
- 6. Reheat until soup is hot. Serve with cream and extra ground pepper if desired.

- 1 tablespoon olive oil
- 1 onion, chopped
- 2 cloves garlic, crushed
- 2 carrots, diced
- 1 potato, diced
- 2 trimmed celery stalks, diced finely

800g can chopped tomatoes

6 cups water

- 1 cup chopped savoy cabbage
- 2 small zucchini, diced

100g button mushrooms, sliced sea salt and freshly ground black pepper

- Heat oil in frying pan on setting 5.
 Cook onion and garlic until translucent.
 Add carrot, potato and celery; cook, stirring occasionally for 5 minutes.
- Add the chopped tomatoes, cabbage, zucchini, mushrooms and water and bring the soup to the boil. Reduce heat to a simmer and cook, covered for about 45 minutes or until vegetables are tender.
- 3. Remove from heat and allow to cool to room temperature. Place the soup in batches into the blender jug and press the 'PUREE' button.
- 4. Return soup to saucepan and reheat until hot.

Tip: For a soup with more texture you can simply puree only half the soup.

Recipes – Dips/Starters/Pastes

Hummus

Serves 4 Guacamole

420g can chickpeas, rinsed, and drained

2 tablespoons tahini

1/4 cup lemon juice

½ cup water

½ cup olive oil

1 clove garlic, crushed

½ teaspoon ground cumin

½ teaspoon salt

- 1. Place all ingredients in the blender jug.
- 2. Press the 'PUREE' button.
- 3. Transfer mixture into a bowl and refrigerate for 1-2 hours before serving.

Serving suggestions: Serve hummus with toasted pita crisps; simply cut pita bread into triangles, brush with olive oil and season with a little salt and cumin seeds. Bake in oven at 200°C for about 5 minutes or until crisp.

2 ripe avocados, peeled, seeds removed

1 clove garlic

1 tablespoon lemon juice

dash Tabasco sauce

1 jalepeno chilli, sliced

1/4 cup fresh coriander leaves

1 tomato, chopped

- 1. Place all ingredients except tomato in the blender jug.
- 2. Press the 'PURFF' button.
- 3. Transfer mixture to a bowl and stir through tomato.
- 4. Refrigerate for 1 hour before serving. Serve with corn chips and salsa

Pesto

Serves 4

Whole Egg Mayonnaise Approx. 1½ cups

- 125g fresh basil leaves
- 3 cloves garlic
- 2 teaspoons lemon juice sea salt

freshly ground black pepper

- 1 cup extra virgin olive oil
- ½ cup pine nuts, roasted

60g pecorino or parmesan, grated

- 1. Place the basil, garlic, juice, salt, pepper and oil in the blender jug. Blend on 'HIGH' for 20 seconds.
- Push down any ingredients that may have come up the sides of the jug and add the nuts and cheese. Blend on 'HIGH' for a further 20 seconds or until a smooth texture is achieved. If a nutty texture is desired only blend on 'HIGH' for 5-10 seconds.

To serve: Boil a large pot of boiling water with a little oil in it. Boil 500g pasta until just tender. Drain pasta well but do not rinse. Place hot pasta back in to pot and stir through half of the pesto sauce. Add more pesto to taste if desired. Serve with extra cheese and a sprinkle of toasted pine nuts.

Tip: To keep pesto sauce for a few days in the refrigerator simply place pesto into a clean container and pour enough olive oil over top to cover, this will stop the pesto from discolouring. Cover with lid or plastic wrap.

- 1 egg
- 1 tablespoon lemon juice
- 2 teaspoons Dijon mustard pinch sea salt
- 1 cup vegetable oil
- Place egg, juice, mustard and salt in the blender jug. Blend on 'LOW' for 10 seconds or until combined.
- With the motor still running remove the measuring cup from the lid, start to pour in the oil in a slow, thin stream until the mixture is creamy and all the oil has been added.
- 3. Keeps in the refrigerator for 1 week.

Baba Ghanoush

- 2 large eggplants
- 2 cloves garlic
- 2 tablespoons tahini
- ½ cup lemon juice
- 1/4 teaspoon sweet paprika sea salt and freshly ground black pepper
- 1 tablespoon Extra Virgin olive oil
- Pierce eggplants all over with a fork. Cook eggplants under a griller until the skin blackens and the flesh is soft. Allow eggplants to cool for 20 minutes before removing skin; drain for 10 minutes.
- Place all ingredients into blender jug.
 Place lid onto jug and press the 'PUREE' button. Check mixture and scrape sides if necessary. Blend on low to finish blending if needed.
- 3. Transfer mixture into a bowl and refrigerate for 1-2 hours before serving. Drizzle extra virgin olive oil over the top before serving.

Serve with crusty fresh bread

Herbed Mushroom Pate Approx. 1½ cups

50g butter or margarine
1 onion, roughly chopped
300g mushrooms, sliced
200g cream cheese, cubed
1 tablespoon freshly chopped chives
salt and freshly ground black pepper to taste

- 1. Heat butter in a frying pan over a medium heat. Cook onion and mushrooms until soft; cool.
- 2. Place mushroom mixture into blender jug with remaining ingredients.
- 3. Press the 'PUREE' button.
- 4. Pour into serving bowl and refrigerate for at least 2 hours before serving.
- 5. Serve with Melba toasts.

Recipes - Light Snacks

Sweet potato and rocket frittata Serves 8 Bacon and Cheese Quiche

1 small sweet potato 80g baby rocket leaves 200g fetta cheese, crumbled 250ml thickened cream

10 eggs

Sea salt and freshly ground black pepper, to taste

½ cup grated tasty cheese

- 1. Preheat oven to 200°C. Grease and line base of a 19cm square shallow cake tin.
- 2. Peel the sweet potato and slice thinly.
- 3. Place a layer of sweet potato then rocket then fetta into the cake tin and then repeat layers again. Reserve a few sweet potato slices if possible for the top.
- 4. Combine the eggs, cream, salt and pepper in blender and blend on HIGH until smooth. Pour egg mixture into the cake tin and top with the grated cheese.
- 5. Place frittata into oven and cook for about 30-35 minutes or until cooked through. If the frittata starts to brown too much before the inside is completely cooked lay a piece of foil over the top, this will stop excessive browning.

1 large sheet ready made frozen shortcrust pastry

6 bacon rashers, rind removed, roughly chopped

1 small onion, chopped finely

1½ cups grated tasty cheese

4 eggs

1 cup milk

½ cup cream

 $\frac{1}{2}$ cup self raising flour

pepper to taste

- Preheat oven to 180°C. Line quiche dish with pastry and trim edges. Prick pastry all over with a fork.
- Cook bacon in a frying pan until tender, remove from pan and drain on absorbent paper; cool.
- 3. In a large bowl combine the bacon, onion and cheese.
- 4. Place all the remaining ingredients into the blender jug.
- 5. Press the 'MIX' button.
- Place the bacon mixture into the prepared quiche dish and pour the egg mixture over the top.
- Bake in oven for about 50 minutes or until cooked. Allow quiche to stand for 10 minutes before cutting.

Recipes - Desserts

Baked Lemon Cheesecake

Serves 10 Banan

Banana Cake with Cream Cheese Frosting

250g plain biscuit crumbs

2 teaspoons nutmeg

125g melted butter

250ml thickened cream

3 eggs

½ cup caster sugar

2 teaspoon grated lemon rind

2 tablespoons lemon juice

500g cream cheese, room temperature, cubed

- Crush biscuits 5-6 at a time using the 'PULSE' button until crumbled. Remove jug from base and shake biscuits if necessary. Combine the nutmeg, melted butter and biscuit crumbs in a bowl; mix well. Press crumb mixture into the base and sides of a greased 20cm springform pan. Place on a baking tray and refrigerate for 30 minutes.
- 2. Place cream, eggs, sugar, rind, juice and half of the cream cheese in blender.
- 3. Press the 'MIX' button. With the motor still running, remove the ingredient cup from the lid and drop in the remaining cubes of cream cheese one at a time, until the mixture is smooth.
- Pour filling into crust and bake in oven at 160°C for approximately 50 minutes or until firm. Cool in oven with door ajar. Refrigerate for several hours before serving.

21/4 cups self raising flour

½ teaspoon salt

1 teaspoon cinnamon

½ teaspoon nutmeg

2 eggs

180g butter, room temperature, chopped

½ cup buttermilk

1½ cups raw sugar

1 teaspoon white vinegar

1 teaspoon vanilla essence

1½ cups very ripe mashed banana

- 1. Preheat oven to 180°C. Grease and line a 20cm baba pan.
- 2. Sift flour, salt, cinnamon and nutmeg into a large bowl.
- 3. Place the eggs, butter, milk, sugar, vinegar, essence, and bananas into blender jug.
- 4. Press the 'MIX' button. (Mixture will separate at this stage but will come back together when mixed with dry ingredients).
- Pour the banana mixture into the dry ingredients and mix with a wooden spoon or whisk until combined.
- Pour mixture into prepared tin and bake for about 40 minutes or until cooked when tested with a skewer.
- 7. Allow cake to cool in pan for 5 minutes before transferring to a wire rack to cool.
- 8. Ice with cream cheese frosting, recipe over page.

Cream Cheese Frosting

250g softened cream cheese

½ cup butter

- 1 teaspoon vanilla
- 3 cups icing sugar mixture
- 1/4 cup passionfruit pulp

Combine cream cheese, butter and vanilla in a small bowl. Using an electric mixer beat until smooth. Add the icing sugar mixture and beat until smooth. Reduce speed and add passionfruit. Spread over cooled cake.

Sticky Date Pudding

Serves 8

200g coarsely chopped dried dates

- 1 teaspoon bicarbonate soda
- 1 1/4 cups boiling water

60ml olive oil

- 1 cup firmly packed brown sugar
- 1 cup self raising flour
- 1/4 teaspoon mixed spice
- 2 eggs

Butterscotch sauce

140g butter

2/3 cup firmly packed brown sugar

1 cup (250ml) thickened cream

- 1. Preheat oven to 180°C. Grease and line a 20cm cake pan with baking paper.
- Place dates, soda and water into the blender jug. Pace the lid on and allow the mixture to stand for 5 minutes.
- 3. Add oil and sugar and pulse 3 times.
- Add remaining ingredients and pulse mixture until just combined. Scrape down sides of jug if necessary. Do not over process.

- 5. Pour mixture into prepared pan and bake for about 1 hour or until cooked when tested with a wooden skewer. Remove from oven and stand for 5 minutes before turning out onto a wire rack.
- Serve pudding with butterscotch sauce.
 To make sauce, heat all ingredients in a small saucepan over a low heat until combined.

Honey Pikelets

Makes 30

3 large eggs

½ cup honey

1 cup milk

1½ cups self raising flour pinch salt

- Add all ingredients into the blender jug and blend on 'LOW' for 30 seconds.
 Scrape down sides of blender and blend again on 'LOW' for a further 30 seconds.
- 2. Pour mixture into a jug and refrigerate for 30 minutes.
- 3. Place tablespoon amounts of mixture into a lightly greased frying pan until golden on each side.
- 4. Serve with butter.

Recipes – Drinks

Place all ingredients into blender jug.
 Press the 'MILK SHAKE' button.

3. Pour into 2 glasses.

Classic Banana Smoothie Serves 2 Serves 2 Milo Madness 2 cups skim milk 2 cups milk 2 medium bananas, roughly chopped 2 scoops vanilla ice cream ½ cup low fat yogurt 3-4 tablespoons Milo 1 tablespoon honey 1. Place all ingredients into blender jug. ½ teaspoon cinnamon 2. Press the 'MILK SHAKE' button. 1. Place all ingredients into blender jug. 3. Pour into 2 glasses, dust with extra Milo. 2. Press the 'SMOOTHIF' button. Serves 2 **Fruity Fantasy** 3. Pour into 2 glasses. 180ml fresh orange juice Classic Milkshake Serves 2 90ml pineapple juice 250ml milk 1 punnet strawberries 2 scoops ice cream - any flavour slice honeydew melon slice rockmelon 2 tablespoons topping – any flavour 8 small ice cubes 1. Place all ingredients into blender jug. 2. Press the 'MILK SHAKE' button. 1. Place all ingredients into blender iug. 3. Pour into 2 glasses. 2. Press the 'SMOOTHIE' button. 3. Pour into 2 glasses. Serves 2 Strawberry Milkshake 6 strawberries 2 cups milk 2 scoops strawberry ice cream

Citrus Buzz

60ml fresh lime juice 1 cup raspberry yogurt 4 dashes Angostura bitters 1 cup frozen yogurt 8 small ice cubes 1 cup orange juice lemonade 1 cup frozen raspberries 1. Place all ingredients except for lemonade 1. Place all ingredients into blender jug. into blender jug. 2. Press 'SMOOTHIE' button. 2. Press the 'SMOOTHIF' button. 3. Pour into 2 glasses. 3. Pour into 2 glasses, top with lemonade. Peach Smoothie Serves 2 **Iced Coffee** Serves 2 400g can peaches in natural juice, drained 2 tablespoons instant coffee dissolved in ½ cup plain yogurt 2 tablespoons boiling water 2 teaspoons honey 2 cups milk 1 scoop vanilla ice-cream 2 scoops vanilla ice cream 1 cup milk whipped cream to serve 1. Place all ingredients into blender iug. 1. Place all ingredients except for cream into 2. Press 'SMOOTHIE' button. blender jug. 3. Pour into 2 glasses. 2. Press the 'MILK SHAKE' button. 3. Pour into 2 large glasses, top with Serves 2 Mango Papaya Smoothie whipped cream and dust with chocolate. 1 mango, peeled, pitted, and chopped ½ small papaya, peeled, seeded, and **Frosty Fruity Smoothie** Serves 2 chopped 1 banana 1 cup plain yogurt 1 cup tropical juice 1 tablespoon fresh lime juice ½ cup milk 1 tablespoon honey 3 ice cubes 1. Place all ingredients into blender jug. 1. Place all ingredients into blender jug. 2. Press 'SMOOTHIE' button. 2. Press 'SMOOTHIE' button.

Serves 2

Raspberry Citrus Smoothie

3. Pour into 2 glasses.

Serves 2

3. Pour into 2 glasses.

Recipes - Thick Shakes

Tips for great Thick shakes

- Don't use hard ice cream straight from the freezer
- Leave ice cream out for about 5 minutes before blending; this time may vary depending on how cold your freezer is.
- Ice creams with a higher cream content may need a little extra milk.
- Always put ice cream in the blender jug in small pieces, never in large chunks as this may prevent the blender from blending in the allotted time.

Classic thick shake

Serves 2

270g chocolate ice cream ¹/₃ cup milk

- 1. Place all ingredients into blender jug.
- 2. Press the 'THICK SHAKE' button.
- 3. Pour into 2 glasses.

Berry Yogurt Thick shake

Serves 2

270g frozen berry yogurt ½ cup frozen mixed berries ½ cup milk

- 1. Place all ingredients into blender jug.
- 2. Press the 'THICK SHAKE' button.
- 3. Pour into 2 glasses.

Tim Tam Thick shake

Serves 2

4 Arnott's Original Tim Tams, roughly chopped

270g vanilla ice-cream 100ml milk

- 2 Tim Tam Fingers, to garnish
- 1. Place ingredients into blender jug.
- 2. Press the 'THICK SHAKE' button.
- 3. Pour into 2 glasses, garnish with Tim Tam Fingers.

Recipes - Cocktails

Sugar Syrup is an essential ingredient to making great cocktails. Use equal parts of white sugar and water and bring to the boil in a small saucepan until the sugar has dissolved. Cool and store in the refrigerator.

Frozen Lime Margarita

Serves 2

60ml tequila

30ml fresh lime juice

60ml Cointreau or triple sec

30ml sugar syrup

14 standard size ice cubes

- 1. Combine all ingredients in blender.
- 2. Press the 'COCKTAIL' button.
- 3. Pour into 2 cocktail glasses.

Strawberry Daiquiri

Serves 2

90ml Bacardi rum

60ml fresh lime juice

60ml sugar syrup

6 strawberries, quartered

14 standard size ice cubes

- 1. Combine all ingredients in blender.
- 2. Press the 'COCKTAIL' button.
- 3. Pour into 2 cocktail glasses.

Pina Colada

Serves 2

90ml Bacardi rum

120ml pineapple juice

60ml coconut cream

30ml Malibu

30ml sugar syrup

14 standard size ice cubes

- 1. Combine all ingredients in blender.
- 2. Press the 'COCKTAIL' button.
- 3. Pour into 2 cocktail glasses.

Splice

Serves 2

60ml Midori

60ml Malibu

120ml pineapple juice

80ml cream

- 14 standard size ice cubes
- 1. Combine all ingredients in blender.
- 2. Press the 'COCKTAIL' button.
- 3. Pour into 2 cocktail glasses.

glasses with milk.

Serves 2 Mocha Madness Serves 2 Frozen Cosmopolitan 20ml citron vodka 30ml espresso coffee 60ml Baileys 40ml vodka 60ml vodka 60ml Cointreau 1 scoop chocolate ice cream 120ml cranberry juice 14 standard ice cubes 1 teaspoon lime juice 8 standard size ice cubes 1. Combine all ingredients in blender. 2. Press the 'COCKTAIL' button. 1. Combine all ingredients in blender. 3. Pour into 2 cocktail glasses. 2. Press the 'COCKTAIL' button. 3. Pour into 2 cocktail glasses. **Eggnog** Serves 2 30ml sugar syrup 60ml brandy 60ml dark rum 2 eggs 8 standard size ice cubes Milk 1. Combine all ingredients except milk in blender. 2. Press the 'COCKTAIL' button. 3. Pour into 2 cocktail glasses then top up

Notes

Notes

Notes



12 Month Replacement Guarantee

In the unlikely event that this appliance develops any malfunction within 12 months of purchase (3 months commercial use) due to faulty materials or manufacture, we will replace it for you free of charge.

Should you experience any difficulties with your appliance, please phone our customer service line for advice on 1300 881 861 in Australia, or 0800 786 232 in New Zealand. Alternatively, you can send a written claim to Sunbeam at the address listed below. On receipt of your claim, Sunbeam will seek to resolve your difficulties or, if the appliance is defective, advise you on how to obtain a replacement or refund.

Your Sunbeam 12 Month Replacement Guarantee naturally does not cover misuse or negligent handling and normal wear and tear.

Similarly your 12 Month Replacement Guarantee does not cover freight or any other costs incurred in making a claim. Please retain your receipt as proof of purchase.

The benefits given to you by this guarantee are in addition to your other rights and remedies under any laws which relate to the appliance.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law and under the New Zealand Consumer Guarantees Act.

In Australia you are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

Should your appliance require repair or service <u>after</u> the guarantee period, contact your nearest Sunbeam service centre.

For a complete list of Sunbeam's authorised service centres visit our website or call:

Australia

www.sunbeam.com.au

1300 881 861

Units 5 & 6, 13 Lord Street Botany NSW 2019 Australia

New Zealand

www.sunbeam.co.nz

0800 786 232

26 Vestey Drive, Mt Wellington Auckland, New Zealand



Need help with your appliance?


Contact our customer service team or visit our website for information and tips on getting the most from your appliance.

In Australia

Visit www.sunbeam.com.au Or call 1300 881 861

In New Zealand

Visit www.sunbeam.co.nz Or call 0800 786 232



'MultiBlender' is a trademark of Sunbeam Corporation.

Made in China.

Due to minor changes in design or otherwise,

the product may differ from the one shown in this leaflet.

© Copyright. Sunbeam Corporation Limited 2011.

ABN 45 000 006 771

Units 5 & 6, 13 Lord Street

Botany NSW 2019 Australia

Unit 3, Building D

26 Vestey Drive

Mt Wellington Auckland

New Zealand

Sunbeam Corporation is a division of GUD Holdings Ltd.