



Package contents

Digital-to-analog converter box
 Remote control
 AAA battery
 Coaxial cable
 RCA audio/video cable




Install remote control battery

Remove the cover from the back of the remote control, insert the battery as shown, then replace the cover.




Connect to antenna and TV



Method 1 (Better)

- 1 Connect the antenna to the **IN (FROM ANT)** jack on your converter box using a coaxial cable.
- 2 Connect the **R AUDIO**, **L AUDIO**, and **VIDEO** jacks on your converter box to the corresponding jacks on your TV using an A/V cable. TV should be tuned to correct video source (see your TV documentation).
- 3 Plug the power cable into a power outlet or surge protector. This is the preferred method for the best video and audio quality.




Method 2 (Good)


- 1 Connect the antenna to the **IN (FROM ANT)** jack on your converter box using a coaxial cable.
- 2 Connect the **OUT (TO TV)** jack on your converter box to the **Antenna IN** jack on your TV using a coaxial cable. Your TV must be tuned to channel **3**. For best performance with this connection, change the Audio Output option in the Options menu to Mono. For more information, see "OPTION menu" on page 9 in your *User Guide*.
- 3 Plug the power cable into a power outlet or surge protector.

Complete setup


1 Turn on your converter box and TV.



2 Press > on the remote control.



3 Press ^ or v to select a menu language (**English, Spanish, or French**), then press >.





4 Press ^ or v to select your TV aspect ratio, then press >.




TV aspect ratios:
4x3 is standard size
16 x 9 is widescreen


5 Press ● to start the channel search. When the search is complete, press >.



6 Press ^ or v to select your time zone, then press >.



7 Press ● to complete the setup.



Leave the TV on channel **3** or **Video Input** (as determined in the "Connect" step) and change the channel with the converter box remote control.

If you have any issues with this product, DO NOT RETURN TO THE STORE. Call INSIGNIA at 1 877 467-4289