



# VRBT300V Hands-Free Car Kit

Dear Customer,  
CONGRATULATIONS. The VRBT300V Bluetooth® Hands-Free Cell Phone Car Kit allows the driver to make voice calls hands-free via their Bluetooth® mobile phone. When used as described, the VRBT300V will give you years of dependable service in your car, truck, RV, or mini-van. We have taken numerous measures in quality control to ensure that your product arrives in top condition and will perform to your satisfaction. In the rare event that your VRBT300V Bluetooth® Hands-Free Cell Phone Car Kit contains a damaged or missing item, does not perform as specified, requires warranty service, or you have an installation problem, **DO NOT RETURN THIS PRODUCT TO THE STORE. PLEASE CALL OUR TOLL FREE NUMBER FROM THE U.S.A. AND CANADA 1-800-445-1797** and ask to speak with a member of our technical service team; or submit your questions via our web site [www.vr-3.com](http://www.vr-3.com) and a member of our technical service team will respond by e-mail to your questions. Our in-house technical service team will expedite delivery of your part, advise you on installation, or help troubleshoot a problem with you. If your product needs warranty service, our technical service team representative will help you obtain the fastest remedy possible under the warranty.

## Features & Functions

**WARNING: The user MUST read the instructions in full, and successfully operate the VRBT300V with a cell phone before using in the car.**



### IMPORTANT INFORMATION & PRODUCT MAINTENANCE

- Store in a cool, dry place; use clean soft cloth to clean the surface of Bluetooth® car kit.
- Do not expose to high or extremely low temperatures, or to dust.
- Do not open VRBT300V. Non-professional maintenance may cause damage, and will void the warranty.
- Do not operate the VRBT300V roughly, e.g knocking, bumping.
- Do not short circuit the charging port of the VRBT300V; a short circuit will cause damage to the battery.
- Use original accessories only; any damage caused by using other accessories will void the warranty.
- If the VRBT300V does not turn on, please recharge the battery.

## Operation

### INSTALLATION

To install the VRBT300V, attach to the visor of your vehicle using the clip on the rear of the unit.

### CHARGING

Insert the mini USB connector of the charging adaptor into the mini USB charging port of the VRBT300V, then insert the 12 Volt adaptor end into the vehicle's cigarette lighter socket or 12 Volt Power Port. If the unit is ON, it will automatically shut OFF when you start charging and the Red LED will come on to indicate the unit is charging. When the VRBT300V is fully charged, the Red LED will go off.

### LOW BATTERY WARNING

When the VRBT300V battery is low, the Blue LED will be off, the Red LED will flash, and the speaker will make a BEEP sound.

### POWER ON AND OFF

Press and hold the Multi-Function Button until you hear a short BEEP and HELLO is displayed on the LCD. When the VRBT300V is in standby mode, press and hold the Multi-Function Button for 3 seconds to turn the unit off. You will hear a long BEEP and both LED lights will turn off.

### MULTI-FUNCTION BUTTON

POWER - Press and hold until you hear a beep and HELLO appears on the LCD.

PAIRING - Press and hold until you hear 2 beeps and the buttons alternately flash ON & OFF.

ANSWER A CALL - Press once

RE-DIAL - Press two times or more, depending on your phone's features.\*

VOICE ACTIVATED DIALING - Press once\*

CALL TRANSFER - Press once to transfer to VRBT300V

Press and hold for 3 seconds to transfer to cell phone

MUTE - Press and hold for 3 seconds

### THREE WAY BUTTON

VOLUME - Move the 3-Way button to the right to increase, - or move the 3-Way button to the left to decrease.

CALL WAITING\* - With a call in progress you will hear 2 short tones, then:

1. Press and hold the 3-Way button to the right for 3 seconds to put the current call on hold and answer the waiting call.

Note: To cancel the second call and return to the "call on hold", press the cancel button once.

2. Press and hold the 3-Way button to the left for 3 seconds to cancel the current call and answer waiting call.

MUTE - Press and hold for 3 seconds to Mute or Unmute.

ENTER CALL LOG BOOK - Press Once

TO CHOOSE A CALL LOG BOOK - Move to Left or Right

### CANCEL BUTTON

END CALL - Press Once

REJECT CALL - When you are on a previous call, press once to reject an incoming call.

EXIT CALL LOG BOOK - Press Once

### PAIRING WITH A BLUETOOTH® ENABLED CELL PHONE

1. The VRBT300V and the Bluetooth® enabled cell phone should be within a distance of 3 feet (1 meter).

2. With the VRBT300V OFF, press and hold the Multi-Function button until you hear 2 beeps. The Red & Blue LEDs will flash indicating the unit is ready to be paired.

3. The Bluetooth® cell phone will search for nearby Bluetooth® devices. The cell phone will display the "VRBT300V" in the list of Bluetooth® devices. If you are using a "dongle" type Bluetooth® adaptor, follow the manufacturer's instructions for that device.

4. Select "VRBT300V" to add this Bluetooth® device into the list of paired devices.

5. Enter in the PIN Code "0000" and your mobile phone will show that pairing is complete.

6. If pairing is successful, user will hear a long BEEP and the Blue LED(cancel) will flash about every 3 seconds.

### CALLER ID DISPLAY

The LCD will flash ON & OFF while displaying the phone number of the incoming call. The phone number of the incoming call will be displayed on the LCD.

## Operation

### CALL LOG BOOK

Note: The Call Log Book feature DOES NOT access the cell phone's Call Log Book.

1. Press the 3-Way button once to enter the Call Log menu. The three call log categories are: Missed Calls -> Dialed Calls -> Received Calls in that order.

2. Move the 3-Way button to the LEFT or RIGHT to navigate the three logs.

3. Press the 3-Way button once to enter each log.

4. After you enter a Call Book Log, move the 3-Way button to the LEFT or RIGHT to navigate through the phone numbers. Press the Multi-Function Button to call the high-lighted phone number.

5. Press the Cancel Button to quit the Call Log Book.

### CALL LOG DISPLAY

Within the Call Log Books, each number is preceded by a single digit number (0-5) and a space to designate the order the calls were received. "0" is the most recent number; "1" is the next number and so on, up to "5".

### RECONNECT TO CELL

1. If the VRBT300V loses connection by moving out of operating distance of the paired cell phone, reconnect by moving it within the operating area and press the Multi-Function button once to reconnect to the cell phone.

2. If the VRBT300V is disconnected because of being powered off, it will connect automatically after powering on again.

### STORAGE CONDITIONS

Operating Temperature Range 0°C to +50°C (32° to 122°F) without loss of function.

Storage Temperature Range: - 20°C to +65°C (-4° to 149°F) without any damage.


Humidity Range: 30%-90% humidity

### EARBUD

Insert the earbud's plug into the headphone jack on the side of the VRBT300V.

Use the Earbud for privacy or high ambient noise situations.

\*Note: Please refer to your cell phone's product user manual for Voice Dialing, Call & Redial functionality and settings.



### ICONS

When the VRBT300V completes a Bluetooth® connection, the Bluetooth® icon will be on.

A solid Battery Power Level Icon will display when the battery is full; One line on Battery Power Level icon will display when the battery is half full; only the battery frame will remain when the battery is discharged.

When opening the Call Logs, the Call Log Book icon will be on.

When entering the Received Call Log, the Received Call icon on the LCD and the Call Log Book icon will be on.

When there is an incoming call, the Incoming Call icon will be on while the backlit LCD flashes

When entering the Received Call Log, the Received Call icon on the LCD and the Call Log Book icon will be on.

The Missed Call icon will be on when a call is missed and until that call is acknowledged.

When entering the Dialed phone numbers in the Phonebook, the Outgoing Call icon on the LCD and the Call Log Book icon will be on.

When checking a phone number in the Missed Call Log, the Missed Call icon and the Phonebook icon will be on.

When entering the Dialed phone numbers in the Phonebook, the Outgoing Call icon on the LCD and the Call Log Book icon will be on.