

Philips DVD laser lens cleaner

Brush system

Twelve

SVC2522W



Clean and protect your DVD player

Regular cleaning of your DVD player's lens ensures optimum performance of your equipment. It is important to keep a DVD player optical laser lens clean and dust free. This dry-brush system safely removes dust, debris and other contaminants.

Maintain original sound and video quality

· Safe dry brush cleaning system

Easy to use

• Voice instructions in 14 languages



DVD laser lens cleaner Brush system Twelve

Specifications

Storage Media

Supported formats: DVD-ROM, DVD/R, DVD/ RW

Accessories

• User Manual: 3 languages

Inner Carton

- EAN: 87 12581 39470 7
- Gross weight: 0.48 kg
- GTIN:
- Inner carton (L \times W \times H): 20 \times 7 \times 14.7 cm
- Nett weight: 0.12 kg
- Number of consumer packagings: 6
- Tare weight: 0.36 kg


Outer Carton

• EAN: 87 12581 39471 4

- Gross weight: 10.48 kg
- GTIN:
- Outer carton (L x W x H): 42.9 x 35.1 x 36.1 cm
- Nett weight: 1.44 kg
- Number of consumer packagings: 72
- Tare weight: 9.04 kg

Packaging dimensions

- Packaging dimensions (W x H x D): 14 x 18.5 x 1.3 cm
- EAN: 87 12581 39469 I
- Gross weight: 0.12 kg
- Nett weight: 0.02 kg
- Number of products included: I
- Packaging type: Carton
 Tare weight: 0.1 kg
- UPC:



Product highlights

Dry brush system

The dry brush cleaning system safely removes dust, debris and other contaminants from the CD/DVD players laser lens, leaving it clean and performing optimally.

Voice instructions

The voice instructions on this easy to use CD lens cleaner guide you through the cleaning process in one of the 14 languages provided.



Issue date 2008-02-22

© 2008 Koninklijke Philips Electronics N.V. All Rights reserved.

Version: 1.1.5

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

12 NC: 8670 000 36943 EAN: 87 12581 39469 I

www.philips.com