

MODEL H7728 ROLLING TOOL CART INSTRUCTION SHEET

Introduction

This rolling tool cart with tool box requires some assembly. Follow the instructions under each **Figure** on the following page.

To begin, lay out all of the parts and compare quantities to the inventory list given below.

If you need additional help with these instructions, call our service department at: (570) 546-9663.

Inventory (Figure 1)

Vertical Support	4
Handle	1
Plain Caster	2
Pivoting Caster	2
8mm Carriage Bolt	22
8mm Hex Nut	24
6mm Phlps. Head Screw	16
6mm Hex Nut	16
8mm Flat Washer	24
Front/Back Support	2
Angle Bracket	4
	Tool Box w/ Upper Shelf Side Support Bottom Shelf Vertical Support Handle Plain Caster Pivoting Caster 8mm Hex Bolt 8mm Carriage Bolt 8mm Hex Nut 6mm Hex Nut 6mm Hex Nut 8mm Flat Washer Front/Back Support Angle Bracket



Figure 1. Inventory of parts.

COPYRIGHT © SEPTEMBER, 2005 BY GRIZZLY INDUSTRIAL, INC. WARNING: NO PORTION OF THIS MANUAL MAY BE REPRODUCED IN ANY SHAPE OR FORM WITHOUT THE WRITTEN APPROVAL OF GRIZZLY INDUSTRIAL, INC. #DD7590 PRINTED IN CHINA



Figure 2. Assemble casters and vertical supports to bottom shelf.



Figure 3. Assemble the side supports to the vertical supports.



Figure 4. Set the tool box on top of the side supports and secure with screws, washers and nuts.



Figure 5. Details for assembly of the vertical support, the upper tray and the angle bracket.



Figure 6. Assemble the handle onto the side of the tool box.