



RP-9328



60-Watt Stereo System with Drawer-Load 3-CD Changer and Surround Sound Speakers

- 60 Watts of Total Power {30 Watts/ Channel RMS @ 10% THD, 1 kHz}
- 3-Disc Carousel Changer
- Multifunction 2-Color Vacuum Fluorescent Display
- Simultaneous Play-and-Load System
- Digital AM/FM/FM Stereo Tuning
- Electronic EQ/Bass Boost
- Program/Repeat/Shuffle/ATS™
- Dual-Cassette Recorder
- Full-Function Remote
- Two Surround Sound Speakers
- One-Year Limited Warranty*



RCA

Changing Entertainment. Again.™

RP-9328

General

- Dimensions:
Receiver
12¹/₄" H, 27" W, 13¹/₂" D
Surround Speakers
5" H, 6¹/₂" W, 5¹/₂" D
- One-Year Limited Warranty*

Power/Jacks

- 1/4" Stereo Headphone Jack
- Video in 1 {L & R Audio, RCA-Type}
- Main Speakers
- Surround Speakers
- FM Antenna
- AM Antenna

Tuner

- Digital AM/FM/FM Stereo Tuning
- Multifunction 2-Color Vacuum Fluorescent Display
- 32 Station Presets
- Automatic Preset Programming
- Seek Up
- Scan Up
- FM Mono/Stereo
- AM Loop Antenna
- FM Wire Antenna
- Real-Time Clock with Alarm and Wake-to-Music

Cassette Deck

- Dual-Cassette Operation
- Continuous Play
- Automatic End-of-Tape Shutoff
- Automatic Level Control {ALC}
- Six Push-Button Operation on Record Deck
 - Stop/Eject
 - Pause
 - Fast Forward
 - Rewind
 - Play
- Five Push-Button Operation on Play Deck
 - Stop/Eject
 - Pause
 - Fast Forward
 - Rewind
 - Play
- Record from Tuner, Tape, CD

Compact Disc



- 3-Disc Drawer-Load CD Changer
- Simultaneous Play-and-Load System
Allows you to change two discs while the third is still playing.
- Programmable 32-Track CD Memory
- 16-Track ATS™ {Auto/Track/Skip}
Allows for Programmable Track Skipping.
- Three-Way Repeat
 - Track
 - Disc
 - All
- Two-Way Shuffle
 - Disc
 - All
- Program Clear
- CD Intro
- CD Push-Button Controls
 - Play
 - Pause
 - Stop
 - Track Forward/Reverse
 - Scan Forward/Reverse
 - Disc Skip
- Full-Function Display
 - Shows Track
 - Time
 - Time Remaining
 - Time Elapsed
 - Repeat
 - Shuffle
 - Pause

Remote Control

- 24-Key Full-Function Remote
- Amplifier Functions
 - Power On/Off
 - Volume Up/Down
 - Function Select: Tuner, Tape, CD, Video
 - Mute
 - EQ Preset
- Tuner Functions
 - Tune Up/Down
 - Preset Up/Down
 - Seek
- CD Functions
 - Play
 - Pause
 - Stop
 - Track Forward
 - Track Reverse
 - Disc Skip
 - Repeat
 - Shuffle

Sound

- 60 Watts of Total Power
30 Watts/Channel RMS @ 10% THD, 1 kHz
- Two-Way Full-Range Speakers
 - 5¹/₄" Woofer
 - 2" Cone Tweeter
- Three-Band EQ System with Four Presets
 - Jazz
 - Pop
 - Rock
 - Flat
- Bass Boost
Enhances bass frequencies at low volume settings and provides fuller sound at any setting.
- Two Surround Sound Speakers



Changing Entertainment. Again.™

©1998 Thomson Consumer Electronics, Inc.
Get more information on RCA Consumer Electronics
Products at www.rca.com

*For complete details on warranties,
see your nearest RCA Dealer.

Form RP-9328

Trademark(s) ® Registered Marca(s) Registrada(s)
Photos and features subject to change without notice.
Illustration of product finish may vary from actual color.

PC10725