PRODUCT SPECIFICATIONS

• Partial QWERTY keyboard

FEATURES



Samsung SGH-t349

INFORMATION GUIDE



Vibrate Mode

*Many of the services and features described above are network dependent and may require additional subscription and/or usage charges. Not all features are available for purchase or use in all areas. Other conditions and restrictions apply. See carrier for more information. All talk and standby times are approximate. Battery performance depends on network configuration, signal strength, operating temperature, features selected, and voice, data, and other application usage patterns. Internet content/services designed for mobile devices.

The Samsung SGH-a657 supports Bluetooth® Profiles for wireless handsets, hands-free accessories, and object exchange. Both devices must be compatible with object exchange profile. Copyrighted material cannot he transferred

©2009 Samsung Telecommunications America, LLC ("Samsung"). Samsung is a registered trademark of Samsung Electronics America, Inc. and its related entities. Other company and product names mentioned herein may be trademarks of their respective owners. Screen images simulated

> https://training.samsungtelecom.com password: myfaves

SAMSUNG TELECOMMUNICATIONS AMERICA



Mixed Sources

Cert no. SW-COC-003300 www.fsc.org



Differentiator: Fast-and-easy Messaging Phone with Partial QWERTY keyboard

- XT9 predictive text which takes the magic of T9 predictive text and takes it up a notch improving letter prediction to make it fast and effortless to text.
- Multiple messaging options including email, instant message, picture messaging, video messaging and text messaging.
- One-touch access to your favorite messaging function with the messaging shortcut key.
- New simplified circle menu style which is easy to use with friendly graphics and succinct menu description text.
- Popular email client options, such as AIM[®], AOL[®] Yahoo![®] and Gmail[™].
- Both microSD[™] and Secure Digital High-Capacity (SDHC) memory cards are supported up to 4GB, and both are hot-swappable.









1301 E. Lookout Drive | Richardson, TX 75082 | 1.800.SAMSUNG

BUTTON MAP



WHY SAMSUNG?

ABOUT SAMSUNG ELECTRONICS

Samsung Electronics Co., Ltd. is a global leader in semiconductor, telecommunication, digital media and digital convergence technologies with 2007 consolidated sales of US\$105 billion. Employing approximately 150,000 people in 134 offices in 62 countries, the company consists of two main business units: Digital Media & Communications and Device Solutions. Recognized as one of the fastest growing global brands, Samsung Electronics is a leading producer of digital TVs, memory chips, mobile phones and TFT-LCDs. For more information, please visit www.samsung.com.

TIPS & TRICKS

TIP #1: USING THE PARTIAL QWERTY KEYBOARD

The partial QWERTY keyboard combines letters on the keys to conserve space; for example, QW share a key. If you send a lot of termessages, use the XT9 mode which has built-in shortcuts to entering your message. Simply begin to type your text using the part QWERTY keyboard, and the t349 will complete your words by calculating the words you are typing. With the XT9 predictive text, you or need to press the keys once, instead of double-clicking. If you are n in the XT9 mode, press the key to get the first letter and double-click the key to get the second letter.

TIP #2: PERIODS, HYPHENS AND SPECIAL SYMBOLS

To access punctuation marks and symbols, press the Shift key in the lower right of the keypad, next to the Enter key. This key controls the use of capital and lower-case letters. To access symbols, use the Al key plus the Sym/Z/X key. This process is faster and more intuitive the XT9 mode.

TIP #3: INSTANT ACCESS TO CONTACTS

When on the home screen, simply press the lower edge of the nav gation button as you would to scroll down. Your contact list will appear on the screen.

TIP #4: CAMERA SHORTCUTS

Press the button with the camera icon on the right side phone. A and take the picture using the same button (top side if you're hold the camera horizontally). To use the camera's 4x digital zoom featur press the volume control buttons to zoom in or out, then snap you photo.

TIP #5: USING REGULAR microSD[™] CARD

The Samsung t349 supports regular microSD[™] cards so you don't have to transfer all your files to new HD or SDHC cards. The t349 can support both the regular and new SDHC microSD[™] card up to a maximum of 4GB. Both cards are recognized automatically by your phone. You don't have to adjust anything to accommodate the older memory card.



KEYS

- The following list correlates to the illustrations.
- 1. EARPIECE/SPEAKER
- 2. MEMORY CARD SLOT
- 3. VOLUME KEYS
- 4. LEFT SOFT KEY
- 5. MESSAGING SHORTCUT KEY
- 6. SEND KEY
- 7. VOICEMAIL KEY
- 8. SHIFT KEY
- 9. NAVIGATION KEYS

10. OK (SELECT) KEY
 11. MICROPHONE
 12. POWER ON/OFF (EXIT) KEY
 13. CANCEL/CLEAR KEY
 14. RIGHT SOFT KEY
 15. CAMERA KEY
 15. CAMERA KEY
 16. DISPLAY
 17. POWER/ACCESSORY INTERFACE CONNECTOR



ihe m- est	 T-Mobile[®] HotSpot@HomeSM, launched in 2007. The Samsung Memoir[™] is the first 8.0-megapixel touch-screen camera phone to be available in the U.S in 2009.
of	
ore	
	TIP #6: USING THE PHONE FOR MASS STORAGE
n-	1. Press Menu > Settings > Personalize > Phone Settings >
ext	USB Mode.
er-	2. Select Mass Storage to use your phone as Mass Storage.
tial	This allows you to use your phone as a removable storage
cu-	device with your computer to store and upload files. When
nly	using your phone in Mass Storage mode, you won't be able
not	to connect to PC Studio.
ick	
	TIP #7: SEND PICTURE MESSAGE
	1. Select Menu > Messaging > Create Message.
	2. Enter the recipient's contact information
he	3. Type your message
he	4. Press the lower edge of the navigation button to access the
LT	icons at the bottom of the screen. Use the left and right
e in	navigation to select Add Picture.
	5. Select the file where the photo is stored and press OK. Scroll
	through the photos and press the soft key under Add. You can
	take a picture by selecting Camera instead of Add Picture.
vi-	Press the soft key for Add.
ap-	6. Press OK to Send your Picture Message. Separate charges
	may apply to send/receive domestic/international picture
	messages.
lim	TIP #8: SET UP EMAIL ADDRESS
ng	1. Press Menu > Messaging > Email.
re,	2. On the Email Set-up screen, choose your email service from
Dur	the list. If your service isn't listed, simply select More
	Accounts.
	3. Complete your email address and password.
n't	TIP #9: SET UP IM
n t 49	
49 D a	 Press Menu > Messaging > IM. On the IM Set-up screen, choose your IM service among AIM[®],
our	2. On the livi Set-up screen, choose your livi service among Alivi , Windows Live® and Yahoo!®.

• The Trace[™] by Samsung was the slimmest bar phone available in

• The Samsung t409 was one of the first mobile phones to support

the U.S. at time of launch in 2006.

3. Sign in with your information and password.