

Halo Lighting

INSTRUCTION SHEET

L2756P, L2756MB Framing Projector L256 Iris Control Accessory

Warning: Keep fixture away from combustible materials. Operate only in areas with proper ventilation around unit.

To Relamp -

Remove two screws in rear cover - remove cover. Pull forward on lamp retainer clip and pivot down. Pull lamp from socket - insert new lamp. Reposition lamp clip on bottom of lamp. Insert cover into housing - replace screws.

For Iris Accessory -

Remove two front cover screws and cover - take out shutter assembly. Place iris into round depression and install two screws. Before tightening screws down on iris, iris aperture must be adjusted as shown. Do not over tighten as binding may result. Tighten screws. Replace front cover and cover screws.

