Philips Audio cassette cleaner



SAC2500



Clean and protect your audio cassette player

This cassette head cleaner uses non-abrasive cloth tape and special cleaning fluid to gently clean away dust, dirt and oxide build-up without damaging the audio heads and pinch rollers.

Maintain original sound and video quality

· Special cleaning fluid removes dust, dirt and oxide build-up

Easy to use

• Simple operation as easy as playing a tape

Clean and protect your cassette player

· Non-abrasive cloth tape safely cleans the player's heads



Specifications

Technical specifications

• Contents: Cleaning fluid, 15ml

• Lifetime: 20x

Storage Media

• Supported formats: CD-Audio

Accessories

• User Manual: 14 languages

Packaging Data

Quantity: IEAN/UPC/GTIN: 87 1010198380 8

• Gross weight: .08 kg Tare weight: .02 kg Net weight: .06 kg
 Width: 108 mm • Height: 19 mm • Length: 197 mm

Outer Carton

• EAN/UPC/GTIN: 87 1010198382 2

• Quantity: 72

Gross weight: 7.3 kg

• Tare weight: .60 kg

• Net weight: 6.7 kg

Width: 215 mm · Height: 400 mm

· Length: 500 mm

Inner Carton

• EAN/UPC/GTIN: 87 1010198381 5

• Quantity: 6

Gross weight: .56 kg

Tare weight: .08 kg

Net weight: .48 kg

Width: I18 mm

· Height: 128 mm

· Length: 205 mm

Product highlights

Special cleaning fluid

This cleaning fluid is specially formulated to gently clean away dirt, dust and oxide build-up. Works with the nonabrasive cloth tape.

Non-abrasive cloth tape

Non-abrasive cloth tape gently travels across the player's heads, removing all dust, dirt and oxide build-up.

Simple operation

Simple operation as easy as playing a tape. Just apply fluid and "play".



Issue date 2007-08-31

Version: 2.0

© 2007 Koninklijke Philips Electronics N.V. All Rights reserved.

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

12 NC: 9082 100 09109 EAN: 87 10895 98380 8

www.philips.com