

Illus. No.	Part No.	DESCRIPTION
1	2300247	Literature Parts Use & Care Guide
	4344731	Wiring Diagram
2	4344664	Cover, Hole
3	4344662	Panel, Back
4	4344678	Socket, Light
5	4344702	Plug, Hole (6)
6	4344625	Switch, Light

Illus. No.	Part No.	DESCRIPTION
7	4344730	Pivot Post
8	4344693	Hinge, Upper
9	681582	Screw
10	4344680	Closer, Door
	4344681	Upper
	4344681	Lower
11	4344694	Hinge, Lower
12	4344663	Screw
13	4344734	Overlay Kit (Custom Wood Door)


Illus. No.	Part No.	DESCRIPTION
17		Cabinet (Not A Serviceable Part)
20	4344672	Knob, Control
22	4344667	Lens, Light
23	4344602	Light Bulb
24	4344670	Grille
25	4344635	Foot, Leveling (4)
26	4344673	Clip, Grille

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

DOOR AND SHELF PARTS

For Model: KUWO244PBL00

(Black)



Illus. No.	Part No.	DESCRIPTION
1	4344732	Door Assembly (Includes Gasket)
2	4344696	Gasket, Door
3	4344660	Clip
4	4344692	Wine Display Rack
5	4344686	Shelf, Wine (5)

Illus. No.	Part No.	DESCRIPTION
7	4344733	Plate, Pivot
10	4344710	Screw
14	4344709	Bracket, Door Switch
16	4344679	Evaporator
17	4344718	Channel, Drain


Illus. No.	Part No.	DESCRIPTION
18	4344719	Rivet, Push-In
19	4344720	Spacer
20	4344611	Funnel, Drain
21	4344722	Washer, Foam
22	4344723	Tube, Drain
23	4344724	Clamp

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

UNIT PARTS

For Model: KUWO244PBL00

(Black)



Illus. No.	Part No.	DESCRIPTION
1	4344688	Condenser
2	4344632	Blade, Fan
3	4344607	Switch, Door
4	4344631	Motor, Fan
5	4344689	Cord, Power
6	4344675	Bracket, Switch
7	4344655	Pan, Drain

Illus. No.	Part No.	DESCRIPTION
9	4344638	Relay, Starting
10	4344687	Overload
11	2208371	Cover, Terminal
12	2163786	Grommet (4)
13	4344621	Compressor (Includes Items 9, 10, 11 & 12)

Illus. No.	Part No.	DESCRIPTION
14	4344690	Thermostat
15	4344630	Drier Assembly
		REFRIGERANT CHARGE
		4.0 oz. (R-134)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST