

Brookstone®

Fogless Mirror

STAYS CLEAR SO YOU CAN GET
THE PERFECT SHAVE



BATTERY PRECAUTIONS


- Dispose of the old batteries properly. Do not dispose of the old batteries in a fire.
- Do not leave the batteries where a child or pet could play with or swallow them. If the batteries are swallowed, contact a physician immediately.
- The batteries may explode if mistreated. Do not attempt to recharge or disassemble the batteries.
- Use only fresh batteries of the required size and type. Do not mix old and new batteries, different types of batteries, or rechargeable batteries of different capacities.

CARE AND MAINTENANCE

- Use the SQUEEGEE on the bottom of the WATER RESERVOIR to wipe water off the mirror.
- Do not fully submerge Mirror in water.
- To avoid scratching, clean only with a soft, wet cloth or a non-abrasive household degreaser. Let mirror surface air dry.

LOCATION OF PARTS AND CONTROLS

1. Water Reservoir/Squeegee
2. Mirror
3. Vanity Lights (2)
4. Shaving Light
5. Vanity Light button
6. Shaving Light button
7. Suction Cup Attachments (3)
8. Battery Compartment Door
9. Lanyard
10. Suction Cups (3)
11. Razor Holder



Brookstone®

A WORLD OF INNOVATION

Since 1965, people have come to Brookstone to see what's new, discover smart solutions to everyday problems—and have some fun. At Brookstone, we believe there's always a better way to do things. And we created a world of innovation to prove it.

Merrimack, New Hampshire, USA 03054
800-846-3000 • Brookstone.com

841268

INSTALLING THE BATTERIES

1. Unscrew and remove the BATTERY COMPARTMENT DOOR.
2. Insert 4 AA batteries (not included) according to polarity indicators inside the battery compartment.
3. Replace the BATTERY COMPARTMENT DOOR and replace the screw securely to ensure a water-resistant seal.

SECURING THE MIRROR

USING THE SUCTION CUPS

Snap the SUCTION CUPS into the SUCTION CUP ATTACHMENTS. Press the Mirror firmly to a smooth, clean, non-porous surface. Moistening the SUCTION CUPS before mounting may provide a stronger hold. If the surface is tile, avoid placing the suction cups over grout.

USING THE LANYARD

Loop the ends of the LANYARD onto the ends of two of the SUCTION CUPS. Snap them into the outer SUCTION CUP ATTACHMENTS. Use the LANYARD to hang the Mirror.

USING THE MIRROR

1. Peel protective film from Mirror face before first use.
2. Remove the WATER RESERVOIR and use the SQUEEGEE on the bottom of the WATER RESERVOIR to wipe any water droplets or fog build up from the mirror.
3. Fill the WATER RESERVOIR with hot shower water. Replace the WATER RESERVOIR. Repeat as needed.
4. Press the VANITY LIGHT BUTTON once to turn the VANITY LIGHTS on. The lights will turn off automatically in 5 minutes, or press the VANITY LIGHT BUTTON again to turn the lights off manually.
5. Press the SHAVING LIGHT BUTTON once to turn the SHAVING LIGHT on. The light will turn off automatically in 5 minutes, or press the SHAVING LIGHT BUTTON again to turn the light off manually.

USING THE RAZOR HOLDER

Press the RAZOR HOLDER firmly to a smooth, clean, non-porous surface. Moistening the suction cup before mounting may provide a stronger hold. Place your razor in the holder.

ONE (1) YEAR LIMITED WARRANTY

Brookstone® warrants this product against defects in materials and/or workmanship under normal use for a period of ONE (1) YEAR from the date of purchase by the original purchaser ("Warranty Period"). If a defect arises and a valid claim is received within the Warranty Period, at its option, Brookstone will either 1) repair the defect at no charge, using new or refurbished replacement parts, or 2) replace the product with a new product that is at least functionally equivalent to the original product, or 3) provide a store credit in the amount of the purchase price of the original product. A replacement product or part, including a user-installable part installed in accordance with instructions provided by Brookstone, assumes the remaining warranty of the original product. When a product or part is exchanged, any replacement item becomes your property and the replaced item becomes Brookstone's property. When a store credit is given, the original product must be returned to Brookstone and becomes Brookstone's property.

Obtaining Service: To obtain warranty service, call Brookstone Limited Warranty Service at 1-800-292-9819. Please be prepared to describe the product that needs service and the nature of the problem. A purchase receipt is required. All repairs and replacements must be authorized in advance. Service options, parts availability and response times will vary. You are responsible for delivery and the cost of delivery of the product or any parts to the authorized service center for replacement, per our instructions.

Limits and Exclusions: Coverage under this Limited Warranty is limited to the United States of America, including the District of Columbia and the U.S. Territories of Guam, Puerto Rico, and the U.S. Virgin Islands. This Limited Warranty applies only to products manufactured for Brookstone that can be identified by the "Brookstone" trademark, trade name, or logo affixed to them or their packaging. The Limited Warranty does not apply to any non-Brookstone products. Manufacturers or suppliers other than Brookstone may provide their own

warranties to the purchaser, but Brookstone, in so far as permitted by law, provides these products "as is." This warranty does not apply to: a) damage caused by failure to follow instructions relating to product's use or the installation of components; b) damage caused by accident, abuse, misuse, fire, floods, earthquake or other external causes; c) damage caused by service performed by anyone who is not a representative of Brookstone; d) accessories used in conjunction with a covered product; e) a product or part that has been modified to alter functionality or capability; f) items intended to be periodically replaced by the purchaser during the normal life of the product including, without limitation, batteries or light bulbs; g) any product sold "as is" including, without limitation, floor demonstration models and refurbished items; or h) a product that is used commercially or for a commercial purpose.

BROOKSTONE SHALL NOT BE LIABLE FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES RESULTING FROM THE USE OF THIS PRODUCT, OR ARISING OUT OF ANY BREACH OF THIS WARRANTY. TO THE EXTENT PERMITTED BY APPLICABLE LAW, BROOKSTONE DISCLAIMS ANY AND ALL STATUTORY OR IMPLIED WARRANTIES, INCLUDING, WITHOUT LIMITATION, WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND WARRANTIES AGAINST HIDDEN OR LATENT DEFECTS. IF BROOKSTONE CANNOT LAWFULLY DISCLAIM STATUTORY OR IMPLIED WARRANTIES, THEN TO THE EXTENT PERMITTED BY LAW, ALL SUCH WARRANTIES SHALL BE LIMITED IN DURATION TO THE DURATION OF THIS EXPRESS WARRANTY.

Some states disallow the exclusion or limitation of incidental or consequential damages or how long an implied warranty lasts, so the above exclusions or limitations may not apply to you. This warranty gives you specific legal rights and you may also have other rights, which vary from state to state.