

Please read and keep this Owner's Guide and take the time to carefully read and follow the important Safety Instructions, Warranty and Contact information.

For additional information about your headphones or for replacement accessories, refer to:

- <http://global.bose.com>
- U.S. only: <http://Owners.Bose.com/QC20i>

Charging

Allow up to 2 hours for a full charge before first use. Use the supplied USB cable to connect the headphones to a powered USB port on your computer or an agency approved wall charger (not supplied). When fully charged, headphones will have about 15 hours of battery life.

Note: Before charging, be sure the headset is at room temperature, between 41°F (5°C) and 104°F (40°C).

Components

- A. Control module
- B. In-line microphone and 3-button remote
- C. Charging clip
- D. StayHear+™ tips: Small (white), Medium, Installed (gray), Large (black)
- E. USB charging cable
- F. Carry case

Powering on

1 Slide the power switch on the control module to On. The headphones will turn on in Mode Cancelling, which reduces most sounds around you.

Note: When the power off, the headphones will still charge, which keeps them warm. For best quality audio, turn the power on.

Switching modes

Press the Mode button on the side of the remote to switch to another mode, which lets you hear some sounds around you, such as traffic noise.

Connecting to an Apple device

2 Connect the Bose® QuietComfort™ 20i headphones to the standard 3.5 mm headphone jack on your iPhone, iPod, or iPad.

The headphones come with an in-line microphone and 3-button remote for convenient control of connected Apple products.

Action	Headphone Control
Adjust volume	Press + or -
Play/Pause	Press and release Answer/End
Skip track	Press and release Answer/End twice quickly
Previous track	Press and release Answer/End three times quickly
Fast forward	Press Answer/End twice and hold
Reverse	Press Answer/End three times and hold
Answer or end a call	Press and release Answer/End
Switch to incoming call, put current call on hold	While on a call, press Answer/End once. Press and release again to end the call.
Switch to incoming call, end current call	While on a call, press Answer/End and hold for about 2 seconds and release.
Use voice control	Press and hold Answer/End. The ridge on the control module is used for compatibility and usage information.

Note: Full controls may not be available for some Apple products.

Importance of Proper Fit

For effective noise reduction performance, it is important to choose the correct size StayHear+™ tip. Select the size that gives you the best comfort and seal in each ear. You may need to try all three sizes to determine the best fit.

To test fit, try speaking aloud (with the power off). Your voice should sound muffled in both ears. If not, select another tip size.

Each tip is marked with either an L or an R. Be sure to attach the left tip (L) to the left earpiece and the right tip (R) to the right earpiece.

To change a StayHear+™ tip

1 Gently peel the edges of the attached tip away from the earpiece using the edge of the case cap.

CAUTION: To prevent damage, do not pull on the tip wiring.

4 Fitting the headphones to your ear

1 Insert the headphone into the ear so the tip gently rests in the opening of the ear canal.

2 Tilt the headphone back and lightly press the wing under the ear until it is comfortable and secure. The tip should sit comfortably yet securely in the bowl of the ear.

Recognizing the lights

Color	Status while in use:	Status while charging:
Green (solid)	Power on. More than 3 hours of battery life remaining.	Charging complete
Green (blinking)	Power on. Less than 3 hours of battery life remaining.	N/A
Amber (blinking)	N/A	Charging Error. See "Temperature range" for more information.
None (Off)	Power off or battery depleted.	N/A

Lampernes betydning

Farve	Status under brug:	Status under opladning:
Grøn (fast)	Der er tændt for strømmen. Mere end 3 timer batteritid tilbage.	Opladning færdiggjort
Grøn (blinkende)	Der er tændt for strømmen. Mindre end 3 timer batteritid tilbage.	N/A
Rød	N/A	Charging Error. See "Temperature range" for more information.
None (Off)	Power off or battery depleted.	N/A

Troubleshooting

Power sound quality

Make sure the headphones are powered on and securely plugged into the headphone jack on the Apple device.

- Try another StayHear+™ tip size.
- Try another Apple device or music application.
- Clean the connector with isopropyl alcohol and dry with a clean cloth.
- If you are using the buds, turn off the power switch.

Clear or no noise reduction

- Make sure the power is switched on and the Mode indicator is on (green).
- Try another StayHear+™ tip size. See "Importance of Proper Fit."
- Ensure that headphones are properly charged.

Short battery life (less than 16 hours)

- When charging, be sure both ends of the USB cable are firmly connected and verify that the Battery Indicator is blinking amber.

Technical information

Temperature range

Operate and store this product within the temperature range of 4°F to 113°F (-20°C to 45°C) only.

For use with:

The remote mic is supported only by iPhone 3GS or later, iPad, iPod touch (2nd generation or later), iPod classic (120GB, 160GB), and iPod nano (4th generation or later). The remote is supported by iPhone 3GS or later, iPod nano (4th generation or later), iPod classic (120GB, 160GB), and iPod nano (4th generation or later). Audio is supported by all iPad and iPod models.

Apple, iPad, iPhone, iPod, iPod classic, iPod nano, iPod shuffle, and iPod touch are trademarks of Apple Inc., registered in the U.S. and other countries.

"Made for iPod," "Made for iPhone," and "Made for iPad" mean an electronic accessory has been designed to connect specifically to iPod, iPhone, or iPad, respectively, and has been certified by the developer to meet Apple Performance Standards.


Headphones are not responsible for the device or its compliance with safety and regulatory standards. Please note that the use of this accessory with iPod, iPhone or iPad may affect wireless performance.

Serial number (on Warranty Card):

Now is a good time to register your headphones. You can do this easily going to:

<http://global.bose.com/register>

©2013 Bose Corporation. No part of this work may be reproduced, modified, distributed, or otherwise used without prior written permission.



Please read and keep this Owner's Guide and take the time to carefully read and follow the important Safety Instructions, Warranty and Contact information.

For additional information about your headphones or for replacement accessories, refer to:

- <http://global.bose.com>
- U.S. only: <http://Owners.Bose.com/QC20i>

Oppladning

Brug 2 timer på en full opladning inden høretelefonerne bruges for første gang. Brug det medfølgende USB-kabel til at tilslutte høretelefonerne til en strømtilførsel-USB-port på din computer eller en godkendt vægoplader (medfølger ikke). Når høretelefonerne er helt opladede, vil høretelefonerne have ca. 15 timers batterilevetid.

Note: Før opladning, sørg for at hovedsettet er ved stuetemperatur, mellem 5°C og 40°C.

Komponenter

- A. Kontrolmodulet
- B. In-line-mikrofon og fjernbetjening med 3 knapper
- C. Opladningsklemme
- D. StayHear+™ indstater: Små (hvide), Medium, Installeret (grå), Store (sorte)
- E. USB-opladerkabel
- F. Bærersækk

Sådan tændes høretelefonerne

1 Flyt tænd/sluk-knappen på kontrolmodulet til On. Høretelefonerne vil tændes i Modus Cancelling, som reducerer de fleste lyde omkring dig.

Note: Når du slukker for strømmen, vil høretelefonerne fortsætte med at oplade, hvilket holder dem varme. For bedste lyd kvalitet, tænd strømmen for at få den bedste lyd kvalitet.

Skift mellem tilstandene

Tryk på tilstandsknappen på siden af fjernbetjening for at skifte til Opsamlings tilstand, hvor du kan høre nogle lyde omkring dig, f.eks. trafiklyde.

Tilslutning til en Apple-enhed

2 Tilslut Bose® QuietComfort™ 20i høretelefonerne til standard 3,5 mm høretelefonstik på din iPhone, iPod eller iPad.

Høretelefonerne kommer med en in-line mikrofon og en fjernbetjening med 3-knaps remote for nem kontrol af tilsluttede Apple-produkter.

Handling	Hovedtelefonbetjening
Justér lydstyrken	Tryk på + eller -
Åb/luk/afspil	Tryk på svar/slut-tast og slip den hurtigt
Skip track	Tryk på og slip svar/slut-tast hurtig
Forrige nummer	Tryk på og slip svar/slut-tast hurtig tre gange
Spol frem	Tryk på og slip svar/slut-tast hurtig to gange
Spol tilbage	Tryk på og slip svar/slut-tast hurtig to gange
Besvar eller afslut et kald	Tryk på svar/slut-tast og slip den
Ignorér en indgående opkald	Tryk på svar/slut-tast og hold den
Skift til indgående opkald, afslut et kald	Tryk på svar/slut-tast og hold den i ca. 2 sekunder og slip den
Skift til indgående opkald, afslut et kald	Tryk på svar/slut-tast og hold den i ca. 2 sekunder og slip den

Note: Full controls may not be available for some Apple products.

Importance of Proper Fit

For effective noise reduction performance, it is important to choose the correct size StayHear+™ tip. Select the size that gives you the best comfort and seal in each ear. You may need to try all three sizes to determine the best fit.

To test fit, try speaking aloud (with the power off). Your voice should sound muffled in both ears. If not, select another tip size.

Each tip is marked with either an L or an R. Be sure to attach the left tip (L) to the left earpiece and the right tip (R) to the right earpiece.

To change a StayHear+™ tip

1 Gently peel the edges of the attached tip away from the earpiece using the edge of the case cap.

CAUTION: To prevent damage, do not pull on the tip wiring.

4 Fitting the headphones to your ear

1 Insert the headphone into the ear so the tip gently rests in the opening of the ear canal.

2 Tilt the headphone back and lightly press the wing under the ear until it is comfortable and secure. The tip should sit comfortably yet securely in the bowl of the ear.

Recognizing the lights

Color	Status while in use:	Status while charging:
Green (solid)	Power on. More than 3 hours of battery life remaining.	Charging complete
Green (blinking)	Power on. Less than 3 hours of battery life remaining.	N/A
Amber (blinking)	N/A	Charging Error. See "Temperature range" for more information.
None (Off)	Power off or battery depleted.	N/A

Lampernes betydning

Farve	Status under brug:	Status under opladning:
Grøn (fast)	Der er tændt for strømmen. Mere end 3 timer batteritid tilbage.	Opladning færdiggjort
Grøn (blinkende)	Der er tændt for strømmen. Mindre end 3 timer batteritid tilbage.	N/A
Rød	N/A	Charging Error. See "Temperature range" for more information.
None (Off)	Power off or battery depleted.	N/A

Troubleshooting

Power sound quality

Make sure the headphones are powered on and securely plugged into the headphone jack on the Apple device.

- Try another StayHear+™ tip size.
- Try another Apple device or music application.
- Clean the connector with isopropyl alcohol and dry with a clean cloth.
- If you are using the buds, turn off the power switch.

Clear or no noise reduction

- Make sure the power is switched on and the Mode indicator is on (green).
- Try another StayHear+™ tip size. See "Importance of Proper Fit."
- Ensure that headphones are properly charged.

Short battery life (less than 16 hours)

- When charging, be sure both ends of the USB cable are firmly connected and verify that the Battery Indicator is blinking amber.

Technical information

Temperature range

Operate and store this product within the temperature range of 4°F to 113°F (-20°C to 45°C) only.

For use with:

The remote mic is supported only by iPhone 3GS or later, iPad, iPod touch (2nd generation or later), iPod classic (120GB, 160GB), and iPod nano (4th generation or later). The remote is supported by iPhone 3GS or later, iPod nano (4th generation or later), iPod classic (120GB, 160GB), and iPod nano (4th generation or later). Audio is supported by all iPad and iPod models.

Apple, iPad, iPhone, iPod, iPod classic, iPod nano, iPod shuffle, and iPod touch are trademarks of Apple Inc., registered in the U.S. and other countries.

"Made for iPod," "Made for iPhone," and "Made for iPad" mean an electronic accessory has been designed to connect specifically to iPod, iPhone, or iPad, respectively, and has been certified by the developer to meet Apple Performance Standards.


Headphones are not responsible for the device or its compliance with safety and regulatory standards. Please note that the use of this accessory with iPod, iPhone or iPad may affect wireless performance.

Serial number (on Warranty Card):

Now is a good time to register your headphones. You can do this easily going to:

<http://global.bose.com/register>

©2013 Bose Corporation. No part of this work may be reproduced, modified, distributed, or otherwise used without prior written permission.



Please read and keep this Owner's Guide and take the time to carefully read and follow the important Safety Instructions, Warranty and Contact information.

For additional information about your headphones or for replacement accessories, refer to:

- <http://global.bose.com>
- U.S. only: <http://Owners.Bose.com/QC20i>

Oppladning

Brug 2 timer på en full opladning inden høretelefonerne bruges for første gang. Brug det medfølgende USB-kabel til at tilslutte høretelefonerne til en strømtilførsel-USB-port på din computer eller en godkendt vægoplader (medfølger ikke). Når høretelefonerne er helt opladede, vil høretelefonerne have ca. 15 timers batterilevetid.

Note: Før opladning, sørg for at hovedsettet er ved stuetemperatur, mellem 5°C og 40°C.

Komponenter

- A. Kontrolmodulet
- B. In-line-mikrofon og fjernbetjening med 3 knapper
- C. Opladningsklemme
- D. StayHear+™ indstater: Små (hvide), Medium, Installeret (grå), Store (sorte)
- E. USB-opladerkabel
- F. Bærersækk

Sådan tændes høretelefonerne

1 Flyt tænd/sluk-knappen på kontrolmodulet til On. Høretelefonerne vil tændes i Modus Cancelling, som reducerer de fleste lyde omkring dig.

Note: Når du slukker for strømmen, vil høretelefonerne fortsætte med at oplade, hvilket holder dem varme. For bedste lyd kvalitet, tænd strømmen for at få den bedste lyd kvalitet.

Skift mellem tilstandene

Tryk på tilstandsknappen på siden af fjernbetjening for at skifte til Opsamlings tilstand, hvor du kan høre nogle lyde omkring dig, f.eks. trafiklyde.

Tilslutning til en Apple-enhed

2 Tilslut Bose® QuietComfort™ 20i høretelefonerne til standard 3,5 mm høretelefonstik på din iPhone, iPod eller iPad.

Høretelefonerne kommer med en in-line mikrofon og en fjernbetjening med 3-knaps remote for nem kontrol af tilsluttede Apple-produkter.

Handling	Hovedtelefonbetjening
Justér lydstyrken	Tryk på + eller -
Åb/luk/afspil	Tryk på svar/slut-tast og slip den hurtigt
Skip track	Tryk på og slip svar/slut-tast hurtig
Forrige nummer	Tryk på og slip svar/slut-tast hurtig tre gange
Spol frem	Tryk på og slip svar/slut-tast hurtig to gange
Spol tilbage	Tryk på og slip svar/slut-tast hurtig to gange
Besvar eller afslut et kald	Tryk på svar/slut-tast og slip den
Ignorér en indgående opkald	Tryk på svar/slut-tast og hold den
Skift til indgående opkald, afslut et kald	Tryk på svar/slut-tast og hold den i ca. 2 sekunder og slip den
Skift til indgående opkald, afslut et kald	Tryk på svar/slut-tast og hold den i ca. 2 sekunder og slip den

Note: Full controls may not be available for some Apple products.

Importance of Proper Fit

For effective noise reduction performance, it is important to choose the correct size StayHear+™ tip. Select the size that gives you the best comfort and seal in each ear. You may need to try all three sizes to determine the best fit.

To test fit, try speaking aloud (with the power off). Your voice should sound muffled in both ears. If not, select another tip size.

Each tip is marked with either an L or an R. Be sure to attach the left tip (L) to the left earpiece and the right tip (R) to the right earpiece.

To change a StayHear+™ tip

1 Gently peel the edges of the attached tip away from the earpiece using the edge of the case cap.

CAUTION: To prevent damage, do not pull on the tip wiring.

4 Fitting the headphones to your ear

1 Insert the headphone into the ear so the tip gently rests in the opening of the ear canal.

2 Tilt the headphone back and lightly press the wing under the ear until it is comfortable and secure. The tip should sit comfortably yet securely in the bowl of the ear.

Recognizing the lights

Color	Status while in use:	Status while charging:
Green (solid)	Power on. More than 3 hours of battery life remaining.	Charging complete
Green (blinking)	Power on. Less than 3 hours of battery life remaining.	N/A
Amber (blinking)	N/A	Charging Error. See "Temperature range" for more information.
None (Off)	Power off or battery depleted.	N/A

Lampernes betydning

Farve	Status under brug:	Status under opladning:
Grøn (fast)	Der er tændt for strømmen. Mere end 3 timer batteritid tilbage.	Opladning færdiggjort
Grøn (blinkende)	Der er tændt for strømmen. Mindre end 3 timer batteritid tilbage.	N/A
Rød	N/A	Charging Error. See "Temperature range" for more information.
None (Off)	Power off or battery depleted.	N/A

Troubleshooting

Power sound quality

Make sure the headphones are powered on and securely plugged into the headphone jack on the Apple device.

- Try another StayHear+™ tip size.
- Try another Apple device or music application.
- Clean the connector with isopropyl alcohol and dry with a clean cloth.
- If you are using the buds, turn off the power switch.

Clear or no noise reduction

- Make sure the power is switched on and the Mode indicator is on (green).
- Try another StayHear+™ tip size. See "Importance of Proper Fit."
- Ensure that headphones are properly charged.

Short battery life (less than 16 hours)

- When charging, be sure both ends of the USB cable are firmly connected and verify that the Battery Indicator is blinking amber.

Technical information

Temperature range

Operate and store this product within the temperature range of 4°F to 113°F (-20°C to 45°C) only.

For use with:

The remote mic is supported only by iPhone 3GS or later, iPad, iPod touch (2nd generation or later), iPod classic (120GB, 160GB), and iPod nano (4th generation or later). The remote is supported by iPhone 3GS or later, iPod nano (4th generation or later), iPod classic (120GB, 160GB), and iPod nano (4th generation or later). Audio is supported by all iPad and iPod models.

Apple, iPad, iPhone, iPod, iPod classic, iPod nano, iPod shuffle, and iPod touch are trademarks of Apple Inc., registered in the U.S. and other countries.

"Made for iPod," "Made for iPhone," and "Made for iPad" mean an electronic accessory has been designed to connect specifically to iPod, iPhone, or iPad, respectively, and has been certified by the developer to meet Apple Performance Standards.


Headphones are not responsible for the device or its compliance with safety and regulatory standards. Please note that the use of this accessory with iPod, iPhone or iPad may affect wireless performance.

Serial number (on Warranty Card):

Now is a good time to register your headphones. You can do this easily going to:

<http://global.bose.com/register>

©2013 Bose Corporation. No part of this work may be reproduced, modified, distributed, or otherwise used without prior written permission.



Please read and keep this Owner's Guide and take the time to carefully read and follow the important Safety Instructions, Warranty and Contact information.

For additional information about your headphones or for replacement accessories, refer to:

- <http://global.bose.com>
- U.S. only: <http://Owners.Bose.com/QC20i>

Oppladning

Brug 2 timer på en full opladning inden høretelefonerne bruges for første gang. Brug det medfølgende USB-kabel til at tilslutte høretelefonerne til en strømtilførsel-USB-port på din computer eller en godkendt vægoplader (medfølger ikke). Når høretelefonerne er helt opladede, vil høretelefonerne have ca. 15 timers batterilevetid.

Note: Før opladning, sørg for at hovedsettet er ved stuetemperatur, mellem 5°C og 40°C.

Komponenter

- A. Kontrolmodulet
- B. In-line-mikrofon og fjernbetjening med 3 knapper
- C. Opladningsklemme
- D. StayHear+™ indstater: Små (hvide), Medium, Installeret (grå), Store (sorte)
- E. USB-opladerkabel
- F. Bærersækk

Sådan tændes høretelefonerne

1 Flyt tænd/sluk-knappen på kontrolmodulet til On. Høretelefonerne vil tændes i Modus Cancelling, som reducerer de fleste lyde omkring dig.

Note: Når du slukker for strømmen, vil høretelefonerne fortsætte med at oplade, hvilket holder dem varme. For bedste lyd kvalitet, tænd strømmen for at få den bedste lyd kvalitet.

Skift mellem tilstandene

Tryk på tilstandsknappen på siden af fjernbetjening for at skifte til Opsamlings tilstand, hvor du kan høre nogle lyde omkring dig, f.eks. trafiklyde.

Tilslutning til en Apple-enhed

2 Tilslut Bose® QuietComfort™ 20i høretelefonerne til standard 3,5 mm høretelefonstik på din iPhone, iPod eller iPad.

Høretelefonerne kommer med en in-line mikrofon og en fjernbetjening med 3-knaps remote for nem kontrol af tilsluttede Apple-produkter.

Handling	Hovedtelefonbetjening
Justér lydstyrken	Tryk på + eller -
Åb/luk/afspil	Tryk på svar/slut-tast og slip den hurtigt
Skip track	Tryk på og slip svar/slut-tast hurtig
Forrige nummer	Tryk på og slip svar/slut-tast hurtig tre gange
Spol frem	Tryk på og slip svar/slut-tast hurtig to gange
Spol tilbage	