Stowaway® Travel Mouse
Owner's Manual
For
Microsoft® Pocket PC / Windows Mobile™ 2003
Apple Macintosh OS X
and
Microsoft® Windows XP

Includes:

Asus MyPal A620BT	iPAQ 4150
Dell Axim x30	iPAQ 4155
Dell Axim x3i	iPAQ 4350
iPAQ 1945	iPAQ 4355
iPAQ 2210	iPAQ 5450
iPAQ 2215	XDA II

Mouse/Keyboard Driver:

Stowaway 4.0

Table of Contents

Installing the Mouse with Macintosh OS X

Before You Begin

➢ Determine that your Macintosh is Bluetooth-enabled with either a built-in Bluetooth component, or via an external hardware adaptor (Dongle).

➢ Ensure that the accompanying Bluetooth software (Stack) is installed.

➢ **It is not necessary to disable or remove your existing mouse software.** (Refer to the User's Guide included with your Macintosh with any questions on your current mouse.)

➢ Insert the 2 AAA batteries (included) beneath the battery cover of the Stowaway Travel Mouse.

Creating a Paired Connection with your Macintosh

1. Install the Bluetooth Dongle, if necessary, and launch the accompanying Bluetooth Setup Assistant on your Macintosh.

2. Refer to the instructions included with the Bluetooth Setup Assistant on the process for Pairing Devices.

3. Power on the Stowaway Travel Mouse and press its Discoverable button to make it detectable by the Bluetooth software on your Macintosh.

4. Begin device detection for the mouse with the Bluetooth Setup Assistant, and locate the Stowaway Travel Mouse among any found devices.

5. Select the Bluetooth mouse in the list of discovered devices to create a link to your Macintosh.

6. After the mouse is successfully linked with your Macintosh, the mouse pointer will immediately begin responding to movement and button presses, similar to your standard mouse. Refer to the User Guide for your Macintosh to modify mouse functionality within the Macintosh Operating System.

Installing the Mouse for Use with Windows XP

Before You Begin

➢ Determine that your PC is Bluetooth-enabled with either a built-in Bluetooth component, or via an external hardware adaptor (Dongle).

➢ Ensure that the accompanying Bluetooth software (Stack) is installed.

➢ **It is not necessary to disable or remove your existing mouse software.** (Refer to the User's Guide included with your PC with any questions on your current mouse.)

➢ Insert the 2 AAA batteries (included) beneath the battery cover of the Stowaway Bluetooth mouse.

Creating a Paired Connection with your PC

1. Install the Bluetooth Dongle, if necessary, and launch the accompanying Bluetooth software on your PC.

2. Refer to the instructions included with your Bluetooth software on the process for Pairing Devices.

3. Power on the Stowaway Travel Mouse and press its Discoverable button to make it detectable by the Bluetooth software on your PC.

4. Begin a device detection, and locate the Stowaway Travel Mouse among any found devices.

5. Establish a link between the computer and the Stowaway Travel Mouse. (Refer to the User Guide included with your Bluetooth software for instructions on how to do this.)

6. After the mouse is successfully linked with your PC, the mouse pointer will immediately begin responding to movement and button presses, similar to your standard mouse. Refer to the User Guide for your PC on the Windows Control Panel Mouse applet to modify mouse functionality within Windows.

NOTE: The remainder of this document primarily addresses the Stowaway Travel Mouse for use with Pocket PC / Windows Mobile2003-enabled PDAs.

Installing and Configuring the Mouse for PPC

Before You Begin

Before you install the Stowaway keyboard and mouse software for Windows Mobile 2003-compatible PDAs:

➢ **Disable or remove any other keyboard/mouse applications that you have previously installed on your Pocket PC device.** (Refer to the User's Guide included with your Pocket PC device for instruction on how to do this.)

➢ Ensure there is at least 400 KB of memory on your Pocket PC device. To check the available memory, tap Start =>Settings=>System=>Memory.

➢ Insert the 2 AAA batteries (included) beneath the battery cover of the Stowaway Travel Mouse.

Installing the Software

1. Connect your Pocket PC device to a computer using the docking cradle or sync cable.

2. Establish a connection between the computer and your Pocket PC device using ActiveSync® and then backup the data stored on the Pocket PC device. (Refer to the User Guide included with your Pocket PC device for instructions on how to do this.)

3. Insert the CD enclosed with your mouse and follow the on-screen instructions to successfully install the software.

4. Tap the on-screen button to reset your Pocket PC device to complete the installation.

5. After the driver is successfully installed and the Pocket PC device is reset, the keyboard and mouse driver icons will show up in the *Programs* window.

Stowaway Keyboard   Stowaway Travel Mouse

NOTE: The Bluetooth connection between the PDA and keyboard must be set up through the Stowaway keyboard/mouse driver.

Configuring the Mouse to Your Pocket PC Device

1. After the driver installation completes, the *Stowaway Settings* screen will display and you will be prompted to *Choose device to setup*. Select the *Stowaway Travel Mouse* and tap *Setup*.

2. The *Select mouse pointer mode* screen will display for selecting Enhanced or Safe pointer mode:
   a. *Enhanced* mode – Works for most PDAs. Try Enhanced mode first.
   b. *Safe* mode – In the event that display issues arise with Enhanced mode, select Safe mode. It works for all PDAs, but may leave pointer traces on display.

   Prior to selecting a mode, you may want to synchronize your PDA to back up your data.

3. Select *Yes* at the next screen to reset the PDA and apply the pointer mode.

4. Once the PDA resets, the *Confirm mouse pointer mode* screen will display. If the PDA display is working properly, accept Enhanced mode by selecting *Enhanced* again, and tapping *OK*. Otherwise, select *Safe* and tap *OK*.

5. The *Bluetooth mouse status* screen will open, stating that *Connection is not set up*. You may also open this page by selecting the *Connection* tab of the Stowaway Travel Mouse application. You can begin a connection to the mouse and view the status of a connection from this screen. Make sure the mouse is *Discoverable*. To do this, press the Discoverable button on the underside of the mouse (Please refer to your Getting Started Guide for detailed instruction).
   NOTE: After the initial installation, the *Mouse settings* screen is opened automatically.

6. Then tap the *Connect* button on the screen. The status will read *Scanning for a mouse*, and *Initializing connection.* During the initialization stage, the application starts the Pocket PC Bluetooth system software, known as the *Bluetooth Stack*.

7. Once a mouse is detected, the application will begin *Verifying connection* by prompting you to move the mouse and click in the red box provided. This will verify that the correct mouse is being connected to your PDA. If you cannot use the mouse to click in the red box, tap *Disable* with the stylus and begin the connection again.

8. If the connection process is successful, the **Mouse connection enabled** message will display on the Pocket PC device. This is the normal mode for wireless communication between the Stowaway Travel Mouse and the Pocket PC device during use.

9. In the event that several Stowaway Bluetooth mice (or BT keyboards) happen to be nearby and in **Discoverable** mode, the scan will display all of these devices in the list. Compare the ID (Bluetooth address) of the device you're using and select it from the list.

10. Tap **Connect** to connect to the selected keyboard. .Move the pointer and click in the red box. This will verify that the correct mouse is being connected to your PDA. If you cannot use the mouse to click in the red box, tap **Scan** with the stylus and begin scanning for a mouse again.

11. If the Bluetooth scan or connection fails, ensure the mouse is Discoverable and tap *Connect* again. If the connection still fails:

a. Power cycle the mouse, make it Discoverable, and tap *Connect*.

b. Or, reset the PDA, make the mouse discoverable, and tap *Connect*.

c. If neither step works, check/replace the mouse batteries, and/or charge the PDA battery.

12. If the mouse has previously been connected with your Pocket PC but you have pressed the Discoverable mode button during normal use, the mouse will lose its bond with your handheld device. Tap *Connect* to reestablish the bond.

13. The *Bluetooth Mouse status* screen also allows access to the *Advanced* page, where buttons are provided to select *Power efficient mode* and *Mouse Pointer* mode.

a. *Power efficient mode* – Allows you to enable the Stowaway Travel Mouse application to *Auto*-detect the proper power setting for your device combination (keyboard/mouse/PDA, etc.), or to turn *On* or *Off* Power efficient mode.

b. *Mouse pointer mode* – Most PDA displays work well with Enhanced mode. Some will require Safe mode for effective mouse pointer tracking and use.

14. The **Mouse Status Page** displays the mouse battery status. The three states of the battery are Normal, Low and Critical:
   a. **Normal** – This is the most common state of the battery.
   b. **Low** – This is a warning that the batteries have reached a threshold where they should be replaced soon.
   c. **Critical** – This means the batteries are in imminent danger of reaching a point where they will no longer function.

15. When the mouse batteries reach Low or Critical, a warning message will be displayed from the Caption Bar at the top of the display.

16. If the mouse driver fails to detect a supported Bluetooth stack during the initial setup or at a later time (e.g. after power on), it will display the **Bluetooth system not detected** message on the **Connection** page. This should not happen on Pocket PC devices with a built-in Widcomm stack version 1.4.x or later or Microsoft stack, since it is always present and is supported by the mouse software. However, if the device has an incompatible version of the stack, this message may be displayed or the software may function improperly. In this case the mouse software must be replaced with an updated version.

Reconnecting the Stowaway Travel Mouse

The above steps establish the Bluetooth wireless connection and bonding between the Pocket PC device and the mouse for the first time. The Mouse pointer should display and be enabled as long as the connection is maintained.

Despite a high degree of reliability, the Bluetooth connection could break for many reasons:

➢ When the mouse is powered off, the mouse circuit will be powered off, and the Bluetooth connection will be lost.

➢ As a power saving feature, the mouse will be automatically powered down after an *idle period* (when there is no activity for approximately 5 minutes).

➢ When the Pocket PC device is turned off, the established Bluetooth connection will be lost.

➢ When the Pocket PC device and the mouse are moved away from each other beyond the wireless range (~10m), the previously established connection is lost.

When any of these conditions occurs, the connection will be lost and the software will switch to waiting mode. To restore the connection, make sure the mouse and Pocket PC device are powered on and in range, then press a mouse button. See Reconnecting and Bluetooth Accessibility for further details. The connection should be reestablished within 2-3 seconds but this may be delayed if the Bluetooth system on the Pocket PC device is busy. For example, after the Pocket PC device is powered on, it may take 10 or more seconds for the Bluetooth system to re-initialize.

Even when disconnected, the Pocket PC device and the mouse remain bonded. The mouse will only reconnect to the bonded Pocket PC device and the Pocket PC device will only listen to the bonded mouse. To break the bond, press the Discoverable button. Normally the bond will not need to be broken unless the mouse will be used with another Pocket PC device or another mouse will be used with the Pocket PC device. Therefore, please avoid pressing the Discoverable button during normal operation. If this has happened, you will have to establish a new connection as described in the Configuring the Mouse to Your Pocket PC Device section above.

Reconnecting and Bluetooth Accessibility

If your Stowaway Travel Mouse software returns to waiting mode, and pressing a mouse button will not trigger reconnection with the PDA, this may be because the Bluetooth stack is awaiting a signal only from a previously **paired device**, (such as if you had been using a Secured keyboard connection). If you want the convenience of not placing the mouse in **Discoverable mode** before every use, you will need to select **All devices** in the Bluetooth Settings applet. This will permit your Pocket PC to receive Bluetooth signals from unpaired devices, like the mouse. Note: Your Bluetooth screen may vary.

Each manufacturer's Bluetooth configuration screens differ, but generally you will find the *All devices* and *Paired devices only* options within the Bluetooth Settings under the Accessibility tab. This set of screens may be available directly via a Bluetooth icon on the Today screen, or from the Start Menu =>Settings=>Connections tab.

Customizing Mouse Functions

Once the mouse software is installed on the Pocket PC device, you may customize the options. A mouse icon ▧ will display in the lower right corner of the screen while using Calendar, Contacts, or other applications.

➢ Tap the mouse icon on the bottom toolbar to display the Mouse Control Panel.
➢ Tap the keyboard icon at the Mouse Control Panel to display the Input Method Toolbar.

Input Method Toolbar

There are four icons that appear on the Input Method Toolbar. This assumes that the *Stowaway Keyboard* input method is selected from the Input Methods menu (tap the up arrow to the right of the keyboard icon in the lower right corner of the display). The leftmost icon shows the state of the Stowaway Travel Mouse connection; there are three different states that can be indicated. A tap and hold on this icon will display a text message describing the state.

➢ This shows that the mouse connection is enabled.

➢ This shows that the connection is disabled or is waiting to reconnect.

➢ This shows that the connection failed or no mice were found.

The other three icons relate to other features of the keyboard/mouse driver.

➢ Tap this speaker icon to turn the keyboard clicking sounds on or off (for use, if a Stowaway keyboard is installed).

➢ Tap this keyboard icon to access the Keyboard Control Panel. This second keyboard icon appears above the keyboard icon that is visible in the lower right corner of the screen.

➢ Tap this help icon to access keyboard and mouse help topics and troubleshooting tips.

Mouse Control Panel

On the *Mouse* tab:

➢ Tap *Enable* to choose which device to enable (the next screen will allow you to select the *Stowaway Travel Mouse*). Tap *Disable* to turn off access to the mouse.
➢ To select *Button Assignments* for custom applications to launch, or functions to perform with each of the mouse buttons, tap the down-arrows following the *Left*, *Middle* and/or *Right* drop down lists.
➢ To **increase** mouse pointer speed, drag the *Mouse Speed* slider to the **right**.
➢ To **decrease** key repeat speed, drag the *Mouse Speed* slider to the **left**.
➢ To select whether or not the mouse icon will appear in the lower right corner of the Today screen, check or uncheck the *Show Icon on Today screen* option.

On the *Connection* tab:

The *Bluetooth mouse status* screen lists the mouse status, firmware version and mouse battery status. There are three buttons available from this screen:
   ➢ To start a Stowaway Travel Mouse connection, tap *Connect*.
   ➢ To disable an existing connection, tap or mouse click on *Disable*.
   ➢ To set Power efficient mode and Mouse pointer mode, tap or click on *Advanced*. This will open another screen where you can choose from Auto, On, or Off Power efficient mode, and Enhanced or Safe Mouse pointer mode. Help on these options is also available from the *Advanced* screen.

On the *About* tab:

➢ The *About* tab indicates the keyboard/mouse software version installed on your Pocket PC device.

Disabling the Stowaway Travel Mouse

When the Stowaway Travel Mouse is no longer needed, you can disable it by tapping the *Disable* button, on the *Connection* or *Mouse* page. The *Connection is not set up* message will then be displayed on the *Connection* page.

NOTE: Disabling the Stowaway Travel Mouse will not automatically turn off the Bluetooth radio. Conversely, turning the Bluetooth radio off while the Stowaway BT keyboard driver is still enabled will not work. Because of the behavior of the Bluetooth stack, the Bluetooth radio will automatically turn back on after a few seconds.

To re-enable the connection, tap the *Connect* button on the *Connection* page or tap *Enable* on the *Mouse* page. See [Configuring the Mouse to Your Pocket PC Device](#) for complete instructions.

Mouse Discoverable Mode

Discoverable mode is the state that allows the mouse to be detected by the Pocket PC device.

➢ To place the mouse in Discoverable mode, press the Discoverable button underneath the mouse. A green LED will light underneath the mouse to indicate it is Discoverable.

Device Pairing Overview

The Pocket PC and the Stowaway Travel Mouse share a *virtual cable*. This means there is a 1:1 relationship between the Pocket PC device and the mouse. During connection, the Pocket PC device searches the Bluetooth radio band until it finds the mouse. Once completed, each time the Pocket PC device and mouse are powered on within range of each other, the devices will be reconnected with a simple mouse click. Once connected, the mouse leaves Discoverable mode, and will not be detected by other devices. The Pocket PC device on the other hand will retain the ability to create new pairings with other devices, such as a Bluetooth keyboard.

Using the Stowaway Travel Mouse

Moving the Pointer/Highlighting Text

Using default mouse functions: Mouse movements and Mouse button clicks, you can easily navigate, position the cursor, and select text for subsequent editing functions. You may also customize mouse functionality with the Left, Middle and Right Button Assignment options via the Mouse tab:

To Perform/Navigate	Press
Mouse Click	Left mouse button (default)
Launch Mouse Settings	Middle mouse button (default)
Context Menu	Right mouse button (default)
Place text insertion point in text	Single Mouse Click
Select (highlight) Current Word	Double Mouse Click
Select (highlight) Current Paragraph	Triple Mouse Click
Select (highlight) any amount of text	Mouse Click, drag and release
Edit Text via Context Menu	Right Mouse Click, Mouse Click option
Scroll Up, Down, Left, or Right	Customize a button on Mouse tab

On-Screen Buttons and Application Launching

By customizing mouse button activities in the Stowaway Travel Mouse application, you can activate on-screen buttons such as (OK) or (X) and launch applications using the Left, Middle or Right mouse buttons. Note: Retain one mouse button for the Mouse Click, and customize the remaining two buttons via the *Mouse* tab. Following are a few of the tasks you can customize to mouse buttons:

On-Screen Button and Application Launching
OK/Close Window or Application
Open Start Menu
Launch Today Screen
Toggle Input Method Toolbar On/Off
Launch Mouse Settings
Launch Keyboard Settings
Launch Calendar
Launch Contacts
Launch Inbox
Launch Tasks
Launch Notes
Launch Word
Launch Excel
Launch Internet Explorer
Choose Data File (opens any file you choose)

Menu and Toolbar Navigation

You can access program menus, submenus, and toolbars with the Stowaway Travel Mouse using the following activities.

Action
To activate a program's menu bar at the bottom of the Pocket PC device screen and select a main menu item: • Mouse click on the menu title, then move the mouse and click on the menu item, or submenu you want to activate.
To access a program's toolbar at the top or bottom of the Pocket PC device screen: • Mouse click on the desired tool on the toolbar.

Frequently Asked Questions

Q: My mouse and handheld are in-range and powered on, why won't they reconnect after a mouse button press?

If Bluetooth Accessibility is set to *Paired devices only,* the mouse may not automatically reconnect. To allow the mouse to reconnect with a button press, change the default settings within the Bluetooth accessibility settings, see Reconnecting and Bluetooth Accessibility.

Q: What should I do when I try to use the mouse and nothing happens?

- Verify that the Pocket PC has an adequate battery charge.
- Verify that the Stowaway Travel Mouse batteries do not need replaced.
- Check to make sure that the keyboard/mouse software is installed properly according to the instructions.
- Check the *Connection* tab of the *Mouse Control Panel* to make sure the *Stowaway Travel Mouse* is enabled.
- Check the *Mouse* tab of the *Mouse Control Panel* to make sure you've selected the appropriate device type. After tapping *Enable*, you should select *Stowaway Travel Mouse*.
- Use the Mouse Help icon to launch the help.

Q: I tried to turn off the Bluetooth radio and it automatically turned back on, what should I do?

The Stowaway Travel Mouse must be disabled before the Bluetooth radio can be turned off. See the Disabling the Stowaway Travel Mouse section for more information.

Q: What is the Keyboard Control Panel for?

If you ever install a *Bluetooth wireless keyboard, Connected serial keyboard* or *Infrared wireless keyboard* via the *Config* tab of the *Keyboard Control Panel*, you will see a *BT*, *Serial* and/or *IR* tab added to the *Keyboard Control Panel* and corresponding icons added to the *Input Method Toolbar*. Even if you disable the keyboard(s) and only use the *Stowaway Travel Mouse*, the *BT*, *Serial* and/or *IR* tab and icons will remain. If you do not plan to need these options, you may choose to reinstall the driver and not enable them again so they will not display.

Q: I received an error message saying the keyboard/mouse driver cannot find a supported Bluetooth component, what should I do?

The current version of the keyboard/mouse driver supports Widcomm Bluetooth for Windows CE (BTW-CE) version 1.4.1 or later, and Microsoft stack version TBD. If you have a different version, you may need to check for upgrades for either the Bluetooth stack or for the mouse driver. (To determine the version of the Bluetooth stack installed on your Pocket PC device, locate the Bluetooth icon and tap it with the stylus to open the application. Find the Bluetooth About tab and tap to open the associated page. There you will find the version and build for the installed Bluetooth stack.)

Should the mouse driver find more than one Bluetooth component on your Pocket PC device (for example if you have Bluetooth built-in and a removable Bluetooth card), then a dialog box will be displayed with a choice of available components. You will need to choose the Bluetooth component that you wish to be used with the Bluetooth mouse and tap OK.

NOTE: Some Bluetooth components may not work with the mouse. If you are not able to connect to the mouse, you may have to return to the *Mouse* page, tap *Enable* again, select *Stowaway Travel Mouse*, tap *Setup*, and then select another Bluetooth component.

Q: My mouse was connected and input to Pocket PC device worked fine, but after a certain *idle period*, it seems that the connection was lost.

Refer to the Reconnecting the Stowaway Travel Mouse section.

Q: How do I uninstall the keyboard and mouse driver?

Select Start=>Settings=>System tab=>Remove Programs. Select *Stowaway Keyboard and Mouse Driver* from the list of applications then tap the *Remove* button.

Legal Notices

Think Outside shall not be liable for technical or editorial errors or omissions contained herein or for special, indirect, incidental or consequential damages whatsoever in connection with the furnishing, performance, or use of this material. The information in this document is provided "as is" without express or implied warranty of any kind, including, but not limited to, the implied warranties of merchantability and fitness for a particular purpose, and is subject to change without notice. The warranties for Think Outside products are set forth in the express limited warranty statements accompanying such products. Nothing herein should be construed as constituting an additional warranty. Think Outside assumes no responsibility for any loss or claims by third parties, which may arise through the use of this software. Think Outside does not warrant that the software will be error-free, nor that the software will run uninterrupted. Think Outside assumes no responsibility for any damage or loss caused by deletion of data as a result of malfunction, dead battery, or repairs. Be sure to make backup copies of all important data on other media to protect against data loss. Information in this document is subject to change without notice.
©2004 Think Outside, Inc. All rights reserved.

Reproduction of this document in any manner whatsoever without the written permission of Think Outside, Inc. is strictly forbidden.

Trademarks

Dell and Axim are trademarks of Dell Inc. WIDCOMM and the WIDCOMM logo are trademarks of WIDCOMM, Inc. Bluetooth and the Bluetooth logos are trademarks owned by Bluetooth SIG, Inc., U.S.A. and licensed to WIDCOMM, Inc. ActiveSync, Windows Mobile, Windows and Outlook are registered trademarks of Microsoft Corporation. Think Outside and Stowaway are registered trademarks of Think Outside Corporation. iPAQ is a registered trademark of Hewlett Packard Corporation in the United States and/or other countries. Other trademarks and trade names may used in this document to refer to either the entities claiming the marks and names or their products. No proprietary interest in other trademarks and trade names is claimed.

LICENSED SOFTWARE
© Copyright 2000 – 2004, WIDCOMM, Inc. ("WIDCOMM"). All rights reserved.
Warning: This software and accompanying documentation are protected by copyright law and international treaties. Unauthorized reproduction or distribution of this software, or any portion of it, may result in severe civil

and criminal penalties, and will be prosecuted to the maximum extent possible under the law.

Use of this software is governed by the terms of the end user license agreement that accompanies or is included with such software. Unless otherwise noted in the end user license agreement, or herein, no part of the documentation accompanying this software, whether provided in printed or electronic form may be reproduced in any form, or stored in a database or retrieval system, or transmitted in any form or by any means, or used to make any derivative work (such as translation, transformation, or adaptation) without the express, prior written consent of WIDCOMM.

Obtaining warranty service

Customer must contact Think Outside within the applicable warranty period to obtain warranty service authorization. Dated proof of original purchase will be required for warranty service, repair, or replacement. Products or parts shipped by Customer to Think Outside must be sent postage-paid and packaged appropriately for safe shipment. Think Outside is not responsible for Customer products received without a warranty service authorization and may be rejected. Repaired or replacement products will be shipped to Customer at Think Outside's expense. All products or parts that are replaced become the property of Think Outside. The repair and replacement process for products or parts in locations outside of the United States will vary depending on Customer's location.

Support@ThinkOutside.com

Think Outside
85 Saratoga Ave.
Suite 200
Santa Clara, CA 95051
USA
www.thinkoutside.com

Registering your product

To register your Stowaway Travel Mouse product, please visit www.thinkoutside.com/register and complete the online form.

Important Battery Information

- Keep batteries away from children.
- Do not mix batteries of different types or old and new batteries.
- Always replace old, weak or worn-out batteries promptly and recycle or dispose of them properly. Before inserting new batteries, the battery compartment should be cleaned. If fluid from the battery comes into contact with skin or clothes, flush with water immediately.
- Remove the batteries if the device will be inactive longer than a month.
- Do not open, puncture or otherwise damage the batteries.
- Do not use fire to dispose of batteries.

Released battery electrolyte is corrosive and can cause damage to the eyes and skin and may be toxic if swallowed.

Comfortable Mouse Use

Research suggests that physical discomfort and injury to nerves, tendons, and muscles may be related to repetitive motion, an improperly set up work area, incorrect body posture, and poor work habits.

To reduce the risk of injury, follow these precautions:

- Stand, stretch, and move around several times every hour.
- Every once in a while, work on a different task with your hands. Avoid repetitive motions. Use shortcut buttons to move efficiently and avoid repetitive, awkward movement.
- Relax your shoulders and keep your elbows at your sides. Adjust your work area so that you don't have to stretch to reach the mouse.
- Adjust your position so that you can avoid placing your wrists on a sharp edge.

If you feel discomfort of numbness in your hands, wrists, arms, shoulders, neck or back while typing, get the advice of a qualified medical professional.

Important notes about Bluetooth® devices

The Stowaway Bluetooth mouse can emit radio frequency (RF) energy whenever the batteries are installed and the power switch is turned on.. Care should be taken when used around medical devices or equipment. For specific information, consult with the product manufacturer or your physician before use. To stop interference, power off the mouse or remove its batteries.

The Stowaway Travel Mouse should not be used on any aircraft. Before boarding an aircraft, power off the mouse to ensure there is no RF transmission.

Regulatory Notices

Electromagnetic Interference (EMI) is any signal or emission, radiated In free space or conducted along power or signal leads, that endangers the functioning of radio navigation or other safety service or seriously degrades, obstructs, or repeatedly interrupts a licensed radio communication service. Radio communications services include but are not limited to AM/FM commercial broadcast, television, cellular services, radar, air-traffic control, pager, and Personal Communication Services (PCS). These licensed services, along with unintentional radiators such as digital devices, including computers, contribute to the electromagnetic environment.

Electromagnetic Compatibility is the ability of items of electronic equipment to function properly together in the electronic environment. While this mouse has been designed and determined to be compliant with regulatory agency limits for EMI, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause interference with radio communications services, which can be determined by turning the equipment off and on, you are encouraged to try to correct the interference by one or more of the following measures:

- Reorient the receiving antenna.
- Relocate the mouse with respect to the receiver.
- Move the mouse away from the receiver.

If necessary, consult a Technical Support representative or an experienced radio/television technician for additional suggestions.

FCC Notices (U.S. Only)

The Stowaway mice are classified by the Federal Communications Commission (FCC) as Class B digital devices.

Class B

This equipment has been tested and found to comply with the limits for a Class B digital device pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the manufacturer's instruction manual, may case interference with radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by

turning the equipment off and on, you are encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Consult the dealer or an experienced radio/television technician for help.

FCC Identification Information

The following information is provided on the device or devices covered in this document in compliance with FCC regulations:

- Model number(s):

  MSBT01

- Company name:

  Think Outside, Inc.
  85 Saratoga Ave. Suite 200
  Santa Clara, California 95051
  United States of America
  (408) 551-4545

Industry Canada Statement

This Class B device meets all requirements of the Canadian interference-causing equipment regulations.

Cet appareil numérique de la Class B respecte toutes les exigences du Règlement sur le matériel brouilleur du Canada.

European Compliance Statement
This product complies with the requirements of European Directives 72/23/EEC and 89/336/EEC.

Information for Optical Pointing Device

This product is a Class 1 LED device in accordance with IEC 60825-1 A1 A2.

CE Notice (European Union)

Marking by 〔CE〕 the symbol indicates compliance of this Stowaway keyboard to the Electromagnetic Compatibility Directive and the Low Voltage Directive of the European Union. Such marking is indicative that this Stowaway keyboard meets the following technical standards:

- EN 5502 – "Information Technology Equipment – Radio Disturbance Characteristics – Limits and Methods of Measurement."
- EN 55024 – "Information Technology Equipment - Immunity Characteristics - Limits and Methods of Measurement."
- EN 60950 – "Safety of Information Technology Equipment."

NOTE: EN 55022 emissions requirements provide for two classifications:

- Class A is for typical commercial areas.
- Class B is for typical domestic areas.

This Think Outside device is classified for use in a typical Class B domestic environment.

EN 55022 Compliance (Czech Republic Only)

This device belongs to Class B devices as described in EN 55022, unless it is specifically stated that it is a Class A device on the specification label. The following applies to devices in Class A of EN 55022 (radius of protection up to 30 meters). The user of the device is obliged to take all steps necessary to remove sources of interference to telecommunication or other devices.

Pokud není na typovém štitku počítače uvedeno, že spadá do třídy A podle EN 55022, spadá automaticky do třídy B podle EN 55022. Pro zařízení zařazená do třídy A (ochranné pásmo 30m) podle EN 55022 platí následující. Dojde – li k rušení tlekomunikačnich nebo jinych zařizení, je uživatel povinen provést taková opatření, aby rušení odstranil.

Europe – CE Declaration of Conformity

EN 301 489-1 (December 2001), EN 301 489-17 (December 2001), EN 300 328-1 (August 2002), EN 300 328-2 (August 2002), EN 60950 (January 2000)

$$CE$$

English	Hereby, Think Outside, Inc. declares that this XTBT01 is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC.
French	Par la présente Think Outside, Inc. Déclare que l'appareil XTBT01 est conforme aux exigences essentielles et aux autres dispositions pertinentes de la directive 1999/5/CE.
	Par la présente, Think Outside, Inc. Déclare que ce XTBT01 est conforme aux exigences essentielles et aux autres dispositions de la directive 1999/5/CE qui lui sont applicables.
German	Hiermit erkält Think Outside, Inc., dass sich *dieser/diese/dieses* XTBT01 in Übereinstimmung mit den grundlegenden Anforderungen und den anderen relevanten Vorschriften der Richtlinie 1999/5/EG befindet. (BMWi)
	Hiermit erkält Think Outside, Inc. die Übereinstimmung des Gerätes tastatur mit den grundlegenden Anforderungen und den anderen relevanten Festlegungen der Richtlinie 1999/5/EG. (Wien)
Italian	Con la presente Think Outside, Inc. Dichiara che questo XTBT01 è conforme ai requisiti essenziali ed alle altre disposizioni perteinenti stabilite dalla direttiva 1999/5/CE.

Spanish	Por medio de la presente Think Outside, Inc. Declara que el XTBT01 cumple con los requisotas esenciales y cualesquiera otras disposiciones aplicables o exigibles de la Directiva 1999/5/CE.
Portuguese	Think Outside, Inc. Declara que este XTBT01 está conforme com os requistos essenciais e outra disposições da Directiva 1999/5/EC.
Finnish	Think Outside, Inc. Vakuuttaa täten että XTBT01 tyyppinen laite on direcktiivin 1999/5/EY oleellisten vaatimusten ja sitä koskevien directiiven muiden ehtojen mukainen.
Dutch	Hierbij verklaart Think Outside, Inc. Dat het toestel XTBT01 in overeenstemming is met de essentiële eisen en de andere relevante bepalingen van richtlijn 1999/5/EG.
Swedish	Härmed intygar Think Outside, Inc. Att denna XTBT01 står I överensstämmelse med de väsentliga egenskapskrav och övriga relevanta bestämmelser som framgår av direktiv 1999/5/EG.
Danish	Undertengnede Think Outside, Inc. Erklærer herved, at følgende udstyr XTBT01 overholder de væsentlige krav og øvrige relevante krav i direktiv 1999/5/EF.
Greek	ΜΕ ΤΗΝ ΠΑΡΟΥΣΑ Think Outside, Inc. ΔΗΛΩΝΕΙ ΟΤΙ XTBT01 ΣΥΜΜΟΡΦΩΝΕΤΑΙ ΠΡΟΕ ΤΙΣ ΟΥΣΙΩΔΕΙΣ ΑΠΑΙΤΗΣΕΙΣ ΚΑΙ ΤΙΣ ΛΟΙΠΕΣ ΣΧΕΤΙΚΕΣ ΔΙΑΤΑΞΕΙΣ ΤΗΣ ΟΔΗΓΙΑΣ 1999/5/E

France

Some areas of France have a restricted frequency band. The worst case maximum authorized power indoors is:

10 mW for the entire 2.4 GHz band (2400 MHz–2483.5 MHz).

100 mW for frequencies between 2446.5 MHz and 2483.5 MHz (NOTE—Channels 10
through 13 inclusive operate in the band 2446.6 MHz to 2483.5 MHz).

There are few possibilities for outdoor use: On private property or on the private property of public persons, use is subject to a preliminary authorization procedure by the Ministry of Defence, with maximum authorized power of 100 mW in the 2446.5–2483.5 MHz band. Use outdoors on public property is not permitted.

In the departments listed below, for the entire 2.4 GHz band:

Maximum authorized power indoors is 100 mW.

Maximum authorized power outdoors is 10 mW.

Features and Specifications Summary

- Small, palm-sized design makes it easy to put in your pocket or briefcase.

- Simple connection compatibility with your Pocket PC device via Bluetooth.

- Large, accessible mouse buttons and rubberized scroll wheel.

- User-programmable button shortcuts for faster access to applications.

- On-screen menu and toolbar navigation via mouse

- Does not draw power from your Pocket PC device.

- Easy glide pads underneath the mouse for ease of movement.

- Included travel pouch and two AAA batteries.

Dimensions: 3.74"L x 2.17"W x 1.38"H) (95mm x 55mm x 35mm)

Weight (including batteries):   3 ounces (75 grams)

Operating Temperature Range: 32° to 122°F (0° to 50°C)

Typical Battery Life: Continuous Operation: ~30 hours
                              Typical usage: ~3 weeks
                              Standby: ~2500 hours

RF Technical specifications

RF output power: Class 2. Maximum output power is 2.5mW (4 dBm).
Protocol: Bluetooth specification v. 1.1 compliant. Bluetooth HID Profile v. 1.0 compliant.
Frequency range: 2.4 – 2.4835GHz
Type of Modulation: GFSK (Gaussian Frequency Shift Keying).
Signal Type: FHSS (Frequency Hopping Spread Spectrum)