User Manual

Please read this manual before use

Welcome use senior mobile phone

charger plug   headset jack

Display screen

FM radio turn on/off key   Receiver   Torch turn on/off key

Up arrow key   Ending key

Talking key   Down arrow key

Mp3 turn on/off key   Keypad lock/unlock key

speed dial key/reduce volume key   One key large Volume   speed dial key/add volume key

Key Instruction

| Key	Function
Talking key	1.Dialing: press to make a calling 2.Incoming calls: press to listen the calling 3..In standby mode ,press to check calls log 4.when operation: press to confirm a selection
End key	1.When power on :Press for a second to switch off 2.When power off: press for a second to switch on 3.when operation :press to return last menu. press for a second and return to standby mode 4.Emergency dialing: press for a second to exit emergency dialing
Up Arrow key	1.Press to enter main menu when in standby mode 2.When operation: press to move the cursor up
Down Arrow key	1.Press to enter phone book in standby mode 2. When operation: press to move the cursor down
#key	1.Under standby mode, Press for a second can dial the pre-set contact number directly. 2.Short press to type "#" 3.Press to change input method under edit mode.
*key	1.Under standby mode, Press for a second can dial the pre-set contact number directly. 2.Short press to type "*". 3.Press to select symbol under edit mode.

Key Instruction

Key	Function
One key large volume	Under hands free when conversation. press to make to the volume to meet your desired volume
Volume key	1.Press "+" to add volume 2.Press "−" to reduce volume (can use them under conversation mode;FM radio playing interface and volume adjust mode.
FM radio key	1.Push down to turn on the radio 2.Push up to turn off the radio
Keypad lock key	1.Push down to unlock the keypad 2.Push up to lock the keypad
Keypad lock key	1.Push down to unlock the keypad 2.Push up to lock the keypad
SOS dial key	1.SOS dialing is off, press it to dialing the SOS number 2.SOS dialing is off, press it ,screen will display "restart SOS key select "start", to enter SOS dialingFunction

Start to use

Please remove the battery cover: install the SIM card by sliding it into its nest and under the metal holding plate.

Install the battery into the battery slot and put on the cover, make sure that the three metallic stripes on the battery align with the three metallic prongs in the battery slot.

Press this key [ ] for a second to turn on the phone

One key directly MP3 player

Push the MP3 key down , user can listen music

One key directly MP3 player

Support TF card

Please turn off the phone. Remove the battery and other external power, Install TF card by sliding it into its nest and under the metal holding plate.

SOS

When any un-expect emergency happen, user can press the SOS key, the phone will issue an SOS signal and an SOS message will be sent to the emergency contact numbers which you had preset.

And the first number on the list will be call first. if the select number is not available, the phone will continue with the next number on the list. until there is one answer from one of the number .the Emergency dialing will automatic circulate in 5 times.

SOS

How to Set SOS emergency contact number?

Select [setup] ➡ [SOS dialing setting] ➡ [SOS list] ➡ [add number]

1. it can set 5 SOS emergency contact number(max. 5)
2. Under any mode, Push SOS key, the phone will auto send text message and repeat dialing
3. Push SOS key by mistake, Please push it to it's original position

One key large Volume

When conversation. User can press large volume button for a second to turn the volume to large if he could not hear clearly

---

**One key large Volume**

How to set one key large volume ?
Press up arrow key to enter main menu to select

[setup] ▶ [phone setting] ▶ [adjust volume] ▶ [one key large volume]

Press Arrow up/down key or volume key to adjust.
press up key or volume key + to add volume, press down key or volume key – to reduce volume.
Press talking key to confirm the setting when finish.

Family love speed dial

In order to make an easy dialing, the phone build in speed dial function. It is possible to enter 10 speed dial numbers that can be call from the standby mode by pressing the corresponding number button(2-9,*and #) .

*button with a female icon;

#button with a male icon.

User can set :
Frequent contact family love female telephone number under*Frequent contact family love male telephone number under#
How to set speed dial number?

Select [phonebook]➡[Speed dial]

User can direct use the contact number from phonebook as the speed dial number.

FM radio

You can use to listen FM radio whether SIM card is installed in the phone or not. User can use both headset and phone speaker to listen the radio

FM radio

1. Turn on the radio: under standby mode, push down the FM radio key to turn on the radio player
2. Turn on the radio: under the radio player interface, push up the FM radio key to turn off the radio player
3. Operate instruction: Turn on the radio to enter the radio player interface. Press arrow up/down key to set the channel. User can input the desire channel too. Press talking key(green key) to move cursor

enter the radio player interface. Press arrow up/down key to set the channel. User can input the desire channel too. Press talking key(green key) to move cursor, press "+to enter automatic scan channel and press end key to exit. it will display the channel when a radio station is available, and inform whether you would like to continue or not, press green key to go on scan radio station. Press end key to turn back the radio player interface.(if press "*"again, it will restart to scan radio station)

4.Press end key(red key)to stop the playing. but it will not exit the radio player interface, press end key(red key)again to go on listening the radio.

5.Press "#"for a second to lock the keypad, press for a second again to unlock the keypad.

6.Adjust volume: when listening, press volume key"+to adjust radio volume.

7.Plug headset, push the key down to star the FM radio output, push the key up to turn off the FM radio function.

Torch

When you need lighting under darkness or night, user can push up the torch key, the phone will turn on the torch to meet you desired lighting. Torch can use under phone power off.

Torch

Locking the Keypad

This Key prevent keys being accidentally pressed while you don't like to operate the phone. Push the key up to lock the keypad. the phone standby interface turn to the locking interface and display time. You need to push the key down to unlock the keypad when you want to make a calling or to operate the phone.

Locking the Keypad

Alarm

For remind time convenience, there is alarm function with the phone. User can set the desired alarm time and the alarm ringtone.

Setup ➡ phone setting ➡ Ringtone ➡ Alarm ring

Incoming calls voice number report

User profile➡personal setting➡ incoming calls➡ voice remind

User this function, the phone will report a contact name or contact number with a voice when there is a incoming call,

Voice report

Setup➡voice report

User this function, under dialing number mode, there is a human voice will talk the number you input.

Set time and date

Setup➡phone setting➡time setting

Use this function can set the time and date and set the date format.

Remark: Time only support 24 format

Image is for reference , detail is base on the phone.