ELLIX 20

RECEIPT PRINTER

OPERATOR'S Manual

All specifications are subject to change without notice

Warning - U.S.

This equipment has been tested and found to comply with the limits for a Class A digital device pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates uses, and can radiate radio frequency energy and , if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

Notice - Canada

This Apparatus complies with class "A" limits for radio interference as specified in the Canadian department of communications radio interference regulations.

Get appareil est conforme aux normes class "A" d'interference radio tel que specifier par ministre canadien des communications dans les reglements d'interference radio.

Caution

Some semiconductor devices are easily damaged by static electricity. You should turn the printer "OFF", before you connect or remove the cables on the rear side, in order to guard the printer against the static electricity. If the printer is damaged by the static electricity, you should turn the printer "OFF".

INTRODUCTION

The ELLIX 20 Roll Printer is designed for use with electronic instruments such as system ECR, POS, banking equipment, computer peripheral equipment, etc.

The main features of the printer are as follows:

1. High speed printing : 52 lines per second.
2. Low noise thermal printing.
3. RS-232 serial / IEEE1284 parallel / USB / Ethernet / Bluetooth / Wireless LAN interface.
4. The data buffer allows the unit to receive print data even during printing.
5. Peripheral units drive circuit enables control of external devices such as cash drawer.
6. Characters can be scaled up to 64 times compared to it's original size.
7. Bar code printing is possible by using a bar code command.
8. Different print densities can be selected by DIP switches.
9. 2-dimantional bar code(PDF-417) and Two color printing.

Please be sure to read the instruction in this manual carefully before using your ELLIX20.

NOTES : The socket-outlet shall be near the equipment and it shall be easily accessible.

Table of Contents

CHAPTER 1. SETTING UP THE PRINTER 4
1-1. UNPACKING 4
1-2. CONNECTING THE CABLES 5
1-3. CONNECTING THE COMPUTER 6
1-4. CONNECTING THE DRAWER 7
1-5. CONNECTING THE POWER SUPPLY 8
1-6. INSTALLING OR REPLACING THE PAPER ROLL 10
1-6-1. Partition Installation 11
1-6-2. Wall Mount Installation 12
1-6-3. Paper Roll Installation 13
1-7. ADJUSTMENTS AND SETTINGS 14
1-7-1. Serial Interface Specification 15
1-7-2. Parallel Interface Specification 16
1-8. USING THE PRINTER 17
1-8-1. Control Panel 17
CHAPTER 2. HEXADECIMAL DUMPING 18
CHAPTER 3. THE SELF TEST 19
CHAPTER 4. CODE TABLE 20
CHAPTER 5. CONTROL COMMANDS 32
5-1. EPSON MODE COMMANDS 32
5-2. STAR MODE COMMANDS 35
APPENDIX 38
A. MISCELLANEOUS NOTES 38
B. TWO-COLOR PRINTING 40
C. RECOVERY FORM THE AUTO CUTTER ERROR 41
D. PRINTER HEAD CLEANING 42
E. CONNECTORS 43
D.1 Interface Connector 44
D.2 Drawer Connector 47
F. ERROR STATUS 48
G. ADJUSTING THE ROLL PAPER NEAR-END SENSOR LOCATION 50
H. SPECIFICATION 51
G.1 General Printer specification 51
G.2 Paper specification 52

Click here to download the full manual at THE-CHECKOUT-TECH.COM