Multimedia Navigation System

Owner's Manual

Ford Mustang

*FOR MODELS WITH FORD SYNC® ONLY

Navigation

Bluetooth Hands-Free (For use with Sync)

iPod® and MP3 compatible (For use with Sync)

Back-up camera included

Play Audio CDs and MP3 Discs (For use with Sync)

Supports steering wheel controls

Customizable backgrounds

Satellite Radio (For use with Sync)

CARSHOW

Operational Panel

Button Functions

1) DISP Button:

• Press this button to dim backlight.

• Press this button to turn display off.

2) NAV Button:

• Press this button to enter naviation mode; press again to return to current source.

3) MENU Button:

• Press this button to access the MENU option of the particular source.

4) Micro SD Card Slot:

• Holds Micro SD card that contains Navigation software.

AM/FM Source



1) Settings Button - This will take you to the settings page.

2) EQ Button - Enable/Cycles the EQ Menu.

3) RDS Text Organization- Cycles the organization of RDS text.

4) System Time Display

5) The current playing station

6) Temperature

7) Compass

8) Seek Up key- Next Station

9) Preset Channels

10) Source shortcut keys

11) Seek Down key - Previous Station

Scanning

Touch the current station to activate/deactivate scanning mode.

Step Tuning

1. Touch the [AM/FM] key to select radio band (FM1>FM2>AM1)

2. Long touch the [<<] / [>>] key to search to the next strong signal station.

3. Short touch the [<<] / [>>] key to tune backward or forward one step.

Preset List

Touch a preset key for 3 seconds to store a new channel.

SAT Source



1) Settings Button - This will take you to the settings page.

2) EQ Button - Enable/Cycles the EQ Menu.

3) RDS Text Organization- Cycles the organization of RDS text.

4) System Time Display

5) The current playing station

6) Temperature

7) Compass

8) Seek Up key - Next Station

9) Preset Channels

10) Source shortcut keys

11) Seek Down key - Previous Station

Scanning

Touch the current station to activate/deactivate scanning mode.

Step Tuning

1. Touch the [SAT] key to select radio band (SAT1>SAT2>SAT3)

2. Short touch the [<<] / [>>] keys to tune backward or forward one station

Preset List

Touch a preset key for 3 seconds to store a new channel.

CD Source

1) Settings Button - This will take you to the settings page.

2) EQ Button - Enable/Cycles the EQ Menu.

3) Song info text organization

4) System Time Display

5) Temperature

6) Compass

7) Next Track

8) Pause/Play

9) Source shortcut key

10) Previous Track

11) Seek Down [Only for folders]

12) Seek Up [Only for folders]

13) Scan Enable/ Disable Scan feature

14) Eject Disc

SYNC Line In Source

1) Settings Button - This will take you to the settings page.

2) EQ Button - Enable/Cycles the EQ Menu

3) Song info text organization- Not Used

4) System Time Display

5) Temperature

6) Compass

7) Displays current SYNC source - SYNC Line In

8) Next Track - Not Used

9) Pause/Play - Not Used

10)Source shortcut key

11) Previous Track - Not Used

12) Seek Down - Not Used

13) Seek Up - Not Used

14) Folder - Not Used

15) Source- This button cycles SYNC Line In, SYNC USB, and Bluetooth Streaming

SYNC USB Source



1) Settings Button - This will take you to the settings page.
2) EQ Button - Enable/Cycles the EQ Menu
3) Song info text organization
4) System Time Display
5) Temperature
6) Compass
7) Displays current SYNC source - SYNC USB
8) Next Track
9) Pause/Play
10)Source shortcut key
11) Previous Track
12) Seek Down [Only for folders]
13) Seek Up [Only for folders]
14) Folder
15) Source- This button cycles SYNC Line In, SYNC USB, and Bluetooth Streaming

Bluetooth Streaming Source



Please note that your phone must be paired in order to enable BT streaming

1) Settings Button - This will take you to the settings page.
2) EQ Button - Enable/Cycles the EQ Menu
3) Song info text organization
4) System Time Display
5) Temperature
6) Compass
7) Displays current SYNC source - Bluetooth Streaming
8) Next Track
9) Pause/Play
10)Source shortcut key
11) Previous Track
12) Seek Down [Only for folders]
13) Seek Up [Only for folders]
14) Folder
15) Source- This button cycles SYNC Line In, SYNC USB, and Bluetooth Streaming

AV IN Source



The AV IN source allows for display of external video/audio. This source will automatically go to full screen. To exit, just tap anywhere on the touch screen and then select the desired source.

1) Settings Button - This will take you to the settings page.

2) System Time Display

3) Temperature

4) Compass

5)Source shortcut key

Cam Source

The Cam source will display the Backup camera.

Caution- Objects may be closer then they appear

The Cam source will automatically go to full screen. To exit, just tap anywhere on the touch screen and then press the back arrow on the top left corner.

Phone Source

1) Settings Button - This will take you to the settings page.

2) EQ Button - Enable/Cycles the EQ Menu

3) Song info text organization - No Function

4) System Time Display

5) Temperature

6) Compass

7) Keypad

8)Source shortcut key

9) >>| Navigate Phone menu

10) OK Navigate Phone menu

11) |<< Navigate Phone menu

12) Call - Press to answer or make a phone call

13) End- Press to answer or reject a phone call

14) Phone Menu display

Pairing Your Phone

Using the arrow keys, Navigate the Menu and select “Add Bluetooth Device”. A Pin number will then be generated and displayed on screen.On your device, search for SYNC and input the pin provided.When successfully connected the bottom right “Phone” tab will be highlighted blue. For more information please refer to your Vehicle User’s Manual.

Settings Page

Press to return to source

Set: Press set to go into Clock settings page

Beep: Enable/Disable Beep

Reverse: Enable/Disable auto Reverse feature

Illumination: Enable/Disable the auto illumination feature

Turn Info: Enable/Disable the Turn Info feature.

FW Version: Displays the FW Version.

CS1015 Rev A

All rights reserved. Copyright 2012 CarShow Electronics