SONY

DVD Home Theatre System   DAV-FR9

4-255-442-**11**(1)

Speakers – Connection and Installation

The speaker cords and plugs are colour-coded with their respective speaker terminals.
Do not connect any speakers other than those supplied with this system.
For best performance, we recommend speaker placement as shown.
Be sure to see note descriptions of the Operating Instructions for details.

A	B	C	D	E	F
Red	Green	White	Grey	Purple	Blue