

# SPA-3 Stereo Precision Attenuator

# O where the second seco





# **SPA-3 STEREO PRECISION ATTENUATOR**

# **I. DESCRIPTION**

The SPA-3 is a stereo precision attenuator accessory for use with DataPortequipped QSC amplifiers. It mounts directly to the back of two-channel CX, DCA, and PL2 models, but it can be used with the others (PowerLight, ISA, and fourchannel CX or DCA amplifers) by using a DataPort cable and a remote mounting rack. Amplifiers from the ISA series cannot power the SPA-3, so it requires a 15-volt external DC power supply when used with one of them.

SPA-3 SPECIFICATIONS		
GENERAL INFORMATION		
Operating temperature	0–70° C	
Input type, each channel	Differential balanced (transformer balancing optional)	
Input impedance	28.4 k $\Omega$ balanced, 14.7 k $\Omega$ unbalanced	
Output impedance	95 $arOmega$ , quasi-balanced	
Maximum RMS output voltage	+18 dBu	
Equivalent input noise (ref. to max. output level)	less than -100 dBr	
Dynamic range	116 dB	
THD @ 1 volt	< 0.03%	
Frequency response	20 Hz–20 kHz, ±0.2 dB	
Common-mode rejection	>50 dB minimum; >60 dB typical	
Power requirements	+15V @ <300 mA via ext. power jack, or from amplifier via pin 9 of DataPort	
CONTROLS		
Programming	Pushbutton switches for incremental adjustment: Shift, Up, and Down	
INDICATORS		
Attenuation (each channel)	2-digit 7-segment LED display	
Signal presence (each channel)	Green LED	
0.5 dB indicator (each channel)	Decimal point	
CONNECTORS		
Input	Two 3-pin "Euro-style" detachable terminal blocks	
DataPort	HD15 male (to amplifier)	
External power	2.5 mm coaxial jack; center pin positive	
PROGRAMMABLE OPERATING PARAMETERS		
Attenuation	0 to 32 dB in 0.5- or 1.0-dB increments	
Bypass	Either channel	



# **Kit contents**

These parts are included along with your SPA-3 module:

Qty	QSC part #	Description
2	CO-000137-00	3-pin "Euro-style" plug
2	SC-040181-PP	#4-40 × 1 1/8" black screw
1	SC-080051-PP	#8-32 × 5/16" black screw



The screws are for mounting the SPA-3 to an amplifier or accessory bracket (see INSTALLATION), and the two plugs are detachable terminal blocks for the SPA-3's two balanced inputs (see the illustration above).

# II. FEATURES

The heart of the SPA-3 is a Crystal Semiconductor digitally controlled dual-channel gain control. The user controls are pushbuttons for adjusting the amount of attenuation, for bypassing (unity gain), for changing the adjustment increment, and for displaying the firmware version.

Both channels feature electronically balanced input circuitry. The pseudo-balanced outputs connect to the amplifier through the DataPort. The attenuation can be adjusted from 0 to 32 dB and can also be bypassed. A green LED for each channel indicates that its pre-attenuation circuitry is passing a signal. The settings are non-volatile and are retained when the amplifier is turned off.

To improve common-mode noise rejection, an optional XF-1 input isolation transformer can be installed on each channel by a qualified technician.

# **III. INSTALLATION**

# igacha CAUTION: Always turn the amplifier off when installing or removing the SPA-3.

# **Connecting inputs**

The signal wires attach to each "Euro-style" terminal block as shown in the illustration at the top of this page. Pay attention to signal polarity. Strip the wires approximately 0.35 inch (9 mm). The screw head above each terminal opens and closes its clamp; after <sup>(9)</sup> inserting the wire in the terminal, tighten the clamp firmly.

If the input signal is unbalanced, use the + terminal for the signal conductor and *both* the - and shield terminals for the shield.



The terminal blocks plug into their respective jacks on the SPA-3. Attaching the SPA-3 to the amplifier

# PowerLight 2 and two-channel CX, DCA amplifiers

Line up the SPA-3's DataPort connector with the one on the amplifier's rear panel. Press the SPA-3 onto the amplifier and secure it to the chassis with the three screws included (see the illustration above).

Ø

# PowerLight, ISA, and four-channel CX and DCA amplifiers

An SPA-3 will not physically mount on one of these amplifiers. A DPX-4 accessory bracket, however, can hold up to four SPA-3 units. Use a DataPort cable to connect the SPA-3 to the amplifier. The SPA-3 will draw the power it needs from the DataPort of PowerLight, CX and DCA amplifiers, but if used with an ISA series amplifier, it will require an external 15-volt DC power supply capable of 300 mA, such as a QSC DPX-1.

Operation	Press (n = Channel #)
Increase signal (decrease attenuation)	<b>UP</b> n
Increase signal (scroll)	Hold <b>UP</b> n
Decrease signal (increase attenuation)	DOWNn
Decrease signal (scroll)	Hold <b>DOWN</b> <i>n</i>
Bypass/engage attenuation (toggle)	SHIFTn + UPn
Increment step toggle (1 or 0.5 dB)	SHIFT <i>n</i> + DOWN <i>n</i>
Display firmware version	SHIFT1 + SHIFT2
Mute Channel 1	SHIFT2 + UP1
Mute Channel 2	SHIFT1 + UP2
Lock Channel 1	SHIFT2 + DOWN1
Lock Channel 2	SHIFT1 + DOWN2

# IV. OPERATION

The table at left shows the button sequences for all possible operations on the SPA-3.

The adjustable range of attenuation on each channel is 0 (no attenuation) to 32 dB. The attenuation changes in real time as you make the adjustments. Halfdecibel settings are indicated by the right decimal point of the two-digit display. For example, a display of **18** indicates a setting of 18 dB of attenuation, while **19** would indicate 18.5 dB. Even when its DC power is removed, the SPA-3 will retain its settings in non-volatile memory.



The buttons, displays, and other features of the SPA-3

# V. WARRANTY AND DISCLAIMERS

# Disclaimer

QSC Audio Products, Inc. is not liable for any damage to speakers, amplifiers, or any other equipment that is caused by negligence or improper installation and/or use of the SPA-3.

# **Product Warranty**

OSC Audio Products, Inc. guarantees the SPA-3 to be free from defective material and/or workmanship for a period of three years from date of sale, and will replace defective parts and repair malfunctioning products under this warranty when the defect occurs under normal installation and use—provided the unit is returned to our factory via prepaid transportation with proof of purchase (sales receipt). This warranty provides that examination of the returned product must disclose, in our judgment, a manufacturing defect. This warranty does not extend to any product which has been subject to misuse, neglect, accident, improper installation, or where the date code has been removed or defaced.

# VI. TECHNICAL ASSISTANCE & SERVICE

Only a qualified technician should service your QSC product. There are no user serviceable components inside the unit and the risk of electric shock exists. Also, some components in your unit may require specific QSC replacements.

### **Technical Assistance**

If you suspect that your SPA-3 is defective, check your system configuration and SPA-3 settings to determine the origin of the problem. Incorrect audio interfacing, poor cabling, or other system-level defects are the most frequent causes of problems in audio systems. For technical assistance beyond the scope of this manual, contact QSC Technical Services. We also offer comprehensive service manuals for many QSC models; contact us for details.

### **Factory Service**

If your SPA-3 needs factory service, contact QSC Technical Services for return instructions. We will issue you a Return Authorization (RA) number for each unit. QSC cannot be responsible for products that are returned without an RA number.

### Product Return Guidelines

- 1. Pack the product well for protection during shipment. Upon request, QSC will provide a factory shipping carton and packaging free of charge.
- 2. Include a copy of the sales receipt, your name, return address, and phone number with your return correspondence. Please include a reasonably detailed description of the defect.
- 3. Call QSC Technical Services for a Return Authorization number.
- 4. Mark the Return Authorization number on the outside of the packaging.
- 5. Ship the product prepaid to QSC Technical Services at the address listed below. We recommend United Parcel Service (UPS).

OSC Technical Services		
1665 MacArthur Blvd. Costa Mesa, California 92626 USA		
	v.qscaudio.com (product info and support) v.qscstore.com (service and accessory sales)	
E-mail: tech	_support@qscaudio.com	
Telephone:	(800) 772-2834 (USA only) +1 (714) 957-7150 +1 (714) 754-6175	
Fax: Bulletin Board:	+1 (714) 754-6173 +1 (714) 668-7567	

### **Qualified Service Centers**

For your convenience, QSC maintains a network of qualified service centers. If you wish to take your QSC product to a local service center, you may call QSC Technical Services for a referral for one near you. However, accessories, input modules, and other peripheral QSC products must be returned to the QSC factory for service.

### **International Servicing**

For service on QSC products purchased outside of the United States, contact the distributor or dealer in the country where the product was originally purchased. In many countries, the distributor or dealer may also refer you to a qualified service centers. QSC Technical Services can help you contact the distributor in your country.

