

# *American DJ® User Instructions*

## **Splitter™**



**CAUTION!** Read instructions before installing or plugging unit in.

### **SPECIFICATIONS: MODEL - Splitter™**

<b>Weight:</b>	18lbs.
<b>Size:</b>	22.5"H x 6"W x 8.75"L
<b>Lamp:</b>	ZB- EHJ 24v/250w
<b>Fuse:</b>	4A GMA
<b>Voltage:</b>	120V
<b>Working Position:</b>	Any Safe position
<b>Duty Cycle:</b>	10 min. on 10 min. off
<b>Cooling:</b>	Fan cooled
<b>Optics:</b>	High quality glass lens Reflective dichoric mirror

### **HALOGEN LAMP WARNING!**

This fixture is fitted with a halogen lamp which is highly susceptible to damage if improperly handled. Never touch lamp with bare fingers as the oil from your hands will shorten lamp life. Also, never move fixture until lamp has had ample time to cool. Remember, lamps are not covered under warranty conditions.

### **Operating Instructions:**

Unit is ready to be hung or set on flat surface. After plugging unit in, the outer mirror dish will react to bass sound via the internal microphone. The internal dichoric color wheel will also rotate to sound. Adjust the sensitivity knob on the bottom of the unit for sound sensitivity. Focus the front lens so the beam patterns are in focus for the height the fixture is mounted. Be sure not to obstruct the cooling vents and keep in a well ventilated area. For best effect, periodically clean the front focus lens and mirror with a glass cleaner.

Caution! Never open unit when in use. Always disconnect main power before servicing or replacing lamp.

Remember to always replace with the same lamp and fuses, unless otherwise specified by technician.

Lamp Replacement: Open the front cover by removing the two thumb screw. Pull lamp out and remove it from socket. Remove and replace lamp.

The *American DJ* Splitter™ comes with a 90 day limited warranty. We recommend filling out the warranty registration card that came with your fixture to validate your warranty. For service contact *American DJ*™

*Affordable Quality Lighting Products From American DJ® Los Angeles, CA. 90058*