



ATD-8835
**ELECTRONIC HEARING
PROTECTION**
85 dB



INSTRUCTION MANUAL

SAVE THIS MANUAL

You will need this manual for the safety instructions, assembly instructions, operating procedures, parts list, and warranty. Put this manual in a safe place for future reference.

IMPORTANT SAFETY INSTRUCTIONS

WARNING! When using electric tools, machines or equipment, basic safety precautions should always be followed to reduce the risk of fire, electric shock and personal injury.

SPECIAL FEATURES



ATD-8835

- Eliminates noise over 85dB
- 1. LED power indicator light
- 2. On/Off switch with volume control
- 3. Fully adjustable headband
- 4. Multi-position ear cushions
- 5. Built-in microphone amplifies low sounds



IMPORTANT SAFETY INSTRUCTIONS

On/Off Switch and Volume Control

To turn on the hearing protection, rotate the switch knob clockwise. The LED power indicator will light up indicating the hearing protection are on. Adjust the volume by rotating the switch knob until the noise level is at a comfortable level. To turn off the hearing protection rotate the switch knob counter-clockwise until it clicks off and the LED power indicator has faded.

OPERATION (CONT.)

Fitting the Hearing Protection

Place the headband over your head ensuring the headband follows the contour of the top of your head.

Guide one ear cushion over your left ear and one over your right ear. Slowly allow the headband to draw each cushion over your ears ensuring both cushions form comfortable cupped seals over each ear. If the ear cushions do not sit centrally over both ears they should be repositioned by moving them up or down the slot on the headband until both ear cushions are centered and sit comfortably and tightly over both ears.

If possible use an available noise source to check the seal formed over both ears and if required slightly re-adjust the ear cushions to achieve optimum hearing protection.

Installing/Removing the Batteries

The batteries fit within the ear piece which has the On/Off Switch.

- Lift the ear cushion from the ear piece using a coin or similar flat object in the slot provided.
- Remove the ear cushion and foam.
- Install new AA batteries, one into each separate cavity. Ensure you insert the negative and positive ends of the batteries as indicated within the cavity.
- Reassemble the foam and ear cushion back to the ear piece.



Note:

Requires (2) AA batteries (not included). Always replace both batteries at once, failure to do so may affect the performance of the hearing protection.