

connect **IT**<sup>®</sup>

## **WARLORD MOUSE**



**USER MANUAL**

# 1 System Requirements

- Microsoft Windows
- PC with a built-in USB port
- Optical drive
- 50 MB free disk space

# 2 Installation

1. Install a software from CD included in package contents or download it from <http://www.connectit.cz/wp-content/uploads/2014/12/ci-390-software.zip>.
2. Open the driver folder and launch the setup.exe file.
3. Click "Next".
4. Click "Finish" to finish installation.
5. Plug the WARLORD MOUSE into your computer and wait for succesful finish of the driver installation.

**Note:** For use with UEFI BIOS equipped motherboards is necessary to „Disable“ xHCI in USB settings.

# 3 Software

## Basic Settings

Basic Settings is the opening screen of the included software for the Warlord mouse. Here, you can assign various functions to keys (see the Key Settings table), set DPI values in four levels, backlight, report rate (the higher the better).



## Key Setting

Left Click	Left Click
Right Click	Right Click
Mid Click	Mid Click
Forward	Forward
Backward	Backward
Triple-click	Left triple click
DPI Switch (+/-/Loop)	DPI switching (increase, decrease, loop)
RGB On/Off	Backlight on/off
Windows	Launching a multimedia player, an e-mail client, calculator, explorer etc.)
Multimedia	Next/previous track, stop, play/pause, mute, volume increase/decrease)
Fire Key	Simulates repeated pressing of a key (the key has to be selected from a list), speed and number of repetitions can be set
Single Key	Keystroke assignment
Combo Key	Shortcut assignment
Macro Key	Macro assignment, the macro needs to be first recorded on the screen "Advanced Settings"
Shift	This function has to be set in Mode A, while holding the button you can use functions of the buttons set in Mode B.
Key Off	Switching off a key

## Report Rate Setting

Sets the frequency of the mouse to sense commands. The higher the value, the shorter response time to commands.

## DPI Setting

Enables setting four levels of resolution from 250 to 4000 DPI, backlight color (Color), or the level can be switched off/on if required (Select).

## DPI Effect

Standard mode	Mouse continuously lit
Respiration mode	Backlight slowly lights and goes out, the speed of the cycle can be regulated using a parameter
Neon mode	Mouse flashing, cycle speed can be regulated using a parameter

## Advanced Settings

Advanced Settings can be accessed via the gear icon in the top left corner of the application. Here, you can set response, scroll wheel speed, double-click speed, and you can record macros.



Mouse speed	Response
Enhance precision of the pointer	Enhance precision of the pointer
Scrolling speed	Scroll wheel speed
Scroll one screen	Move by one page
Double-click speed	Double-click speed

## Macro Setting

Macro is a record of keys that are pressed on a keyboard during its recording. It is used to facilitate simple repeated tasks (such as retrieving magic in a game etc.).

### Recording

1. Enter the name of the macro in the field below the buttons "Start recording" and "Stop recording"
2. Set the number of repetitions
3. Click "start recording"
4. Press the keys that you want to record in the macro (use "Insert a mouse event" to insert a mouse action)
5. Press "Stop recording"
6. Assign the macro to a selected key in "Basic Settings"