

Commissioning (first commissioning after delivery from factory)

Heed the WMF 1000 user manual, especially the hazard instructions and the Safety chapter.



WMF 1000

Unpacking and Setting up

- * Unpack coffee machine and set up on a stable, horizontal support
- * Check the coffee machine for possible transport damage
(in case of doubt: do not put machine into operation and contact WMF service)
- * Plug the connector into a grounded outlet
- * Assemble the optional bean hopper attachment
- * Insert drip tray and drip tray grid

Test water hardness

- * Plunge included carbon hardness test strips briefly in water (approx. 1 second)
 - * One minute later, read the degree of hardness on the colour scale of the test strip package
- The water hardness is set during commissioning.

Prepare water tank

- * Remove the water tank from the coffee machine
 - * Remove all accessories from the water tank
 - * Rinse the water tank thoroughly with tap water
- Do not put the water tank back into the machine yet. The milk hose must be assembled first.

Insert the WMF tank filter

- * Remove the screen built into the water tank [1]
- * Place the cartridge adapter on the water spout supports from above (lock pulled) and lock by pressing the lock down [2]
- * Unpack the tank filter cartridge and place on the cartridge adapter [3]



With water hardness 0-4, do not use a tank filter.

Assemble the milk hose

The milk hose is already mounted on the all-in-one spout.

- For refrigerated milk, use the transparent milk nozzle (assembled on delivery)
- For non-refrigerated milk, use the grey milk nozzle from the accessories
- * Push the all-in-one spout to the lowest position
- * Insert the milk hose into the guide



Fill the water tank

- * Fill the water tank with cold tap water (max. 2.8 litres)
- * Push the water tank back into the machine

Fill the water tank only with fresh, cold water. Never use hot water, mineral water, milk or other liquids.



Packaging material in the carton contains accessories! Do not throw away!

Keep the original packaging for a possible return!

For information about the accessories and the names of the machine parts, see the user manual!

For technical data, see the user manual!

Do not loosen any screws or remove housing parts - inside the machine there is deadly peril due to mains voltage!



Set all-in-One spout:

Press the adjustment lever to the right of the spout and then move the spout.



Connect milk hose to milk

- * Place the refrigerated milk directly to the right of the machine

Place the milk hose with the milk nozzle on it into the milk container. The hose end with the milk nozzle should reach to the bottom of the container.

Milk is a very delicate food. When handling milk, always heed hygiene. Heed the HACCP cleaning schedule! See user manual Chapter 7.

Fill ground coffee hopper

- * Open the cover towards the back
- * Fill coffee beans (max. 320 g),
- * Can be expanded to 500 g with optional, attachable coffee bean hopper
- * Close the cover

Heed that no foreign bodies land in the coffee bean hopper. Such foreign bodies can damage the grinders of the coffee mill. This damage is excluded from the warranty.

Switch on coffee machine / Commissioning program

- * Press the Off/C button
- The commissioning program is started.

```
language: english
OK: P change: -/+
```

The desired language for the display guidance is set here.

The commissioning program uses the display to lead you step by step through the commissioning. Follow the display texts.

```
initial setting up
of your WMF1000
```

The display goes out after 5 seconds and you are lead through the basic settings.

Time

```
time: hh:mm:ss
OK: P change: -/+
```

Date

```
date dd:mm:yyyy
OK: P change: -/+
```

Water hardness

```
water hardn.: 13-16
OK: P change: -/+
```

The machine now heats up!

```
heating up ...
```

- * Place a container for the rinse water under the all-in-one spout (approx. 200 ml)
- After the heating up, there is a coffee system rinse. This warms up all the lines.
Duration approx. 40 seconds.
Now the machine is ready to operate.

```
your selection pls
24.10.2006 08:15
```

We wish you great enjoyment with your WMF 1000!



↓P	select
↑P	confirm
↶	care button
↶	Browse backwards
⊞	Reduce value
⊞	Browse forwards
⊞	Increase value

The new values are saved when you exit the program.

The set values can be changed in the „Basic settings“ program after commissioning.

See user manual
Chapter 4 Settings